

**LiftMaster**  
ELITE SERIES®

**CSW200UL8™**

## **VEHICULAR SWING GATE OPERATOR**

### **OWNER'S MANUAL**



*Your model may look different than the model illustrated in this manual.*

**THIS PRODUCT IS TO BE  
INSTALLED AND SERVICED BY A  
TRAINED GATE SYSTEMS  
TECHNICIAN ONLY.**

Visit [www.liftmaster.com](http://www.liftmaster.com) to  
locate a professional installing  
dealer in your area.

This model is for use on vehicular  
passage gates **ONLY** and not  
intended for use on pedestrian  
passage gates.

This model is intended for use in  
Class I, II, III and IV vehicular  
swing gate applications.

**UL325**  
compliant



**UL991**  
compliant



# TABLE OF CONTENTS

<b>SPECIFICATIONS AND WARNINGS</b>	<b>2</b>
CSW200UL8™ MODELS OVERVIEW	2
UL325 MODEL CLASSIFICATIONS	3
SAFETY INSTALLATION INFORMATION	4
GATE CONSTRUCTION INFORMATION	5
REQUIRED ENTRAPMENT PROTECTION DEVICE LOCATIONS	6
REQUIRED ENTRAPMENT PROTECTION DEVICE LOCATIONS	7
SAFETY INSTALLATION INFORMATION	8
WARNING PLACARD PLACEMENT	8
<b>INSTALLATION</b>	<b>9</b>
INSTALLATION SETUPS	9
CONCRETE PAD AND ARM ATTACHMENT	10
STANDARD INSTALLATION LAYOUT	11
COMPACT INSTALLATION LAYOUT	12
UPHILL DRIVEWAY INSTALLATION (OPTIONAL)	13
POST MOUNTING PLATE INSTALLATION (OPTIONAL)	13
GATE ARM INSTALLATION	14
OUTPUT SHAFT ADJUSTMENT	14
CONTROL BOARD DESCRIPTION	15
SURGE SUPPRESSOR TERMINAL CONNECTIONS	16
<b>WIRING</b>	<b>17</b>
EARTH GROUND ROD INSTALLATION	17
120 VAC POWER CONNECTION	18
HEATER POWER CONNECTION	18
LINKING PRIMARY/SECONDARY OPERATORS	19
SOLENOID/MAGLOCK RELAY CONNECTION	20
FACTORY INSTALLED DC2000™ CONNECTION	21
DC2000™ DEVICE WIRING	22
PLUG-IN LOOP DETECTOR WIRING	23
120 VAC EXTERNAL LOOP DETECTOR WIRING	24
ENTRAPMENT PROTECTION DEVICES	25
ENTRAPMENT PROTECTION DEVICES	26
<b>ADJUSTMENTS</b>	<b>27</b>
SET GATE OPENING DIRECTION	27
LIMIT SWITCH ADJUSTMENT	28
CLUTCH ADJUSTMENT	28
RADIO RECEIVER PROGRAMMING	29
SETTING THE TIMER	30
ADJUSTING REVERSING SENSOR(S)	31
OMNICONTROL™ BOARD CONNECTIONS	32
<b>MAINTENANCE AND OPERATION</b>	<b>33</b>
MAINTENANCE	33
BUILT-IN RESET SWITCH	34
AUDIO ALARM	34
MANUAL DISCONNECT	35
<b>WIRING DIAGRAMS</b>	<b>36</b>
CSW200UL8™ AND CSW200ULDM8™	36
WIRING TABLE CSW200UL8™ AND CSW200ULDM8™	37
CSW200UL1HP8™	38
WIRING TABLE CSW200UL1HP8™	39
WIRING DIAGRAM DC2000™ FOR SINGLE AND DM	40
WIRING TABLE DC2000™	41

<b>TROUBLESHOOTING</b>	<b>42</b>
THE GATE WILL NOT OPERATE WITH REMOTE	42
RESETTING MOTOR(S)	42
TROUBLESHOOTING CHART	43
<b>REPAIR PARTS</b>	<b>44</b>
REPAIR PARTS ILLUSTRATIONS	44
HOW TO ORDER REPAIR PARTS	45
REPAIR PART NAMES AND NUMBERS	45
<b>ACCESSORIES</b>	<b>46</b>
<b>INSTALLATION CHECKLIST</b>	<b>47</b>
<b>WARRANTY POLICY</b>	<b>48</b>

## ⚠ WARNING

*Mechanical*

## ⚡ WARNING

*Electrical*


## CAUTION

When you see these Safety Symbols and Signal Words on the following pages, they will alert you to the possibility of **SERIOUS INJURY** or **DEATH** if you do not comply with the warnings that accompany them. The hazard may come from something mechanical or from electric shock. Read the warnings carefully.

When you see this Signal Word on the following pages, it will alert you to the possibility of damage to your gate and/or the gate operator if you do not comply with the cautionary statements that accompany it. Read them carefully.

### IMPORTANT NOTE

- *BEFORE attempting to install, operate or maintain the operator, you must read and fully understand this manual and follow all safety instructions.*
- *DO NOT attempt repair or service of your gate operator unless you are an Authorized Service Technician.*



# SPECIFICATIONS AND WARNINGS

## CSW200UL8™ MODELS OVERVIEW

### Single Motor and Stainless Models

#### CSW200UL8™ (Single Motor)

1/2 HP Motor, 120 Vac, 4 Amp.  
Maximum Gate Length – 20 ft. Maximum Gate Weight – 600 lbs.  
Maximum Pull – 125 lbs.

#### CSW200ULDC8™ (Single Motor)

1/2 HP Motor, DC2000™, 120 Vac, 4 Amp.  
Maximum Gate Length – 20 ft. Maximum Gate Weight – 600 lbs.  
Maximum Pull – 125 lbs.

#### CSW200ULH8™ (Single Motor)

1/2 HP Motor, 120 Vac, 4 Amp., Heater 3 Amp  
Maximum Gate Length – 20 ft. Maximum Gate Weight – 600 lbs.  
Maximum Pull – 125 lbs.

#### CSW200ULDC8™ (Single Motor)

1/2 HP Motor, DC2000™, 120 Vac, 4 Amp., Heater 3 Amp  
Maximum Gate Length – 20 ft. Maximum Gate Weight – 600 lbs.  
Maximum Pull – 125 lbs.

#### CSW200ULST8™ (Stainless Steel Cover)

1/2 HP Motor, 120 Vac, 4 Amp.  
Maximum Gate Length – 20 ft. Maximum Gate Weight – 600 lbs.  
Maximum Pull – 125 lbs.

#### CSW200ULSTDC8™ (Stainless Steel Cover)


1/2 HP Motor, DC2000™, 120 Vac, 4 Amp.  
Maximum Gate Length – 20 ft. Maximum Gate Weight – 600 lbs.  
Maximum Pull – 125 lbs.

#### CSW200ULSTH8™ (Stainless Steel Cover)

1/2 HP Motor, 120 Vac, 4 Amp., Heater 3 Amp  
Maximum Gate Length – 20 ft. Maximum Gate Weight – 600 lbs.  
Maximum Pull – 125 lbs.

#### CSW200ULSTDC8™ (Stainless Steel Cover)

1/2 HP Motor, DC2000™, 120 Vac, 4 Amp., Heater 3 Amp  
Maximum Gate Length – 20 ft. Maximum Gate Weight – 600 lbs.  
Maximum Pull – 125 lbs.



All operators come with 2 warning placards and a warranty card.



### Dual Motor and 1 HP Models

#### CSW200ULDM8™ (Dual Motor)

Two -1/2 HP Motors, 120 Vac, 4 Amp.  
Maximum Gate Length – 20 ft. Maximum Gate Weight – 800 lbs.  
Maximum Pull – 115 lbs.

#### CSW200ULDMD8™ (Dual Motor)

Two -1/2 HP Motors, DC2000™, 120 Vac, 4 Amp.  
Maximum Gate Length – 20 ft. Maximum Gate Weight – 800 lbs.  
Maximum Pull – 115 lbs.

#### CSW200ULDMH8™ (Dual Motor)

Two -1/2 HP Motors, 120 Vac, 4 Amp., Heater 3 Amp  
Maximum Gate Length – 20 ft. Maximum Gate Weight – 800 lbs.  
Maximum Pull – 115 lbs.

#### CSW200ULDMDCH8™ (Dual Motor)


Two -1/2 HP Motors, DC2000™, 120 Vac, 4 Amp., Heater 3 Amp  
Maximum Gate Length – 20 ft. Maximum Gate Weight – 800 lbs.  
Maximum Pull – 115 lbs.

#### CSW200UL1HP8™ (1 Horse Power)

Two -1/2 HP Motors, 120 Vac, 7.9 Amp.  
Maximum Gate Length – 22 ft. Maximum Gate Weight – 1000 lbs.  
Maximum Pull – 250 lbs.

#### CSW200UL1HPH8™ (1 Horse Power)

Two -1/2 HP Motors, 120 Vac, 7.9 Amp., Heater 3 Amp  
Maximum Gate Length – 22 ft. Maximum Gate Weight – 1000 lbs.  
Maximum Pull – 250 lbs.



**NOTE:** The 1 HP models **Can Not** have the DC2000™ Battery Backup system.



# SPECIFICATIONS AND WARNINGS

## UL325 MODEL CLASSIFICATIONS

The CSW200UL8™ is intended for use in vehicular swing gate applications:


### ***Class I – Residential vehicular gate operator***

A vehicular gate operator (or system) intended for use in a home of one-to four single family dwellings, or a garage or parking area associated therewith.




### ***Class II – Commercial/General access vehicular gate operator***

A vehicular gate operator (or system) intended for use in a commercial location or building such as a multi-family housing unit (five or more single family units) hotel, garage, retail store or other building servicing the general public.




### ***Class III – Industrial/Limited access vehicular gate operator***

A vehicular gate operator (or system) intended for use in a industrial location or building such as a factory or loading dock area or other location not intended to service the general public.



### ***Class IV– Restricted access vehicular gate operator***

A vehicular gate operator (or system) intended for use in a guarded industrial location or building such as an airport security area or other restricted access locations not servicing the general public, in which unauthorized access is prevented via supervision by security personnel.



## **UL325 ENTRAPMENT PROTECTION REQUIREMENTS**


This chart illustrates the entrapment protection requirements for each of the four UL325 classes.

In order to complete a proper installation you must satisfy the entrapment protection chart shown. That means that the installation must have one *primary* means of entrapment protection and one independent *secondary* means of entrapment protection. Both primary and secondary entrapment protection methods must be designed, arranged or configured to protect against entrapments in both the open and close directions of gate travel.

**For Example:** For a gate system that is installed on a single-family residence (UL325 Class I) you must provide the following:

- **Type A** - Inherent (built into the operator) entrapment sensing and at least one of the following as your *secondary entrapment protection*:
- **Type B1** - Non-contact sensors such as photoelectric sensors or,
- **Type B2** - Contact sensors such as edge sensors

GATE OPERATOR ENTRAPMENT PROTECTION		
UL325 Installation Classification	Swing & Gate Barrier (Arm) Operator	
	Primary Type	Secondary Type
<b><i>Class I - Class IV</i></b>	A	B1 or B2



**NOTE:** UL requires that all installations must have warning placards placed in plain view on both sides of the gate to warn pedestrians of the dangers of motorized gate systems.

# SPECIFICATIONS AND WARNINGS

## SAFETY INSTALLATION INFORMATION

1. Vehicular gate systems provide convenience and security. Gate systems are comprised of many component parts. The gate operator is only one component. Each gate system is specifically designed for an individual application.
2. Gate operating system designers, installers and users must take into account the possible hazards associated with each individual application. Improperly designed, installed or maintained systems can create risks for the user as well as the bystander. Gate systems design and installation must reduce public exposure to potential hazards.
3. A gate operator can create high levels of force in its function as a component part of a gate system. Therefore, safety features must be incorporated into every design. Specific safety features include:
  - Gate Edges
  - Guards for Exposed Rollers
  - Photoelectric Sensors
  - Screen Mesh
  - Vertical Posts
  - Instructional and Precautionary Signage
4. Install the gate operator only when:
  - a. The operator is appropriate for the construction and the usage class of the gate.
  - b. All openings of a horizontal swing gate are guarded or screened from the bottom of the gate to a minimum of 4 feet (1.2 m) above the ground to prevent a 2-1/4 inches (6 cm) diameter sphere from passing through the openings anywhere in the gate, and in that portion of the adjacent fence that the gate covers in the open position.
  - c. All exposed pinch points are eliminated or guarded, and guarding is supplied for exposed rollers.
5. The operator is intended for installation only on gates used for vehicles. Pedestrians must be supplied with a separate access opening. The pedestrian access opening shall be designed to promote pedestrian usage. Locate the gate such that persons will not come in contact with the vehicular gate during the entire path of travel of the vehicular gate.
6. The gate must be installed in a location so that enough clearance is supplied between the gate and adjacent structures when opening and closing to reduce the risk of entrapment. Swinging gates shall not open into public access areas.
7. The gate must be properly installed and work freely in both directions prior to the installation of the gate operator.
8. Controls intended for user activation must be located at least six feet (6') away from any moving part of the gate and where the user is prevented from reaching over, under, around or through the gate to operate the controls. Outdoor or easily accessible controls shall have a security feature to prevent unauthorized use.
9. The Stop and/or Reset (if provided separately) must be located in the line-of-sight of the gate. Activation of the reset control shall not cause the operator to start.
10. A minimum of two (2) WARNING PLACARDS shall be installed, one on each side of the gate where easily visible.
11. For a gate operator utilizing a non-contact sensor:
  - a. Reference owner's manual regarding placement of non-contact sensor for each type of application.
  - b. Care shall be exercised to reduce the risk of nuisance tripping, such as when a vehicle trips the sensor while the gate is still moving.
  - c. One or more non-contact sensors shall be located where the risk of entrapment or obstruction exists, such as the perimeter reachable by a moving gate or barrier.
12. For a gate operator utilizing a contact sensor such as an edge sensor:
  - a. One or more contact sensors shall be located where the risk of entrapment or obstruction exists, such as at the leading edge, trailing edge and post mounted both inside and outside of a vehicular horizontal slide gate.
  - b. One or more contact sensors shall be located at the bottom edge of a vehicular vertical lift gate.
  - c. A hard wired contact sensor shall be located and its wiring arranged so the communication between the sensor and the gate operator is not subject to mechanical damage.
  - d. A wireless contact sensor such as the one that transmits radio frequency (RF) signals to the gate operator for entrapment protection functions shall be located where the transmission of the signals are not obstructed or impeded by building structures, natural landscaping or similar obstruction. A wireless contact sensor shall function under the intended end-use conditions.
  - e. One or more contact sensors shall be located on the inside and outside leading edge of a swing gate. Additionally, if the bottom edge of a swing gate is greater than 6 inches (152 mm) above the ground at any point in its arc of travel, one or more contact sensors shall be located on the bottom edge.
  - f. One or more contact sensors shall be located at the bottom edge of a vertical barrier (arm).


# SPECIFICATIONS AND WARNINGS

## GATE CONSTRUCTION INFORMATION

Vehicular gates should be installed in accordance with ASTM F2200: Standard Specification for Automated Vehicular Gate Construction. For a copy, contact ASTM directly at 610-832-9585 or [www.astm.org](http://www.astm.org).

### 1. General Requirements

- 1.1 Gates shall be constructed in accordance with the provisions given for the appropriate gate type listed, refer to ASTM F2200 for additional gate types.
- 1.2 Gates shall be designed, constructed and installed to not fall over more than 45 degrees from the vertical plane, when a gate is detached from the supporting hardware.
- 1.3 Gates shall have smooth bottom edges, with vertical bottom edged protrusions not exceeding 0.50 inches (12.7 mm) when other than the exceptions listed in ASTM F2200.
- 1.4 The minimum height for barbed tape shall not be less than 8 feet (2.44 m) above grade and for barbed wire shall not be less than 6 feet (1.83 m) above grade.
- 1.5 An existing gate latch shall be disabled when a manually operated gate is retrofitted with a powered gate operator.
- 1.6 A gate latch shall not be installed on an automatically operated gate.
- 1.7 Protrusions shall not be permitted on any gate, refer to ASTM F2200 for exceptions.
- 1.8 Gates shall be designed, constructed and installed such that their movement shall not be initiated by gravity when an automatic operator is disconnected.
- 1.9 A pedestrian gate shall not be incorporated into a vehicular gate panel or that portion of the adjacent fence that the gate covers in the open position.
- 3.1.4 Positive stops shall be required to limit travel to the designed fully open and fully closed positions. These stops shall be installed at either the top of the gate, or at the bottom of the gate where such stops shall horizontally or vertically project no more than is required to perform their intended function.
- 3.1.5 All gates shall be designed with sufficient lateral stability to assure that the gate will enter a receiver guide, refer to ASTM F2200 for panel types.
- 3.2 The following provisions shall apply to Class IV vehicular horizontal slide gates:
  - 3.2.1 All weight bearing exposed rollers 8 feet (2.44 m), or less, above grade shall be guarded or covered.
  - 3.2.2 Positive stops shall be required to limit travel to the designed fully open and fully closed positions. These stops shall be installed at either the top of the gate, or at the bottom of the gate where such stops shall horizontally or vertically project no more than is required to perform their intended function.



### 2. Specific Applications

- 2.1 Any non-automated gate that is to be automated shall be upgraded to conform to the provisions of this specification.
- 2.2 This specification shall not apply to gates generally used for pedestrian access and to vehicular gates not to be automated.
- 2.3 Any existing automated gate, when the operator requires replacement, shall be upgraded to conform to the provisions of this specification in effect at that time.

### 3. Vehicular Horizontal Slide Gates

- 3.1 The following provisions shall apply to Class I, Class II and Class III vehicular horizontal slide gates:
  - 3.1.1 All weight bearing exposed rollers 8 feet (2.44 m), or less, above grade shall be guarded or covered.
  - 3.1.2 All openings located between 48 inches (1.22 m) and 72 inches (1.83 m) above grade shall be designed, guarded or screened to prevent a 4 inch (102 mm) diameter sphere from passing through the openings anywhere in the gate, and in that portion of the adjacent fence that covers in the open position.
  - 3.1.3 A gap, measured in the horizontal plane parallel to the roadway, between a fixed stationary object nearest the roadway, (such as a gate support post) and the gate frame when the gate is in either the fully open position or the fully closed position, shall not exceed 2-1/4 inches (57 mm), refer to ASTM F2200 for exception.

### 4. Vehicular Horizontal Swing Gates

- 4.1 The following provisions shall apply to Class I, Class II and Class III vehicular horizontal swing gates:
  - 4.1.1 Gates shall be designed, constructed and installed so as not to create an entrapment area between the gate and the supporting structure or other fixed object when the gate moves toward the fully open position, subject to the provisions in the 4.1.1.1 and 4.1.1.2.
    - 4.1.1.1 The width of an object (such as a wall, pillar or column) covered by a swing gate when in the open position shall not exceed 4 inches (102 mm), measured from the center line of the pivot point of the gate, refer to ASTM F2200 for exception.
    - 4.1.1.2 Except for the zone specified in Section 4.1.1.1, the distance between a fixed object such as a wall, pillar or column, and a swing gate when in the open position shall not be less than 16 inches (406 mm), refer to ASTM F2200 for exception.
  - 4.2 Class IV vehicular horizontal swing gates shall be designed, constructed and installed in accordance with security related parameters specific to the application in question.

# SPECIFICATIONS AND WARNINGS

## REQUIRED ENTRAPMENT PROTECTION DEVICE LOCATIONS

### ⚠ WARNING

To prevent SERIOUS INJURY or DEATH from a moving gate:

- Entrapment protection devices **MUST** be installed to protect anyone who may come near a moving gate.
- Locate entrapment protection devices to protect in **BOTH** the open and close gate cycles.
- Locate entrapment protection devices to protect between moving gate and **RIGID** objects, such as posts or walls.
- A swinging gate shall **NOT** open into public access ways.


### Non-Contact Sensors (Photoelectric Sensors)

Install **photoelectric sensors** to protect against any entrapment or safety conditions encountered in your gate application.

**Safety loops** allow the gate to stay open when vehicles are obstructing the gate path. Suggested for vehicles 14 feet or longer. If a vehicle is shorter, a center loop is recommended and should be installed.

A **center loop** protects during a **Close** cycle of the gate. Safety loops are required when using a center loop.

See Loop Wiring.



# SPECIFICATIONS AND WARNINGS

## REQUIRED ENTRAPMENT PROTECTION DEVICE LOCATIONS

### ⚠ WARNING

To prevent SERIOUS INJURY or DEATH from a moving gate:

- Entrapment protection devices **MUST** be installed to protect anyone who may come near a moving gate.
- Locate entrapment protection devices to protect in **BOTH** the open and close gate cycles.
- Locate entrapment protection devices to protect between moving gate and **RIGID** objects, such as posts or walls.
- A swinging gate shall **NOT** open into public access ways.

### Contact Sensors (Edge Sensors)


Install **edge sensors** to protect against any entrapment or safety conditions encountered in your gate application.

See Entrapment Protection Devices.

**Safety loops** allows the gate to stay open when vehicles are obstructing the gate path. Suggested for vehicles 14 feet or longer. If a vehicle is shorter, a center loop is recommended and should be installed.

A **center loop** protects during the **Close** cycle of a gate. Safety loops are required when using a center loop.

See Loop Wiring.



# SPECIFICATIONS AND WARNINGS


## SAFETY INSTALLATION INFORMATION

**THE CSW200UL8™ IS FOR USE ON VEHICULAR PASSAGE GATES ONLY AND NOT INTENDED FOR USE ON PEDESTRIAN PASSAGE GATES.**


Property owners **MUST** never mount any gate operating device near the gate's path!



Property owners **MUST** never allow anyone to hang or ride on the gate!



Property owners **MUST** never let pedestrians cross the path of a moving gate!



### ⚠ WARNING


To prevent SERIOUS INJURY or DEATH from a moving gate:

- Entrapment protection devices **MUST** be installed to protect anyone who may come near a moving gate.
- Locate entrapment protection devices to protect in **BOTH** the open and close gate cycles.
- Locate entrapment protection devices to protect between moving gate and **RIGID** objects, such as posts.
- A swinging gate shall **NOT** open into public access ways.

## WARNING PLACARD PLACEMENT

### ⚠ WARNING

To prevent SERIOUS INJURY or DEATH from a moving gate:  
Install warning placards on **BOTH** sides of **EACH** gate in **PLAIN** VIEW.



# INSTALLATION


## INSTALLATION SETUPS

**NOTE:** Weld a horizontal bar across entire gate on any installation for strength.

### Single Operator

Maximum gate length 20 ft. (22 ft. for 1HP)


Maximum gate weight is 600 lbs. (800 lbs. for DM) (1000 lbs. 1HP)



### Primary/Secondary Operators


Maximum gate length 20 ft. (22 ft. for 1HP)

Maximum gate weight is 600 lbs. (800 lbs. for DM) (1000 lbs. 1HP)




# INSTALLATION

## CONCRETE PAD AND ARM ATTACHMENT



Above Ground


Below the Frost Line Check all Local Codes



### CAUTION

To AVOID damaging operator, DO NOT weld ANY supports to chassis. Chassis MUST be allowed to flex during operation.


### Top View of Chassis



Approximate placement of high voltage and/or low voltage conduits.

### Sample of Standard Arm Attachment (See next page for layout)

Drawing not to scale






# INSTALLATION

## STANDARD INSTALLATION LAYOUT


Sample of standard arm attachment is shown on previous page.



**Mount bracket at least a quarter of the gate length from the gate hinge.**

**NOTE:** Longer gates or retro-fits may require both arms to be lengthened by equal parts.

Drawing not to scale



For technical support: 1-800-528-2806


# INSTALLATION

## COMPACT INSTALLATION LAYOUT


### Compact Installation **ONLY!**

**DO NOT** use these measurements for a standard installation.

(For standard installation, see previous page.)




It is necessary to protect against the entrapment that could occur with this type of installation.  
(See entrapment protection devices.)





Gate Open

Outside Property  
Inside Property




Gate Closed



Follow the exact measurements, then cut the standard arm to meet the shorter measurements.


# INSTALLATION

## UPHILL DRIVEWAY INSTALLATION (OPTIONAL)




**Not Possible**

Gate hits driveway.




**Possible**

Special swivel arm and hinges are required.




**Swivel Arm**

## POST MOUNTING PLATE INSTALLATION (OPTIONAL)



3" heavy steel posts can be U-bolted to mounting plate and cemented in ground.




Power and control wiring can be run in separate conduits.

# INSTALLATION


## GATE ARM INSTALLATION

### Incorrect Installation!



Gate Open



Gate Closed




### Correct Installation




Once the gate arm measurements are calculated:


1. Weld the bracket on the gate.



2. Weld the longer arm.....




3. ....then weld the shorter arm.




Completely weld around the rectangular tubes and bracket!

## OUTPUT SHAFT ADJUSTMENT


1. Fit pin in slot.



2. Tighten the nut.




3. Tighten the handle.




4. Pull the short arm away from the gate.

**NO** slippage should occur.

If it does, go back and tighten the nut.




5. Replace cover and star knob.



# INSTALLATION

## CONTROL BOARD DESCRIPTION



1. **1HP Connection** - Factory installed CSW200UL1HP8™ Models.
2. **J3 Motor, Limit Switch, Maglock/Solenoid Connection**
3. **DC2000™ Back-Up Power or Reset Switch Connection**
4. **Circuit Board Power LED** - Operator power OK when ON.
5. **Overload LED** - Operator power has overloaded when ON.
6. **On-Board 3 Button Station** - Close, Stop, Open commands.
7. **Timer** - Timed close.
8. **Gate Opening Direction Selector** - Open Left, Open Right.
9. **Gate Locked LED** - Maglock/Solenoid is activated when on.
10. **Reset Motor LED** - Cycle operator power when ON.
11. **Radio Receiver LED** - Radio transmitter is activated when ON.
12. **Center Loop LED** - Center loop detector activated when ON.
13. **Strike Open LED** - Strike connected device activated when ON.
14. **Safety Loop LED** - Safety loop detector activated when ON.
15. **Fire Dept LED** - Key Switch activated when ON.
16. **Exit Loop LED** - Exit loop detector activated when ON.
17. **Command Processed LED** - Successful command executed.
18. **Alarm Sensor** - Limited Adjustment.
19. **Reverse Sensor** - Gate hit obstruction when ON.
20. **System On LED** - Operator is successfully performing a command.
21. **J1 Surge Suppressor Data Connection**
22. **M/S Link LED** - Data being transferred between primary and secondary operators when ON.

**120 Vac Power**

**Output Power**

⑪ - Ground

⑬ + 24 Vdc

**LiftMaster OmniControl Surge Suppressor**

**Class 2 Supply**

**Removable Terminals**

**CAUTION**

To ENSURE proper operation of external devices:

- ENSURE bare wires make good contact inside removable terminal connections.
- DO NOT let wire insulation interfere with connection.

**Remote NOT Included**

**315 MHz Factory Installed Radio Receiver**

**Card Reader**

Separate power for card reader.

**Push Button**

Dry Contact

**Telephone Entry System**

Separate power for TES.

**Fire or any Key Switch**

Dry Contact

**12 Vdc Failsafe Photoelectric Sensor**

**External 120 Vac "Safety" Loop Detector**

Separate Power

**External 120 Vac "Exit" Loop Detector**

Separate Power

**Second Operator Link**

**OR**

**CHASSIS GROUND**

**NOTE:** Terminals 11 and 12 are the **ONLY** terminals that will **Open** and **Close** with a single push of a button. All other terminals will **ONLY** Open with a single push of a button.

16

16

# WIRING

## ⚡ WARNING

To reduce the risk of SEVERE INJURY or DEATH:

- ANY maintenance to the operator or in the area near the operator **MUST** not be performed until disconnecting the electrical power and locking-out the power. Upon completion of maintenance the area **MUST** be cleared and secured, at that time the unit may be returned to service.
- Disconnect power at the fuse box **BEFORE** proceeding. Operator **MUST** be properly grounded and connected in accordance with local electrical codes. **NOTE: The operator should be on a separate fused line of adequate capacity.**
- ALL electrical connections **MUST** be made by a qualified individual.
- **DO NOT** install ANY wiring or attempt to run the operator without consulting the wiring diagram. We recommend that you Install an optional reversing edge **BEFORE** proceeding with the control station installation.
- ALL power wiring should be on a dedicated circuit and well protected. The location of the power disconnect should be visible and clearly labeled.
- ALL power and control wiring **MUST** be run in separate conduit.
- **BEFORE** installing power wiring or control stations be sure to follow ALL specifications and warnings described below. Failure to do so may result in SEVERE INJURY to persons and/or damage to operator.
- **DO NOT** disconnect the built-in audio alarm or reset switch.

120 Vac Power Wire	16 Gauge	14 Gauge	12 Gauge	10 Gauge	8 Gauge	4 Gauge
1/2 HP and Dual Motor	up to 150 FT	250 FT	400 FT	650 FT	1000 FT	2200 FT
1 HP	up to 75 FT	125 FT	200 FT	325 FT	500 FT	1100 FT

All power wiring should be on a dedicated circuit and well protected.

**NOTE:** Calculated using NEC guidelines. Local codes and conditions must be reviewed for suitability of wire installation.

## EARTH GROUND ROD INSTALLATION


Proper grounding gives an electrical charge, such as from an electrical static discharge or a near lightning strike, a path from which to dissipate its energy safely into the earth.

Without this path, the intense energy generated by lightning could be directed towards the gate operator. Although nothing can absorb the tremendous power of a direct lightning strike, proper grounding can protect the gate operator in most cases.

The earth ground rod must be located within 3 feet from the gate operator. Use the proper type earth ground rod for your local area. The ground wire must be a single, whole piece of wire. Never splice two wires for the ground wire. If you should cut the ground wire too short, break it, or destroy its integrity, replace it with a single wire length.


## CAUTION

To **AVOID** damaging gas, power, or other underground utility lines, contact underground utility locating companies **BEFORE** digging more than 18 inches (46 cm) deep.



# WIRING

## 120 VAC POWER CONNECTION



Use a 20 amp dedicated circuit for each operator.

Input power 120 Vac, 60 Hz.

**Earth Ground Rod Highly Recommended!**  
See previous page.


120 Vac Power Wire	16 Gauge	14 Gauge	12 Gauge	10 Gauge	8 Gauge	4 Gauge
1/2 HP and Dual Motor	up to 150 FT	250 FT	400 FT	650 FT	1000 FT	2200 FT
1 HP	up to 75 FT	125 FT	200 FT	325 FT	500 FT	1100 FT

## HEATER POWER CONNECTION

Connect the black, white and ground wire from the heater to the 120 Vac power supply as shown. When the heater switch is left in the "ON" position, the heater will turn on and off automatically when needed.

### CAUTION

To reduce the risk of **SERIOUS INJURY**:  
DO NOT touch the heater when switch is on, heater may be hot.






# WIRING

## LINKING PRIMARY/SECONDARY OPERATORS

Use a 20 amp dedicated power circuit for each operator.



### Primary Board

Primary/Secondary control boards are interchangeable.

### Secondary Board

Use shielded twisted wires for M/S link.  
Shield wire **MUST** be grounded to primary operator Only.

Surge Suppressor  
Primary/  
Secondary  
Connection

**NOTE:** To adjust  
timers, see page 30.

**NOTE:** Disconnect the second  
radio receiver when using a  
primary/secondary setup.

Shield Wire

**Connect Primary M/S Link G to Second M/S Link G.  
Connect Primary M/S Link B to Second M/S Link B.  
Connect Primary M/S Link A to Second M/S Link A.**

### Partial Primary/Individual Control

In order for the following operation to occur, follow the instructions.


**EXAMPLE:** There is a double gate, the entry gate is to be opened with a remote control and the exit gate with a free exit loop. Only one safety loop system is to open both gates, and a fire department switch should open both gates at the same time.

1. Connect the radio receiver to entry gate only.
2. Connect the exit loop to exit gate only.
3. Connect the safety loop to both entry and exit gates (observe polarity of voltage).
4. Connect the fire department switch to both entry and exit gates (observe polarity of both operators).



# WIRING

## SOLENOID/MAGLOCK RELAY CONNECTION

Connection of a solenoid or magnetic lock can be made using the J7 board connector and “Optional” Relay Adapter Module.



**Relay Contact Rating**  
2 Amp - 125 AC/DC  
2 Amp switching load  
capability



# WIRING

## FACTORY INSTALLED DC2000™ CONNECTION

### DC2000™ Startup

1. Plug in the 12 pin plug into the DC2000™ control unit. Make sure the “**System ON**” and “**Charge OK**” LEDs are lit. If the “**Battery Low**” led comes on, the battery needs to charge before it can be used.
2. Make sure “**Gate Direction**” setting on DC2000™ is set the same as the OmniControl™ board setting. See Adjustments.
3. Adjust “**Reverse Sensor**” setting. See Adjusting Reverse Sensor(s).



Reset button and interlock wires, Do Not Remove.

	120 Vac Power Failure	120 Vac Power On, OmniControl™ Board Malfunction
<b>Manual Mode</b>	Push and <b>Hold</b> to operate gate.	Turn the 120 Vac power off then push and <b>Hold</b> to operate gate.
<b>Auto Mode</b>	Gate automatically opens.	Turn the 120 Vac power off then gate opens automatically.

**NOTE:** All devices wired to the DC2000™ MUST be **dedicated** to it alone. Normal operation will be controlled by separate devices wired to the OmniControl™ board and surge suppressor.

**EXAMPLE:** If the DC2000™ is “automatically opening” the gate due to a power failure (auto mode), any manual command such as “**One-Button**”, “**Three Push Button**”, “**Key Switch**”, “**Photoelectric Sensor**” or “**Edge Sensor**” will cancel the automatic mode of the DC2000™. After such cancellation, the DC2000™ will continue to operate in “manual mode” until 120 Vac power is restored.

# WIRING

## DC2000™ DEVICE WIRING

### Manually Operated DC2000™ Devices

Manual external devices should be dry-contact which do not consume any current like push buttons or a key switch.


**Key switch is for property owner's emergency access ONLY. DO NOT USE FOR AN EMERGENCY FIRE/POLICE KEY ACCESS.**

Contact your local Fire/Police municipalities for more information on correct Fire/Police emergency key access.

#### Manual One-Button


Push and **HOLD** button to *Open*.

Push button **again** and **HOLD** to *Close*.




#### Manual 3-Button

Push and **HOLD** a button to operate.




#### Manual Key Switch



Turn and **HOLD** key to *Open*.  
Turn key **again** and **HOLD** to *Close*.


### DC2000™ Entrapment Protection Devices

It is recommended using separate entrapment protection devices to maintain gate safety when the DC2000™ is needed for any reason. The entrapment protection devices connected to the OmniControl™ board and surge suppressor **WILL NOT** protect the gate when there is a AC power failure and the DC2000™ is used.




# WIRING


## PLUG-IN LOOP DETECTOR WIRING



Plug-In Loop Detectors  
See Accessories.



The wire **MUST** be twisted together **minimum 6 twists per foot** from the end of the loop to the control board.




### CAUTION

To **AVOID** damaging control board, disconnect all power to operator before installing plug-in loop detectors.  
Use a different frequency for every loop detector installed.

**Plug-In "Center" Loop Detector:** Allows gate to stay open when vehicles are obstructing path.  
**CAUTION:** This option is for all vehicles including ones less than 14 feet long. Center loop system requires two safety loops.

Example of a 1 wire loop. (See "Installing Insulated Loop Wire" on next page for more information.)

**NOTE:** Refer to the plug-in loop detector manual for more specific information.



**Plug-In "Safety" Loop Detector:** Allows gate to stay open when vehicles are obstructing path.  
**CAUTION:** Suggested for vehicles 14 feet or longer.

If the **"Inside"** and **"Outside"** safety loops are connected to the same loop detector:

- They should be series connected to the detector.
- Have the same dimensions.
- Have the same number of wire turns.

Example of a inside and outside 2 wire turn loop connected in series. (See "Installing Insulated Loop Wire" on next page for more information.)


**Plug-In "Exit" Loop Detector:** Allows gate to automatically open for exiting vehicles.

Example of a 3 wire loop. (See "Installing Insulated Loop Wire" on next page for more information.)

**Contact your local dealer for information about plug-in loop detectors.**

# WIRING

## 120 VAC EXTERNAL LOOP DETECTOR WIRING



**120 Vac “Center” Loop Detector:** Allows gate to stay open when vehicles are obstructing path. **CAUTION:** This option is for all vehicles including ones less than 14 feet long. Center loop system requires two safety loops.

**120 Vac “Safety” Loop Detector:** Allows gate to stay open when vehicles are obstructing path. **CAUTION:** Suggested for vehicles 14 feet or longer. If a vehicle is shorter, a center loop system is recommended and should be installed.

If the “Inside” and “outside” safety loops are connected to the same loop detector:

- They should be series connected to the detector.
- Have the same dimensions.
- Have the same number of wire turns. (See table below.)

**120 Vac “Exit” Loop Detector:** Allows gate to automatically open for exiting vehicles.

### Installing Insulated Loop Wire

#### Number of Wire Turns Needed for Loop Sizes

Loop Perimeter	Number of Wire Turns
10 feet to 13 feet	4
14 feet to 26 feet	3
27 feet to 80 feet	2
80 feet and up	1



The wire **MUST** be twisted together 6 twists per foot from the end of the feeder slot to the loop detector.

Home Run


1/8" to 1/4" Width Saw Cut

Road Surface


Sealant

Backer Rod

Insulated loop wire  
3 turns shown, amount varies.  
Refer to table.



2" to 2.5" Depth  
Saw Cut



See Accessories



Center Loop




Safety Loop



Exit Loop

**NOTE:** Use separate 120 Vac power for each loop detector.



The wire is continuously wound in the loop saw cut for the required number of turns. One turn shown (refer to table).

Saw Cut

Remove sharp inside corners by making corner cuts.

Feeder Slot

**Contact your local dealer for more information about loop detectors.**

**Recommended Loop Wire XLPE 12-18 gauge**  
(Use heavier wire gauge for a more durable loop.)

**NOTE:** Wire mesh or reinforcement imbedded in the road surface should be cut away a minimum of 6 inches from the perimeter of the loop.



# WIRING

## ENTRAPMENT PROTECTION DEVICES


### Contact Sensors (Edge Sensor)

**NOTE:** When touched, these electrically activated edge sensors immediately signal the gate operator to stop and reverse. Property owners are obligated to test edges monthly.

#### 3 Edge Contact Sensor





#### Open and Close Contact Sensors





Connect both edge sensors parallel to sensor connector.

UL Listed 3 sided Edge Sensor  
(See Accessories for part number.)



UL Listed Edge Sensors  
(See Accessories for part number.)



Contact your local dealer for more information about edge sensors.

# WIRING

## ENTRAPMENT PROTECTION DEVICES

### Non-Contact Sensors (12 Vdc Photoelectric Sensors)


**NOTE:** Property owners are obligated to test photoelectric sensors monthly.

See Accessories for part number.


### ⚠ WARNING

To prevent SERIOUS INJURY or DEATH from a moving gate:

- Locate entrapment protection devices to protect in BOTH the open and close gate cycles.
- Locate entrapment protection devices to protect between moving gate and RIGID objects, such as posts or walls.



**NOTE:** If the photoelectric sensor gets blocked while the gate is closing, it will stop and reopen. The gate will remain open until the obstruction is cleared.



**It is best to use Failsafe Photoelectric Sensors for this safety option.**


**Failsafe Photoelectric Sensors:** If a failsafe photoelectric sensor is not working or loses power or photoelectric sensor is blocked, then the photoelectric sensors will stop ALL gate operation.

Contact your local dealer for more information about photoelectric sensors.




# ADJUSTMENTS

## SET GATE OPENING DIRECTION



### **WARNING**


To reduce the risk of **SERIOUS INJURY** or **DEATH**:  
Disconnect power **BEFORE** performing **ANY** adjustments.




# ADJUSTMENTS

## LIMIT SWITCH ADJUSTMENT

Release the red handle and move the gate to the open position. Loosen the screw on one of the limit cams and turn the cam until the half moon shape hits the limit switch and you hear the switch click. Tighten cam. Move gate to the closed position and do the same with the other limit cam. For a more precise adjustment, use the allen screw.



Loosen screws to turn limit cams.






Precise adjustment.

## CLUTCH ADJUSTMENT

The adjustment is for a gate that is over 300 pounds and 12 feet long or longer. While the gate is closing, instantly an “open” command is given as shown below; the clutch may slip a bit, max. of 1/4 to 3/4 of a turn (slippage depends on the weight of the gate). If it does not slip, then readjust the clutch.

**NOTE:** Clutch is NOT used as an entrapment protection device.



Typical clutch slippage (1/4 turn)

(Starting Position)  
(Finishing Position)

# ADJUSTMENTS

## RADIO RECEIVER PROGRAMMING

The receiver can be used as a single, two, or three channel receiver and is compatible with Security+ 2.0™ remote controls ONLY. Each channel is compatible with a certain number of remote controls and keypads. Refer to the list below:

- CH1: 50 remote controls and 2 keypads
- CH2: 20 remote controls and 2 keypads
- CH3: 20 remote controls and 2 keypads

When the channel has reached full capacity for remote controls, all LEDs will blink 3 times. When the channel has reached full capacity for keypads, all LEDs will blink 4 times. Additional accessories can be programmed, however, the newly programmed accessory will replace the first programmed accessory.

**NOTE:** The receiver will only allow you to program a button on the remote control to one channel at a time. For example, if the button on the remote control is already programmed to channel 1 and then is programmed to channel 3, the button will be erased from channel 1 and will only work on channel 3.

**IMPORTANT:** Remote control is **NOT** provided.

### Program a Single Button Remote Control

- 1 Press and release the Learn button for the selected channel on the receiver. The corresponding LED will glow steadily for 30 seconds.
- 2 Within 30 seconds press and hold the button on the remote control that you wish to program to the receiver.
- 3 Release the remote control button when the LED on the receiver blinks, then turns off. Programming is complete.

Repeat the steps above for each remote control you would like to program.

### Program a 3-Button Remote Control as OPEN, CLOSE, and STOP

- 1 Press and release the CH1 Learn button on the receiver.
- 2 Within 30 seconds press the desired OPEN button on the remote control.
- 3 Press and release the CH2 Learn button on the receiver.
- 4 Within 30 seconds press the desired CLOSE button on the remote control.
- 5 Press and release the CH3 Learn button on the receiver.
- 6 Within 30 seconds press the desired STOP button on the remote control.

**NOTE:** If a remote control button is not pressed within 30 seconds, the LED next to the selected Learn button will turn OFF. In that case, repeat the programming.

### To Erase the Memory

- 1 Press and hold the Learn button for the channel you want to erase. Release the button when the corresponding LED turns off; the memory has been erased.

### Optional Remote Controls - See Accessories

## **WARNING**

To prevent possible SERIOUS INJURY or DEATH from electrocution:

- Be sure power is NOT connected BEFORE installing the receiver.


To prevent possible SERIOUS INJURY or DEATH from a moving gate or garage door:

- ALWAYS keep remote controls out of reach of children. NEVER permit children to operate, or play with remote control transmitters.
- Activate gate or door ONLY when it can be seen clearly, is properly adjusted, and there are no obstructions to door travel.
- ALWAYS keep gate or garage door in sight until completely closed. NEVER permit anyone to cross path of moving gate or door.

**NOTICE:** This device complies with Part 15 of the FCC rules and Industry Canada (IC) license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This Class B digital apparatus complies with Canadian ICES-003.



**NOTE:** Disconnect the secondary receiver when using a primary/secondary setup.



# ADJUSTMENTS

## SETTING THE TIMER

### Single Operator


To use the automatic close for the gate system the timer switch should be put in the **"ON"** position.

To use the push close command, the timer should be switched to the **"OFF"** position. Push button once to open gate, push button again to close gate.




### Primary/Secondary Operators

Operators need to be connected by **M/S LINK**. See Linking Primary/Secondary page 19.



Primary Board


Secondary Board



#### With Timers ON


1. Turn Primary timer ON.
2. Turn Secondary timer OFF.
3. Use Timer on Primary Board Only. (3 to 60 seconds)

**NOTE:** If a secondary photoelectric sensor device is NOT used when the timer is **ON**, the gate WILL hit a vehicle obstructing the gate path before reversing during the close cycle.



Primary Board


Secondary Board



#### With Timers OFF

1. Turn BOTH timers OFF.

**NOTE:** Push button once to open gate, push button again to close gate.




## ***ADJUSTING REVERSING SENSOR(S)***

Adjust the **“Reverse Sensor”** on the OmniControl™ board. **Alarm Sensor** does not need to be adjusted except where noted below.

**The level of reverse sensitivity depends on the weight of the gate and the condition of installation.**


**Sensor is too sensitive** = If the gate stops in mid cycle or reverses by itself.

**Sensor is not sensitive enough** = If the gate hits an object and does not stop or reverse.



## DC2000™ Reverse Sensor


The DC2000™ has a separate reverse sensor that will need to be adjusted. The 120 Vac operator power needs to be turned off and the DC2000™ should have the **“Charge OK”** LED **ON** to make the adjustment.



# ADJUSTMENTS

## OMNICONTROL™ BOARD CONNECTIONS



**NOTE:** Refer to the OmniControl™ board manual for more specific information.



3-Button Station Dry Contact


Stop Button Dry Contact

**NOTE:** Cut jumper W4 wire for 3 button station or stop button.




Purchased separately from LiftMaster®. See Accessories.


Second Operator




Proximity Switch



12 Vdc House Alarm




Maglock



Relay Contact Rating  
0.5 Amp - 125 Vac  
1 Amp - 24 Vdc

Solenoid Lock



### ***IMPORTANT SAFETY INSTRUCTIONS***

#### **WARNING**

#### **To reduce the risk of SEVERE INJURY or DEATH:**

1. READ AND FOLLOW ALL INSTRUCTIONS.
2. NEVER let children operate or play with gate controls. Keep the remote control away from children.
3. ALWAYS keep people and objects away from the gate. NO ONE SHOULD CROSS THE PATH OF THE MOVING GATE.
4. Test the gate operator monthly. The gate MUST reverse on contact with a rigid object or stop when an object activates the non-contact sensors. After adjusting the force or the limit of travel, retest the gate operator. Failure to adjust and retest the gate operator properly can increase the risk of INJURY or DEATH.
5. Use the emergency release ONLY when the gate is not moving.
6. KEEP GATES PROPERLY MAINTAINED. Read the owner's manual. Have a qualified service person make repairs to gate hardware.
7. The entrance is for vehicles ONLY. Pedestrians MUST use separate entrance.
8. Disconnect ALL power BEFORE performing ANY maintenance.
9. ALL maintenance MUST be performed by a LiftMaster professional.
10. **SAVE THESE INSTRUCTIONS.**

## ***MAINTENANCE***

1. Disconnect power before servicing.
2. The gate area should be kept clean to insure proper operation.
3. Make sure the hinges are working smoothly and lubricated properly.
4. Make sure gate arm is greased properly.
5. Check gate reversing sensor. Check it monthly.
6. Check for proper synthetic oil level in the upper gear box (10W-30 weight synthetic oil).
7. Severe or high cycle usage will require more frequent maintenance checks.
8. Inspection and service should always be performed anytime a malfunction is observed or suspected.
9. When servicing, please do some "house cleaning" of the operator and the area around the operator. Pick up any debris in the area. Clean the operator as needed.
10. It is suggested that while at the site voltage readings be taken at the operator. Using a Digital Voltmeter, verify that the incoming voltage to the operator is within ten percent of the operators rating.

# MAINTENANCE AND OPERATION

## BUILT-IN RESET SWITCH


When the gate operator's audio alarm has been tripped (see below), the reset switch must be pushed for the operator to function again.

The reset switch will shut off an activated audio alarm and reset the operator to function again.

If the audio alarm goes off, always check the gate area for:

- Obstructions in the gate path.
- Damage to the gate and/or gate operator.

Pressing the reset switch will stop a moving gate during a normal open/close cycle, like a stop button. The operator does NOT need to be reset after doing this.




## AUDIO ALARM



The alarm could be tripped when one of the following happens **twice consecutively**, then the alarm will sound for **5 minutes or until the reset switch is pressed!**

Press the built-in reset switch to shut off alarm and reset operator (see above).


The operator arm or gate is incorrectly installed.



Vertical Level



An externally wired photoelectric sensor has been triggered twice (photoelectric sensor blocked).



The gate is TOO heavy.



A foreign object is on the gate frame while the gate is moving.



The gate is moving and a car pushes the gate.



Gate hinges are too tight or broken and the gate is not moving freely.




The gate hits the driveway, curb or other, and gets stuck or bent in an awkward position.



# MAINTENANCE AND OPERATION

## MANUAL DISCONNECT

**NOTE:** Use the dedicated breaker switch to disconnect power to the operator.



### CAUTION


To reduce the risk of **SERIOUS INJURY**:  
**DO NOT** grab the operator arm to move the gate or your fingers could get pinched.

1. Unscrew star knob.


2. Lift off cover.

3. Loosen red handle as shown.

Gate can now be manually moved.




Grab the gate to move it.



Tighten the red handle, replace the cover and knob when finished.  
When the power is on again, the gate will readjust itself automatically.

# WIRING DIAGRAMS

## CSW200UL8™ AND CSW200ULDM8™



**NOTE:** See table on next page.


# WIRING DIAGRAMS

## WIRING TABLE CSW200UL8™ AND CSW200ULDM8™

OmniControl™ Board					
J #	J Pin #	Signal Type	Direction	Level (+/- 10%)	Input Connection
J1	1 2 3 4 5 6 7 8 9 10	Safety Loop Input Power Neutral Center Loop Input Power 120 Vac Strike Open Exit Loop Radio Receiver – Radio Receiver Fire Dept Key Switch Radio Receiver +	In In In In In In In In In Out	5 or 0 Vdc 0V 5 or 0 Vdc 120 Vac 5 or 0 Vdc 5 or 0 Vdc 0V 0V Dry 24 Vdc	External Loop Detector Wires, 120 Vac Power, Radio Receiver, Strike Open, Key Switch Harness
J2	10 Pins	OmniControl™ Option Board	Out	24 Vdc	OmniControl™ Board Input
J3	1 2 3 4 5 6 7 8 9 10	Limit Switch Red N.O. Motor White Normally Closed (No Wire) Motor Black Limit Switch Brown Com Motor Green Purple Com Blue N.O. Limit Switch Yellow Com Limit Switch Orange N.O.	Out Out In Out In Out In In In In	0 Vdc 0V 5 or 0 Vdc 120 Vac 0V 120 Vac 0V 5 or 0 Vdc 0V 5 or 0 Vdc	Motor(s), Limit Switches, Maglock/Solenoid Harness
J5	1 2 3 4 5-7	– Reset Switch Red – Reset Switch Black –	In In In In In	– Dry – Dry –	Reset Switch Input
J6	1 2 3 4	UL Alarm Red UL Alarm Black Photoelectric Sensor Photoelectric Sensor	Out Out In In	24 Vdc 0 Vdc 5 or 0 Vdc 0V	UL Alarm and Photoelectric Sensors
J7	1 2 3	Relay Adapter Red Relay Adapter White Relay Adapter Black	In In In	5 or 0 Vdc 0 Vdc 0 Vdc	Relay Adapter Module Input
J8	1-2 3-4 5-6	Plug-In Exit Loop Wire Plug-In Safety Loop Wire Plug-In Center Loop Wire	In In In	2 to 10 Vdc 2 to 10 Vdc 2 to 10 Vdc	Plug-In Loop Detector Wires
J9	16 Pins	1 HP Board	–	–	Not Used
J10	1 2 3	G M/S Link B M/S Link A M/S Link	In/Out In/Out In/Out	0 Vdc 5 or 0 Vdc 5 or 0 Vdc	Primary/Secondary Link
J11	10 Pins	Center Loop Detector	In	5 or 0 Vdc	Plug-In Loop Detector Inputs
J12	10 Pins	Safety Loop Detector	In	5 or 0 Vdc	
J13	10 Pins	Exit Loop Detector	In	5 or 0 Vdc	
OmniControl™ Surge Suppressor					
J1	1 2 3	G M/S Link (G) B M/S Link (B) A M/S Link (A)	In/Out In/Out In/Out	0V 5 or 0 Vdc 5 or 0 Vdc	Primary/Secondary Link Input
J2	1 2 3 4 5 6 7	Fire Dept. Key Switch (7) Fire Dept. Key Switch (8) Strike Open Push Button (9) Strike Open Push Button (10) Radio Receiver – (11) Radio Receiver (12) Radio Receiver + (13)	In In In In In In Out	Dry Dry 5 or 0 Vdc 0V 0V 5 or 0 Vdc 24 Vdc	Radio Receiver, Strike Open Push Button, Fire Dept Key Switch Inputs
J3	1-2 3-4 5-6	Center External Loop Detector Safety External Loop Detector Exit External Loop Detector	In In In	2 to 10 Vdc 2 to 10 Vdc 2 to 10 Vdc	External Loop Detector Center, Safety, Exit Wires Input

# WIRING DIAGRAMS

## CSW200UL1HP8™




# WIRING DIAGRAMS

## WIRING TABLE CSW200UL1HP8™

OmniControl™ Board					
J #	J Pin #	Signal Type	Direction	Level (+/- 10%)	Input Connection
J1	1 2 3 4 5 6 7 8 9 10	Safety Loop Input Power Neutral Center Loop Input Power 120 Vac Strike Open Exit Loop Radio Receiver – Radio Receiver Fire Dept Key Switch Radio Receiver +	In In In In In In In In In Out	5 or 0 Vdc 0V 5 or 0 Vdc 120 Vac 5 or 0 Vdc 5 or 0 Vdc 0V 0V Dry 24 Vdc	External Loop Detector Wires, 120 Vac Power, Radio Receiver, Strike Open, Key Switch Harness
J2	10 Pins	OmniControl™ Board	Out	24 Vdc	OmniControl™ Board Input
J3	1 2 3 4 5 6 7 8 9 10	Limit Switch Red N.O. Motor White Normally Closed (No Wire) Motor Black Limit Switch Brown Com Motor Green Purple Com Blue N.O. Limit Switch Yellow Com Limit Switch Orange N.O.	Out Out In Out In Out In In In In	0V 0V 5 or 0 Vdc 120 Vac 0V 120 Vac 0V 5 or 0 Vdc 0V 5 or 0 Vdc	Limit Switches, Maglock/Solenoid Harness
J5	1 2 3 4 5-7	– Reset Switch Red – Reset Switch Black –	In In In In In	– Dry – Dry –	Reset Switch Input
J6	1 2 3 4	UL Alarm Red UL Alarm Black Photoelectric Sensor Photoelectric Sensor	Out Out In In	24 Vdc 0 Vdc 5 or 0 Vdc 0V	UL Alarm and Photoelectric Sensors
J7	1 2 3	Relay Adapter Red Relay Adapter White Relay Adapter Black	In In In	5 or 0 Vdc 0 Vdc 0 Vdc	Relay Adapter Module Input
J8	1-2 3-4 5-6	Plug-In Exit Loop Wire Plug-In Safety Loop Wire Plug-In Center Loop Wire	In In In	2 to 10 Vdc 2 to 10 Vdc 2 to 10 Vdc	Plug-In Loop Detector Wires
J9	16 Pins	1 HP Board	Out	5 or 0 Vdc	1HP Motors Board
J10	1 2 3	G M/S Link B M/S Link A M/S Link	In/Out In/Out In/Out	0 Vdc 5 or 0 Vdc 5 or 0 Vdc	Primary/Secondary Link
J11	10 Pins	Center Loop Detector	In	5 or 0 Vdc	Plug-In Loop Detector Inputs
J12	10 Pins	Safety Loop Detector	In	5 or 0 Vdc	
J13	10 Pins	Exit Loop Detector	In	5 or 0 Vdc	
1 HP Board					
J1	1 2 3 4 5 6	Motor Green – Motor Black Input Power Black Motor White Input Power White	Out – Out In Out In	120 Vac – 120 Vac 120 Vac 0V 0V	2 Motors Output
OmniControl™ Surge Suppressor					
J1	1 2 3	G M/S Link (G) B M/S Link (B) A M/S Link (A)	In/Out In/Out In/Out	0V 5 or 0 Vdc 5 or 0 Vdc	Primary/Secondary Link Input
J2	1 2 3 4 5 6 7	Fire Dept. Key Switch (7) Fire Dept. Key Switch (8) Strike Open Push Button (9) Strike Open Push Button (10) Radio Receiver – (11) Radio Receiver (12) Radio Receiver + (13)	In In In In In In Out	Dry Dry 5 or 0 Vdc 0V 0V 5 or 0 Vdc 24 Vdc	Radio Receiver, Strike Open Push Button, Fire Dept Key Switch Inputs
J3	1-2 3-4 5-6	Center External Loop Detector Safety External Loop Detector Exit External Loop Detector	In In In	2 to 10 Vdc 2 to 10 Vdc 2 to 10 Vdc	External Loop Detector Center, Safety, Exit Wires Input

# WIRING DIAGRAMS

## WIRING DIAGRAM DC2000™ FOR SINGLE AND DM




# WIRING DIAGRAMS

## WIRING TABLE DC2000™


J #	J Pin #	Signal Type	Direction	Level (+/- 10%)	Input Connection
J20	1	Open N.O.	Out	5 or 0 Vdc	• Manual Three Button (Dry)  Reset Switch
	2	Closed N.O.	Out	5 or 0 Vdc	
	3	Stop N.O. Reset Switch	Out	5 or 0 Vdc	
	4	Common Radio – Radio Relay Reset Switch	Out	0V	• Manual One Button (Dry) • Key Switch (Dry) • Reset Switch
	5	One Button Key Switch Radio Relay	Out	0V	• Manual One Button (Dry) • Key Switch (Dry)
	6	Radio +12 Vdc Photoelectric Sensor + 12 Vdc	Out	12 or 0 Vdc	• Photoelectric Sensor 12 Vdc
	7	–	–	–	–

**NOTE:** All devices wired to the DC2000™ MUST be **dedicated** to it alone. Normal operation will be controlled by **separate** devices wired to the OmniControl™ board and surge suppressor.



## TROUBLESHOOTING

### THE GATE WILL NOT OPERATE WITH REMOTE



The radio receiver LED on the control board remains “ON” when using the remote control.

1. **Probable Cause:** Stuck remote control button.  
**Solution:** Unstick remote control button.
2. **Probable Cause:** The radio receiver has malfunctioned in the “ON” position.  
**Solution:** Cycle the power to the radio receiver.




The radio receiver LED on the control board remains “OFF” when using the remote control.

1. **Probable Cause:** Remote control battery is dead.  
**Solution:** Replace remote control battery.
2. **Probable Cause:** The radio receiver has malfunctioned in the “OFF” position.  
**Solution:** Cycle the power to the radio receiver. Remote control will need to be reprogrammed, see page 29.
3. **Probable Cause:** Radio receiver’s signal is not getting to gate operator.  
**Solution:** Check wiring between receiver and surge suppressor.
4. **Probable Cause:** Remote is not programmed correctly.  
**Solution:** Reprogram remote control, see page 29.
5. **Probable Cause:** Remote is not on the same frequency as the radio receiver.  
**Solution:** Verify that remote control frequency is 315 MHz.
6. **Probable Cause:** Blown surge suppressor.  
**Solution:** Measure the resistance between pin 12 and 13 on the surge suppressor (see page 16), if the circuit “closes” when the radio receiver is transmitting, replace the surge suppressor.

## RESETTING MOTOR(S)

**NOTE:** Press firmly to reset thermal breaker button(s).



**Motor(s) need resetting when:**  
Reset Motor LED light flashes once,  
THEN  
System ON LED light flashes rapidly.



# TROUBLESHOOTING


## TROUBLESHOOTING CHART

<b>Condition</b>	<b>Probable Causes</b>	<b>Solution</b>
<b>Overload LED ON and Power LED OFF</b>	<ol style="list-style-type: none"> <li>1. Short circuit at terminals 11 and 13.</li> <li>2. Short circuit at any of the loop detectors in the board.</li> <li>3. Short circuit in the control board.</li> </ol>	<ol style="list-style-type: none"> <li>1. Remove the short circuit condition at the terminals.</li> <li>2. Remove the defective loop detector.</li> <li>3. Send the board to repair.</li> </ol>
<b>Overload LED ON and Power LED ON</b>	<ol style="list-style-type: none"> <li>1. Excessive current draw at terminal 13.</li> <li>2. Over-voltage at the 120 Vac line input.</li> </ol>	<ol style="list-style-type: none"> <li>1. Reduce the accessories load from surge suppressor terminal 13.</li> <li>2. Verify your electrical power.</li> </ol>
<b>System On LED Flashing</b>	<ol style="list-style-type: none"> <li>1. Motor thermal fuse has popped-out (Rapid Flashing). OR</li> <li>2. One limit switch is faulty (Rapid Flashing).</li> </ol>	<ol style="list-style-type: none"> <li>1. Reset the motor. OR</li> <li>2. Test the limit switches and wire connections, fix the fault.</li> </ol>
<b>Reverse Sensor LED ON</b>	<ol style="list-style-type: none"> <li>1. Gate has encountered an obstruction during traveling.</li> <li>2. Reverse sensor is extra sensitive.</li> </ol>	<ol style="list-style-type: none"> <li>1. Remove the obstruction.</li> <li>2. Turn the reverse sensor switch counter-clockwise a little more and try again.</li> </ol>
<b>Alarm Sensor LED ON</b>	<ol style="list-style-type: none"> <li>1. Gate encountered an obstruction during traveling.</li> <li>2. Alarm sensor is extra sensitive.</li> </ol>	<ol style="list-style-type: none"> <li>1. Remove the obstruction.</li> <li>2. Turn the alarm sensor switch counter clockwise a little more and try again.</li> </ol>
<b>Command Processed LED ON</b>	<ol style="list-style-type: none"> <li>1. There is a command hold active.</li> </ol>	<ol style="list-style-type: none"> <li>1. This is a normal response of the gate operator. It does not represent necessarily that there is a problem.</li> </ol>
<b>Timer LED Blinking and Command Processed LED Blinking</b>	<ol style="list-style-type: none"> <li>1. There is a command holding the gate open.</li> </ol>	<ol style="list-style-type: none"> <li>1. This is a normal response of the gate operator. It does not represent necessarily that there is a problem. Check inputs for command.</li> </ol>
<b>Timer LED Blinking, Command Processed LED Blinking and Reverse Sensor LED ON</b>	<ol style="list-style-type: none"> <li>1. Gate has reopened because it encountered an obstruction while closing.</li> </ol>	<ol style="list-style-type: none"> <li>1. Any re-new command will resume normal operation. Check for obstructions.</li> </ol>
<b>Audio Alarm ON</b>	<ol style="list-style-type: none"> <li>1. Gate has encountered two consecutive obstructions while trying to close or open.</li> </ol>	<ol style="list-style-type: none"> <li>1. Any re-new command will resume normal operation but not a radio command. Check for obstructions.</li> <li>2. You can stop the alarm by using the built-in reset button.</li> <li>3. You can stop the alarm by using an optional stop button.</li> </ol>
<b>Any Loop LED ON and No vehicle on the sensing area</b>	<ol style="list-style-type: none"> <li>1. The loop detector needs to be reset.</li> <li>2. The wire loop has been disrupted.</li> <li>3. The loop detector needs to work in a different frequency.</li> <li>4. The loop detector is too sensitive.</li> </ol>	<ol style="list-style-type: none"> <li>1. Reset the loop detector (If you use LiftMaster Plug-in Loop detectors, change the setting for sensitivity and come back to your original setting).</li> <li>2. Verify and correct connections.</li> <li>3. Set a different working frequency.</li> <li>4. Decrease the sensitivity of the loop detector.</li> </ol>

For technical support: **1-800-528-2806**

# REPAIR PARTS

## REPAIR PARTS ILLUSTRATIONS



**NOTE:** \* Sold individually, 2 shown.  
For part list, refer to next page.

# REPAIR PARTS

## HOW TO ORDER REPAIR PARTS

OUR LARGE SERVICE ORGANIZATION SPANS AMERICA. INSTALLATION AND SERVICE INFORMATION IS AS NEAR AS YOUR TELEPHONE. SIMPLY DIAL OUR TOLL FREE NUMBER:

**1-800-528-2806**

[www.liftmaster.com](http://www.liftmaster.com)

WHEN ORDERING REPAIR PARTS, ALWAYS GIVE THE FOLLOWING INFORMATION:

- PART NUMBER
- PART NAME
- MODEL NUMBER

Address orders to:

**THE CHAMBERLAIN GROUP, INC.**  
**Technical Support Group**  
6050 S. Country Club Road  
Tucson, Arizona 85706

## REPAIR PART NAMES AND NUMBERS

### **Cludge Assembly - Q061**

- Arm Release Handle
- Output Shaft Cludge

### **Sprocket and Chain Kit - Q057**

- 1-1/8 inch dia. sprocket fits size 70 gear box
- 1 inch dia. sprocket fits size 60 gear box
- Sprocket #35
- Chain #35-72 links
- Chain #35-68 links

### **Assembly, limit Rack, CSW - Q165**

- Limit Switch Bracket
- Limit Cam (Plastic Part)

### **Gear Box Assembly (Size 70) - Q210**

- Sprocket

### **Electronic Box Assembly - K75-34709-4**

- Electronic Metal Box
- Surge Suppressor
- Dust Guard

### **Power Back-Up Unit - ODC2000CSW**

- Drive Belt DC CSW (DM) Q042
- Back-Up Motor DC 12V
- Chassis DC Back-Up
- Hardware Kit for DC Back-Up
- Drive Belt DC CW 4L240 Q163
- Wire Harness DC-2000
- Pulley DC1000 1/2 ID

850LM - 24V Radio Receiver  
G6518CSW - Heater  
K45-50676 - Star Knob  
K23-51142 - Reset Button Assembly  
K82-PX06-05 - PC Board Screws  
Q018 - 1/2 HP Electric Motor  
Q019 - Control Board Non UL (Not Shown)  
Q025 - Motor Pulley (ID5/8)  
Q027 - Motor Capacitor  
Q029 - Limit Switch (One)  
Q044 - Chain No. 50  
Q045 - Drive Belt 1/2 HP 4L190  
Q046 - Gear Reducer Pulley  
Q059 - Output Arm Solid  
Q062 - Cludge Cover - Stainless Steel  
Q084 - Emergency Key Release  
Q118 - Key for Access Door  
Q175 - Belt UL DM/1 HP  
Q183 - Sprocket (B50-16)  
Q212 - Gear Reducer 40-30:1  
Q216 - Output Shaft for 70 Reducer  
K73-36687 - CSW200UL8™ Chassis for 70 Reducer  
K75-35400-2 - Cover - HD Polyethylene  
K75-36763 - Cover - DM HD Polyethylene  
Q268 - Cludge Cover - Plastic  
K75-36768 - Stainless Steel Cover  
Q400E-1 - Omni Main PCB (OmniControl™)  
Q401 - Omni 1 Horsepower Board  
Q404 - Omni Alarm  
Q407 - Omni Motor Harness 1HP  
K10-36700 - Junction Box with On/Off Switch and Receptacle  
K13-34729 - Dust Guard  
Q410 - Surge Suppressor Terminal Block  
Q520 - Omni Motor Harness  
Q521 - Omni Motor Harness DM


**NOTE:** **Assembly Parts Number**

# ACCESSORIES

## Remote Controls

Part # 893MAX

Part # 811LM




Part # 890MAX





**Omni Relay Adapter**  
Part # Q400MAU


**Standard Arm**  
Part # Q104




**Swivel Arm**  
Part # Q103



**Heater Kit**  
Part # G6518CSW




**OmniControl™ Board**  
Part # OOMNIEXB



**Power Hinges**



**UL Approved Round Sensing Edge**  
Part # G65MGR20x  
x= length (4, 5, 6, 8 ft)  
(e.g. G65MGR206 is 6 ft)



**Mounting Plate**  
Part # MPEL


**UL Approved Square Sensing Edge**

Part # G65MGS20x  
x= length (4, 5, 6, 8 ft)  
(e.g. G65MGS204 is 4 ft)


For more information about accessories:  
[www.liftmaster.com](http://www.liftmaster.com)




**Magnetic Lock (Outdoor)**  
Part # MG1300



**Stop Button**  
Part # AEXITP



**12 Vdc Photoelectric Sensor**  
Part # AOMRON



**3-Button Control Station**  
Part # 02-103



**120 Vac External Loop Detector**  
Part # A79



**Plug-In Loop Detector**  
Part # AELD



**DC2000™ Kit**  
Part # ODC2000CSW

# INSTALLATION CHECKLIST

- ☐ 1. Owner and Installer **must** read all warnings and safety precautions.
- ☐ 2. Make sure concrete mounting pad is big enough and deep enough for operator.
- ☐ 3. Operator must be **securely** fastened to concrete pad or mounting plate.
- ☐ 4. Operator arm must be **level** and welded properly to gate.
- ☐ 5. Rectangular tubes on operator arm must be **completely** welded around.
- ☐ 6. When gate is pulled, **No** slippage of operator arm should occur.
- ☐ 7. Gate operator to be grounded to an earth ground rod within 3 feet of operator.
- ☐ 8. Verify that power is connected properly. **Know where the main power disconnect is for operator(s).**
- ☐ 9. Verify that the gate opens and closes as needed.
- ☐ 10. When gate hits object during operation, it **must** stop or reverse direction.
- ☐ 11. **Know how to operate the emergency manual release.**
- ☐ 12. Make sure that any pinch point or potential entrapment are guarded by means of entrapment protection devices or like.
- ☐ 13. Warning placards need to be permanently mounted on **both** sides of gate.
- ☐ 14. Test all additional equipment connected to operator.
- ☐ 15. Make sure all wire connections are **securely** fastened.
- ☐ 16. Review typical maintenance on operator.
- ☐ 17. Schedule periodic maintenance on operator by qualified service technician.
- ☐ 18. Inquire about Manufacturers “operator warranty.” (Warranty Card included with operator.)
- ☐ 19. Inquire about **separate** “installation warranty” with installer.

***Installer Company Name, Address and Phone Number***

***Date Installed:*** \_\_\_\_\_

# WARRANTY POLICY

## **7 YEAR RESIDENTIAL / 5 YEAR COMMERCIAL CSW200UL8™ LIMITED WARRANTY**

The Chamberlain Group, Inc. ("Seller") warrants to the first purchaser of this product, for the structure in which this product is originally installed, that it is free from defect in materials and/or workmanship for a period of 7 year residential/ 5 year commercial from the date of purchase [and that the CSW200UL8™ is free from defect in materials and/or workmanship for a period of 7 year residential/ 5 year commercial from the date of purchase]. The proper operation of this product is dependent on your compliance with the instructions regarding installation, operation, maintenance and testing. Failure to comply strictly with those instructions will void this limited warranty in its entirety.

If, during the limited warranty period, this product appears to contain a defect covered by this limited warranty, call **1-800-528-2806**, toll free, before dismantling this product. Then send this product, pre-paid and insured, to our service center for warranty repair. You will be advised of shipping instructions when you call. Please include a brief description of the problem and a dated proof-of-purchase receipt with any product returned for warranty repair. Products returned to Seller for warranty repair, which upon receipt by Seller are confirmed to be defective and covered by this limited warranty, will be repaired or replaced (at Seller's sole option) at no cost to you and returned pre-paid. Defective parts will be repaired or replaced with new or factory-rebuilt parts at Seller's sole option.

**ALL IMPLIED WARRANTIES FOR THE PRODUCT, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE 7 YEAR RESIDENTIAL/ 5 YEAR COMMERCIAL LIMITED WARRANTY PERIOD SET FORTH ABOVE [EXCEPT THE IMPLIED WARRANTIES WITH RESPECT TO THE CSW200UL8™, WHICH ARE LIMITED IN DURATION TO THE 7 YEAR RESIDENTIAL/ 5 YEAR COMMERCIAL LIMITED WARRANTY PERIOD FOR THE CSW200UL8™], AND NO IMPLIED WARRANTIES WILL EXIST OR APPLY AFTER SUCH PERIOD. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. THIS LIMITED WARRANTY DOES NOT COVER NON-DEFECT DAMAGE, DAMAGE CAUSED BY IMPROPER INSTALLATION, OPERATION OR CARE (INCLUDING, BUT NOT LIMITED TO ABUSE, MISUSE, FAILURE TO PROVIDE REASONABLE AND NECESSARY MAINTENANCE, UNAUTHORIZED REPAIRS OR ANY ALTERATIONS TO THIS PRODUCT), LABOR CHARGES FOR REINSTALLING A REPAIRED OR REPLACED UNIT, OR REPLACEMENT OF BATTERIES.**

**THIS LIMITED WARRANTY DOES NOT COVER ANY PROBLEMS WITH, OR RELATING TO, THE GARAGE DOOR OR GARAGE DOOR HARDWARE, INCLUDING BUT NOT LIMITED TO THE DOOR SPRINGS, DOOR ROLLERS, DOOR ALIGNMENT OR HINGES. THIS LIMITED WARRANTY ALSO DOES NOT COVER ANY PROBLEMS CAUSED BY INTERFERENCE. ANY SERVICE CALL THAT DETERMINES THE PROBLEM HAS BEEN CAUSED BY ANY OF THESE ITEMS COULD RESULT IN A FEE TO YOU.**

**UNDER NO CIRCUMSTANCES SHALL SELLER BE LIABLE FOR CONSEQUENTIAL, INCIDENTAL OR SPECIAL DAMAGES ARISING IN CONNECTION WITH USE, OR INABILITY TO USE, THIS PRODUCT. IN NO EVENT SHALL SELLER'S LIABILITY FOR BREACH OF WARRANTY, BREACH OF CONTRACT, NEGLIGENCE OR STRICT LIABILITY EXCEED THE COST OF THE PRODUCT COVERED HEREBY. NO PERSON IS AUTHORIZED TO ASSUME FOR US ANY OTHER LIABILITY IN CONNECTION WITH THE SALE OF THIS PRODUCT.**

Some states do not allow the exclusion or limitation of consequential, incidental or special damages, so the above limitation or exclusion may not apply to you. This limited warranty gives you specific legal rights, and you may also have other rights which vary from state to state.



**845 Larch Avenue  
Elmhurst, Illinois 60126-1196**