

LiftMaster®

ELITE SERIES®

CSW24V™ & CSW24VH™

VEHICULAR SWING GATE OPERATOR

INSTALLATION MANUAL



Your model may look different than the model illustrated in this manual.

**THIS PRODUCT IS TO BE
INSTALLED AND SERVICED BY A
TRAINED GATE SYSTEMS
TECHNICIAN ONLY.**

Visit www.liftmaster.com to
locate a professional installing
dealer in your area.

This model is for use on vehicular
passage gates **ONLY** and not
intended for use on pedestrian
passage gates.

This model is intended for use in
Class I, II, III and IV vehicular
swing gate applications.

UL325
compliant



UL991
compliant

TABLE OF CONTENTS

SAFETY	2	PROGRAMMING	28
UL325 MODEL CLASSIFICATIONS	2	REMOTE CONTROLS (NOT PROVIDED)	28
SAFETY INSTALLATION INFORMATION	3	ERASE ALL CODES	28
GATE CONSTRUCTION INFORMATION	4	FINISH INSTALLATION	29
REQUIRED ENTRAPMENT PROTECTION DEVICES	5	INSTALL THE COVER	29
IMPORTANT SAFETY INFORMATION	6	OPERATION	30
IMPORTANT SAFETY INFORMATION CONTINUED.....	7	MANUAL DISCONNECT	30
INTRODUCTION	8	RESET SWITCH	30
OPERATOR SPECIFICATIONS	8	OPERATOR ALARM	30
CARTON INVENTORY & OPERATOR DIMENSIONS	8	REMOTE CONTROL	30
FEATURES	9	HEATER (IF APPLICABLE)	30
PREPARATION	10	ADDITIONAL FEATURES	31
SITE PREPARATION	10	GATE OPERATOR SETUP EXAMPLES	31
INSTALLATION	12	CONTROL BOARD OVERVIEW	32
STANDARD INSTALLATION ONLY	12	WIRING ACCESSORIES TO THE CONTROL BOARD	33
STANDARD INSTALLATION ONLY CONTINUED.....	15	EXPANSION BOARD OVERVIEW	34
COMPACT INSTALLATION ONLY	16	WIRING ACCESSORIES TO THE EXPANSION BOARD	35
COMPACT INSTALLATION ONLY CONTINUED.....	17	SAMS WIRING WITH RELAYS NOT ENERGIZED	36
INSTALLATION CONTINUED.....	18	DUAL GATE SETTINGS	36
WIRING	19	LIFTMASTER INTERNET GATEWAY	38
WIRE THE ENTRAPMENT PROTECTION DEVICES	19	WIRING DIAGRAMS	39
EARTH GROUND ROD	19	TROUBLESHOOTING	40
POWER WIRING	20	CONTROL BOARD LEDS	40
POWER WIRING CONTINUED.....	21	CONTROL BOARD LEDS CONTINUED.....	41
AC POWER SWITCH	22	TROUBLESHOOTING CHART	42
CONNECT BATTERIES	22	ACCESSORIES	45
CONNECT BATTERIES CONTINUED.....	23	REPAIR PARTS	46
DUAL GATES ONLY	24	INDIVIDUAL PARTS	46
DUAL GATES ONLY CONTINUED.....	25	MAINTENANCE	48
ADJUSTMENT	26	MAINTENANCE CHART	48
LIMIT AND FORCE ADJUSTMENT	26	BATTERIES	48
OBSTRUCTION TEST	27	WARRANTY	49

SAFETY

SAFETY SYMBOL AND SIGNAL WORD REVIEW

When you see these Safety Symbols and Signal Words on the following pages, they will alert you to the possibility of serious injury or death if you do not comply with the warnings that accompany them. The hazard may come from something mechanical or from electric shock. Read the warnings carefully.

When you see this Signal Word on the following pages, it will alert you to the possibility of damage to your gate and/or the gate operator if you do not comply with the cautionary statements that accompany it. Read them carefully.

IMPORTANT NOTE

- *BEFORE attempting to install, operate or maintain the operator, you must read and fully understand this manual and follow all safety instructions.*
- *DO NOT attempt repair or service of your gate operator unless you are an Authorized Service Technician.*

 **WARNING**

MECHANICAL

 **WARNING**

ELECTRICAL

CAUTION

UL325 MODEL CLASSIFICATIONS

CLASS I – RESIDENTIAL VEHICULAR GATE OPERATOR

A vehicular gate operator (or system) intended for use in a home of one-to four single family dwellings, or a garage or parking area associated therewith.

CLASS II – COMMERCIAL/GENERAL ACCESS VEHICULAR GATE OPERATOR


A vehicular gate operator (or system) intended for use in a commercial location or building such as a multi-family housing unit (five or more single family units) hotel, garage, retail store or other building servicing the general public.

CLASS III – INDUSTRIAL/LIMITED ACCESS VEHICULAR GATE OPERATOR

A vehicular gate operator (or system) intended for use in an industrial location or building such as a factory or loading dock area or other location not intended to service the general public.

CLASS IV – RESTRICTED ACCESS VEHICULAR GATE OPERATOR

A vehicular gate operator (or system) intended for use in a guarded industrial location or building such as an airport security area or other restricted access locations not servicing the general public, in which unauthorized access is prevented via supervision by security personnel.



UL325 ENTRAPMENT PROTECTION REQUIREMENTS

This chart illustrates the entrapment protection requirements for the UL325 classes.


GATE OPERATOR ENTRAPMENT PROTECTION		
UL325 Classification	Swing Gate Operator	
	Primary Type	Secondary Type
CLASS I-CLASS IV	A	B1 or B2

In order to complete a proper installation you must satisfy the entrapment protection chart shown. That means that the installation must have one primary means of entrapment protection and one independent secondary means of entrapment protection. Both primary and secondary entrapment protection methods must be designed, arranged or configured to protect against entrapments in both the open and close directions of gate travel.

For Example: For a gate system that is installed on a single-family residence (UL325 Class I) you must provide the following: As your primary type of entrapment protection you must provide

- Type A - Inherent (built into the operator) entrapment sensing and at least one of the following as your secondary entrapment protection:
- Type B1 - Non-contact sensors such as photoelectric sensors,
- Type B2 - Contact sensors such as gate edges

NOTE: UL requires that all installations must have warning signs placed in plain view on both sides of the gate to warn pedestrians of the dangers of motorized gate systems.



SAFETY INSTALLATION INFORMATION

1. Vehicular gate systems provide convenience and security. Gate systems are comprised of many component parts. The gate operator is only one component. Each gate system is specifically designed for an individual application.
2. Gate operating system designers, installers and users must take into account the possible hazards associated with each individual application. Improperly designed, installed or maintained systems can create risks for the user as well as the bystander. Gate systems design and installation must reduce public exposure to potential hazards.
3. A gate operator can create high levels of force in its function as a component part of a gate system. Therefore, safety features must be incorporated into every design. Specific safety features include:
 - Gate Edges
 - Photoelectric Sensors
 - Vertical Posts
 - Guards for Exposed Rollers
 - Screen Mesh
 - Instructional and Precautionary Signage
4. Install the gate operator only when:
 - a. The operator is appropriate for the construction and the usage class of the gate.
 - b. All openings of a horizontal slide gate are guarded or screened from the bottom of the gate to a minimum of 4 feet (1.2 m) above the ground to prevent a 2-1/4 inches (6 cm) diameter sphere from passing through the openings anywhere in the gate, and in that portion of the adjacent fence that the gate covers in the open position.



- c. All exposed pinch points are eliminated or guarded, and guarding is supplied for exposed rollers.
5. The operator is intended for installation only on gates used for vehicles. Pedestrians must be supplied with a separate access opening. The pedestrian access opening shall be designed to promote pedestrian usage. Locate the gate such that persons will not come in contact with the vehicular gate during the entire path of travel of the vehicular gate.




6. The gate must be installed in a location so that enough clearance is supplied between the gate and adjacent structures when opening and closing to reduce the risk of entrapment. Swinging gates shall not open into public access areas.
7. The gate must be properly installed and work freely in both directions prior to the installation of the gate operator.

8. Controls intended for user activation must be located at least 6 feet (1.8 m) away from any moving part of the gate and where the user is prevented from reaching over, under, around or through the gate to operate the controls. Outdoor or easily accessible controls shall have a security feature to prevent unauthorized use.



9. The Stop and/or Reset (if provided separately) must be located in the line-of-sight of the gate. Activation of the reset control shall not cause the operator to start.
10. A minimum of two (2) WARNING SIGNS shall be installed, one on each side of the gate where easily visible.



11. For a gate operator utilizing a non-contact sensor:
 - a. Reference owner's manual regarding placement of non-contact sensor for each type of application.
 - b. Care shall be exercised to reduce the risk of nuisance tripping, such as when a vehicle trips the sensor while the gate is still moving.
 - c. One or more non-contact sensors shall be located where the risk of entrapment or obstruction exists, such as the perimeter reachable by a moving gate or barrier.
12. For a gate operator utilizing a contact sensor such as an edge sensor:
 - a. One or more contact sensors shall be located where the risk of entrapment or obstruction exists, such as at the leading edge, trailing edge and post mounted both inside and outside of a vehicular horizontal slide gate.
 - b. One or more contact sensors shall be located at the bottom edge of a vehicular vertical lift gate.
 - c. A hard wired contact sensor shall be located and its wiring arranged so the communication between the sensor and the gate operator is not subject to mechanical damage.
 - d. A wireless contact sensor such as the one that transmits radio frequency (RF) signals to the gate operator for entrapment protection functions shall be located where the transmission of the signals are not obstructed or impeded by building structures, natural landscaping or similar obstruction. A wireless contact sensor shall function under the intended end-use conditions.
 - e. One or more contact sensors shall be located on the inside and outside leading edge of a swing gate. Additionally, if the bottom edge of a swing gate is greater than 6 inches (152 mm) above the ground at any point in its arc of travel, one or more contact sensors shall be located on the bottom edge.
 - f. One or more contact sensors shall be located at the bottom edge of a vertical barrier (arm).

GATE CONSTRUCTION INFORMATION

Vehicular gates should be installed in accordance with ASTM F2200: Standard Specification for Automated Vehicular Gate Construction. For a copy, contact ASTM directly at 610-832-9585 or www.astm.org.

1. GENERAL REQUIREMENTS

- 1.1 Gates shall be constructed in accordance with the provisions given for the appropriate gate type listed, refer to ASTM F2200 for additional gate types.
- 1.2 Gates shall be designed, constructed and installed to not fall over more than 45 degrees from the vertical plane, when a gate is detached from the supporting hardware.
- 1.3 Gates shall have smooth bottom edges, with vertical bottom edged protrusions not exceeding 0.50 inches (12.7 mm) when other than the exceptions listed in ASTM F2200.
- 1.4 The minimum height for barbed tape shall not be less than 8 feet (2.44 m) above grade and for barbed wire shall not be less than 6 feet (1.83 m) above grade.
- 1.5 An existing gate latch shall be disabled when a manually operated gate is retrofitted with a powered gate operator.
- 1.6 A gate latch shall not be installed on an automatically operated gate.
- 1.7 Protrusions shall not be permitted on any gate, refer to ASTM F2200 for Exceptions.
- 1.8 Gates shall be designed, constructed and installed such that their movement shall not be initiated by gravity when an automatic operator is disconnected.
- 1.9 A pedestrian gate shall not be incorporated into a vehicular gate panel or that portion of the adjacent fence that the gate covers in the open position.


2. SPECIFIC APPLICATIONS

- 2.1 Any non-automated gate that is to be automated shall be upgraded to conform to the provisions of this specification.
- 2.2 This specification shall not apply to gates generally used for pedestrian access and to vehicular gates not to be automated.
- 2.3 Any existing automated gate, when the operator requires replacement, shall be upgraded to conform to the provisions of this specification in effect at that time.

3. VEHICULAR HORIZONTAL SLIDE GATES

- 3.1 The following provisions shall apply to Class I, Class II and Class III vehicular horizontal slide gates:
 - 3.1.1 All weight bearing exposed rollers 8 feet (2.44 m), or less, above grade shall be guarded or covered.
 - 3.1.2 All openings located between 48 inches (1.22 m) and 72 inches (1.83 m) above grade shall be designed, guarded or screened to prevent a 4 inch (102 mm) diameter sphere from passing through the openings anywhere in the gate, and in that portion of the adjacent fence that covers in the open position.

- 3.1.3 A gap, measured in the horizontal plane parallel to the roadway, between a fixed stationary object nearest the roadway, (such as a gate support post) and the gate frame when the gate is in either the fully open position or the fully closed position, shall not exceed 2 1/4 inches (57 mm), refer to ASTM F2200 for Exception.
- 3.1.4 Positive stops shall be required to limit travel to the designed fully open and fully closed positions. These stops shall be installed at either the top of the gate, or at the bottom of the gate where such stops shall horizontally or vertically project no more than is required to perform their intended function.
- 3.1.5 All gates shall be designed with sufficient lateral stability to assure that the gate will enter a receiver guide, refer to ASTM F2200 for panel types.
- 3.2 The following provisions shall apply to Class IV vehicular horizontal slide gates:
 - 3.2.1 All weight bearing exposed rollers 8 feet (2.44 m), or less, above grade shall be guarded or covered.
 - 3.2.2 Positive stops shall be required to limit travel to the designed fully open and fully closed positions. These stops shall be installed at either the top of the gate, or at the bottom of the gate where such stops shall horizontally or vertically project no more than is required to perform their intended function.



4. VEHICULAR HORIZONTAL SWING GATES

- 4.1 The following provisions shall apply to Class I, Class II and Class III vehicular horizontal swing gates:
 - 4.1.1 Gates shall be designed, constructed and installed so as not to create an entrapment area between the gate and the supporting structure or other fixed object when the gate moves toward the fully open position, subject to the provisions in the 4.1.1.1 and 4.1.1.2.
 - 4.1.1.1 The width of an object (such as a wall, pillar or column) covered by a swing gate when in the open position shall not exceed 4 inches (102 mm), measured from the center line of the pivot point of the gate, refer to ASTM F2200 for exception.
 - 4.1.1.2 Except for the zone specified in Section 4.1.1.1, the distance between a fixed object such as a wall, pillar or column, and a swing gate when in the open position shall not be less than 16 inches (406 mm), refer to ASTM F2200 for exception.
 - 4.2 Class IV vehicular horizontal swing gates shall be designed, constructed and installed in accordance with security related parameters specific to the application in question.

REQUIRED ENTRAPMENT PROTECTION DEVICES

WARNING

To prevent **SERIOUS INJURY** or **DEATH** from a moving gate:


- Entrapment protection devices **MUST** be installed to protect anyone who may come near a moving gate.
- Locate entrapment protection devices to protect in **BOTH** the open and close gate cycles.
- Locate entrapment protection devices to protect between moving gate and **RIGID** objects, such as posts or walls.

An entrapment zone is every location or point of contact where a person can become entrapped between a moving gate and a stationary object. All gate operator systems **REQUIRE** two independent entrapment protection systems for each entrapment zone. This operator contains an inherent (internal) entrapment protection system (the primary entrapment protection system) and **REQUIRES** the addition of an external entrapment protection system (non-contact photoelectric sensor or contact safety edge sensor) for **EACH** entrapment zone.

Your application may contain one or many entrapment zones. Property owners are obligated to test entrapment protection devices monthly.


CONTACT SENSORS (EDGE SENSORS)

If the electrically activated edge sensor comes in contact with an obstruction while the gate is moving, the gate will stop and reverse. The gate will not be able to travel in that direction until the obstruction is cleared. Use edge sensor models G65MG0204, G65MGR020, or G65MGS020.



NON-CONTACT SENSORS

If the photoelectric sensor beam gets blocked while the gate is moving, the gate will stop and reverse. The gate will not be able to travel in that direction until the obstruction is cleared. It is best to use monitored photoelectric sensors, model CPS-UN4. If a monitored photoelectric sensor is not working or loses power or the beam is blocked, then **ALL** gate operation in that direction will stop. Unmonitored photoelectric sensor models AOMRON and RETROAB are also acceptable.



IMPORTANT SAFETY INFORMATION

INSTALLATION

WARNING

To prevent **SERIOUS INJURY** or **DEATH** from a moving gate:

- Pinch points must be guarded at all times. Install enclosed-style gate tracks and roller guards.
- Place screen mesh 4 feet (1.2 m) high on the gate to prevent access through openings anywhere the gate may travel.
- Mount controls at least 6 feet (1.8 m) from the gate or ANY moving part of the gate.
- Install Warning signs on EACH side of gate in **PLAIN VIEW**. Permanently secure each Warning sign in a suitable manner using fastening holes.
- This operator is intended for vehicular use only. To prevent **INJURY** to pedestrians, a separate pedestrian access should be supplied, visible from the gate. Locate the pedestrian access where there is not a chance of **INJURY** at any point during full movement of the gate.
- Contact sensors **MUST** be located at the leading and trailing edges, and post mounted both inside and outside a horizontal swing gate. Non-contact sensors such as photo eyes **MUST** be mounted across the gate opening and operate during **BOTH** the open and close cycles.
- Entrapment protection devices **MUST** be installed to protect anyone who may come near a moving gate.
- Locate entrapment protection devices to protect in **BOTH** the open and close gate cycles.
- Locate entrapment protection devices to protect between moving gate and **RIGID** objects, such as posts or walls.
- Too much force on gate will interfere with proper operation of safety reversal system.
- **NEVER** increase force beyond minimum amount required to move gate.
- **NEVER** use force adjustments to compensate for a binding or sticking gate.
- If one control (force or travel limits) is adjusted, the other control may also need adjustment.
- After **ANY** adjustments are made, the safety reversal system **MUST** be tested. Gate **MUST** reverse on contact with a rigid object.
- **DO NOT** touch the heater when switch is on, heater may be hot.

CAUTION

- To **AVOID** damaging gas, power or other underground utility lines, contact underground utility locating companies **BEFORE** digging more than 18 inches (46 cm) deep.
- **ALWAYS** wear protective gloves and eye protection when changing the battery or working around the battery compartment.

WIRING

WARNING

To reduce the risk of **SEVERE INJURY** or **DEATH**:

- **ANY** maintenance to the operator or in the area near the operator **MUST NOT** be performed until disconnecting the electrical power (AC or solar and battery) and locking-out the power via the operator power switch. Upon completion of maintenance the area **MUST** be cleared and secured, at that time the unit may be returned to service.
- Disconnect power at the fuse box **BEFORE** proceeding. Operator **MUST** be properly grounded and connected in accordance with national and local electrical codes. **NOTE:** *The operator should be on a separate fused line of adequate capacity.*
- **ALL** electrical connections **MUST** be made by a qualified individual.
- **DO NOT** install **ANY** wiring or attempt to run the operator without consulting the wiring diagram. We recommend that you install an edge sensor **BEFORE** proceeding with the control station installation.
- **ALL** power wiring should be on a dedicated circuit and well protected. The location of the power disconnect should be visible and clearly labeled.
- **ALL** power and control wiring **MUST** be run in separate conduit.

ADJUSTMENT

WARNING

To reduce the risk of **SEVERE INJURY** or **DEATH**:

- Without a properly installed safety reversal system, persons (particularly small children) could be **SERIOUSLY INJURED** or **KILLED** by a moving gate.
- Too much force on gate will interfere with proper operation of safety reversal system.
- **NEVER** increase force beyond minimum amount required to move gate.
- **NEVER** use force adjustments to compensate for a binding or sticking gate.
- If one control (force or travel limits) is adjusted, the other control may also need adjustment.
- After **ANY** adjustments are made, the safety reversal system **MUST** be tested. Gate **MUST** reverse on contact with a rigid object.
- Keep clear of moving arm while setting limits.

IMPORTANT SAFETY INFORMATION CONTINUED...

ADDITIONAL FEATURES

WARNING

To prevent **SERIOUS INJURY** or **DEATH** from a moving gate:

- Entrapment protection devices **MUST** be installed to protect anyone who may come near a moving gate.
- Locate entrapment protection devices to protect in **BOTH** the open and close gate cycles.
- Locate entrapment protection devices to protect between moving gate and **RIGID** objects, such as posts or walls.

MAINTENANCE AND OPERATION

WARNING

To reduce the risk of **SEVERE INJURY** or **DEATH**:

- **READ AND FOLLOW ALL INSTRUCTIONS.**
- **ANY** maintenance to the operator or in the area near the operator **MUST NOT** be performed until disconnecting the electrical power (AC or solar and battery) and locking-out the power via the operator power switch. Upon completion of maintenance the area **MUST** be cleared and secured, at that time the unit may be returned to service.
- Disconnect power at the fuse box **BEFORE** proceeding. Operator **MUST** be properly grounded and connected in accordance with national and local electrical codes. **NOTE:** The operator should be on a separate fused line of adequate capacity.
- **NEVER** let children operate or play with gate controls. Keep the remote control away from children.
- **ALWAYS** keep people and objects away from the gate. **NO ONE SHOULD CROSS THE PATH OF THE MOVING GATE.**
- The entrance is for vehicles **ONLY**. Pedestrians **MUST** use separate entrance.
- Test the gate operator monthly. The gate **MUST** reverse on contact with a rigid object or reverse when an object activates the non-contact sensors. After adjusting the force or the limit of travel, retest the gate operator. Failure to adjust and retest the gate operator properly can increase the risk of **INJURY** or **DEATH**.
- Use the manual disconnect release **ONLY** when the gate is not moving.
- **KEEP GATES PROPERLY MAINTAINED.** Read the owner's manual. Have a qualified service person make repairs to gate hardware.
- **ALL** maintenance **MUST** be performed by a LiftMaster professional.
- Activate gate **ONLY** when it can be seen clearly, is properly adjusted and there are no obstructions to gate travel.
- To reduce the risk of **FIRE** or **INJURY** to persons use **ONLY** LiftMaster part 29-NP712 for replacement batteries.
- **SAVE THESE INSTRUCTIONS.**

CAUTION

- **ALWAYS** wear protective gloves and eye protection when changing the battery or working around the battery compartment.

TROUBLESHOOTING

WARNING

To protect against fire and electrocution:

- **DISCONNECT** power (AC or solar and battery) **BEFORE** installing or servicing operator.
- For continued protection against fire:
 - Replace **ONLY** with fuse of same type and rating.

INTRODUCTION

OPERATOR SPECIFICATIONS + CARTON INVENTORY & OPERATOR DIMENSIONS

OPERATOR SPECIFICATIONS

This model is intended for use in vehicular swing gate applications:

Gate Classifications: CLASS I, II, III, & IV

Main AC Supply: 120 Vac or 240 Vac

Solar Power Max: 24 Vdc at 60 watts max.

Input Rating:

- CSW24V: 10 Amps at 120 Vac or 2 Amps at 240 Vac
- CSW24VH: 12 Amps at 120 Vac

Input Rating Excluding Accessory Outlets:

- CSW24V: 4 Amps at 120 Vac or 2 Amps at 240 Vac
- CSW24VH: 6 Amps at 120 Vac

***Input Rating of Accessory Outlets:** 6 Amps at 120 Vac

***NOTE:** The accessory outlets are not connected for the 240 Vac rating.

Main Supply (Motor): 24 Vdc

Accessory Power: 24 Vdc 500 mA Max for ON or SW (switched)

NOTE: Increased accessory power drawn from the operator will shorten the battery back-up duration or decrease cycle count for solar applications.

Full Cycle Time: 40 seconds (90 degree opening and closing)

Maximum Travel Range: 115 degrees

Heater Draw (Optional): 325 watts (120 Vac ONLY)

Maximum Gate Weight/Length:

- 1200 lbs./12 foot
- 800 lbs./16 foot
- 600 lbs./18 foot

Daily Cycle Rate AC power: Continuous duty

Ambient Temperature:


- Without Heater: -20°C to 60°C (-4°F to 140°F)
- With Heater: -40°C to 60°C (-40°F to 140°F)

Fuse Protection Battery: 30 Amp

Fuse Protection DC Power: 30 Amp

CARTON INVENTORY & OPERATOR DIMENSIONS

NOT SHOWN: Documentation Packet



FEATURES

OPERATOR FEATURES

- Advanced “Centerpiece” Control Board
- AC Surge Protection and EMI Filter Board
 - Main AC voltage input selection: 120 Vac (factory setting) or 240 Vac (field change)
- Long life DC motor
- AC powered with integrated Evercharge battery backup and management
- 24 Vdc accessory power
- Programmable with up to 50 remote controls and 2 keyless entries. Compatible with MyQ™ devices and Security+ 2.0™ codes at either 310, 315, 390 MHz, or 433 MHz
- Manual - Secure power failure selection
- SAMS compatible
- Slow-start and slow-stop gate motion
- Reset Button
- Audible Alarm
- Internal Heater option (factory installed or field installed) 120 Vac powered ONLY
- Non-Scissor Action swing arm with easy arm disconnect
- Integrated internal antenna with external antenna option
- Electronic limit adjustment and control from the remote control
- Wireless primary/secondary (refer to “wireless dual gates” on page 24)

CONTROL BOARD FEATURES

- Electronic Limit adjustment and control
- Adjustable reversal force
- Adjustable Timer-to-Close (TTC)
- Maximum Run Timer
- Bipart Delay switch (dual gate applications)
- Feedback and Diagnostic LEDs
- Integrated Radio Receiver and 3-Button Station control, four radio frequencies supporting Security+ 2.0™
- COMMANDS:
 - OPEN, CLOSE, or STOP: accessory connection and on-board button
 - FIRE DEPARTMENT OPEN: accessory connection
 - INTEGRATED RADIO RECEIVER
- LOOPS:
 - EXIT, SHADOW, or INTERRUPT LOOP: accessory connection

EXPANSION BOARD FEATURES

- Plug-in Loop Detector Connectors (Model LOOPDETLM Loop Detector)
 - SHADOW
 - INTERRUPT
 - EXIT, with Fail Safe/Fail Secure selection
- Quick-Close ON/OFF selection switch
- AC Fail Open/Battery selection switch
- Low Battery Open/Close selection switch
- Anti-Tail ON/OFF selection switch
- Single Button Control (SBC) accessory connection
- 3-Button station accessory connection
- AUX Relays (2) each independently selectable operation:
 - OPEN LIMIT: ON at open limit switch
 - CLOSE LIMIT: OFF at close limit switch
 - GATE MOVING: ON with gate moving
 - PRE-ALERT DELAY: ON 3 seconds before gate motion, option of using the onboard alarm
 - TAMPER: ON when gate manually pulled from close limit, option of using the external buzzer through AUX relay 1 or 2 on expansion board.
 - POWER: ON with AC or Solar power available
 - CYCLE QUANTITY: LEDs blink operational cycle count

PREPARATION


SITE PREPARATION

Check the national and local building codes **BEFORE** installation.




GATE

Gate must be constructed and installed according to ASTM F2200 standards (refer to page 4). Gate must fit specifications of operator (refer to specifications).




CONDUIT & CONCRETE PAD

Conduit must be UL approved for low and high voltage. Consider the operator placement **BEFORE** installing the pad or post.



SAFETY

Entrapment protection devices are required to protect against any entrapment or safety conditions encountered in your gate application (refer to page 5 for more details). Install warning signs on both sides of the gate



SAFETY


STANDARD INSTALLATION




The illustration is an example of a standard installation.

VEHICLE LOOPS

The vehicle loops allow the gate to stay open when vehicles are obstructing the gate path. Suggested for vehicles 14 feet (4.27 m) or longer. Vehicle loops are not required but are recommended.




COMPACT INSTALLATION




The illustration is an example of a compact installation. If the operator arm will hit an obstruction when the gate is in the open position follow the directions for Compact Installation.

EARTH GROUND ROD

Proper grounding gives an electrical charge, such as from an electrical static discharge or a near lightning strike, a path from which to dissipate its energy safely into the earth. Without this path, the intense energy generated by lightning could be directed towards the gate operator. Although nothing can absorb the tremendous power of a direct lightning strike, proper grounding can protect the gate operator in most cases.



UPHILL DRIVEWAY INSTALLATION





The illustration is an example of an uphill driveway installation. If installing the operator on a hill, a special swivel arm and hinges are required (not provided).

INSTALLATION

STANDARD INSTALLATION ONLY

CHART INSTALLATION

Refer to the illustration to determine the measurements and location of the concrete pad.



Dimension (A) thru (E) are from the center of one pivot point to the center of another pivot point.

Caution: If the gate is longer than 18 feet, follow **CHART A: A-2**.

Suggestion: The dimensions between the gate and the concrete pad is always 10 inches less than the dimension D.

Example: D = 42", if the dimensions between the gate and the concrete pad is 32".

If this dimension is between 20 and 32 inches, a compact installation is necessary. Refer to page 16.

CHART A

	A	B	C	D	E	DISTANCE
1	46"	35.5"	29.5"	35"	11"	45"
2	46.75"	35.5"	33.5"	42"	11"	37"
3	46.75"	37"	31.5"	40"	11"	41"
4	47.25"	37.25"	30"	37"	11"	45"
5	47"	35"	29.5"	32"	11"	45"
6	42.5"	33"	26.5"	28.5"	11"	41"

CHART B

	A	B	C	D	E	DISTANCE
1	34.5"	34.75"	29.5"	35"	14"	43"
2	44"	36.5"	32.5"	42"	14"	32"
3	44"	37"	30.5"	40"	14"	40"
4	45"	37"	30.5"	37"	14"	43"
5	44.75"	35.75"	29.5"	32"	14"	44"
6	41"	39"	27.5"	28.5"	14"	41"

INSTALLATION

STANDARD INSTALLATION ONLY



STANDARD INSTALLATION ONLY CONTINUED...

CONCRETE PAD AND OPERATOR ATTACHMENT

Check the national and local building codes before installation. **NOTE:** When lifting the operator use the handle to avoid damaging the operator.

- 1 Install the electrical conduit.
- 2 Pour a concrete pad (reinforced concrete is recommended). The concrete pad should be 6 inches above the ground and deeper than the frost line. Ensure the pad is tall enough to avoid possible flooding.
- 3 Secure the operator to the concrete pad with appropriate fasteners.

NOTE: An alternative to a concrete pad is to post mount the operator (refer to accessories).



INSTALLATION


STANDARD INSTALLATION ONLY

STANDARD INSTALLATION ONLY CONTINUED...

POSITION THE GATE BRACKET

NOTE: It may be necessary to attach horizontal reinforcement to the gate before attaching the gate bracket.


- 1 Position the operator arm onto the output shaft so that the pin slides into the slot.
- 2 Measure 46 inches along the gate length from the gate hinge center.
- 3 Measure 27.5 inches up from the concrete pad to the gate hinge position on the gate as shown.
- 4 Make sure the operator arm is level and tack weld the gate bracket in this position. Use the set screws on the arm to temporarily hold the arm in place while determining the correct measurements.



ADJUST THE OPERATOR ARM LENGTH

NOTE: The length of the arm can be adjusted if necessary. If adjusting the length, ensure that both sections of the arm are adjusted proportionally. Use the set screws on the arm to temporarily hold the arm in place while determining the correct measurements.

- 1 Close the gate and measure the distance of the operator arm from the gate bracket to the output shaft center. This distance is E.
- 2 Open the gate 90° (do not allow arms to scissor when open). Measure both sections of the arm (D and C). The arm lengths are correct as long as $C+D=E$ (arm should be perpendicular to the gate in the open position as shown).



Proceed to page 18.

INSTALLATION

COMPACT INSTALLATION ONLY


COMPACT INSTALLATION ONLY

DETERMINE LOCATION FOR CONCRETE PAD AND OPERATOR

DO NOT run the operator until instructed.

Refer to the illustration to determine the measurements and location of the concrete pad.

NOTE: When lifting the operator use the handle to avoid damaging the operator.





CONCRETE PAD AND OPERATOR ATTACHMENT

Check the national and local building codes before installation.

- 1 Install the electrical conduit.
- 2 Pour a concrete pad (reinforced concrete is recommended). The concrete pad should be 6 inches above the ground and deeper than the frost line. Ensure the pad is tall enough to avoid possible flooding.
- 3 Secure the operator to the concrete pad with appropriate fasteners.

NOTE: An alternative to a concrete pad is to post mount the operator (refer to accessories).




COMPACT INSTALLATION ONLY CONTINUED...

SHORTEN THE OPERATOR ARM

For a compact installation the operator arm will have to be shortened.


- 1 Take the operator arm apart and remove the inner sleeves from the outer tubing.
- 2 Cut the outer tubing of the operator arm sections to the lengths shown.
- 3 Put the arm back together and adjust the arm to the measurements as shown. Use the set screws on the arm to temporarily hold the arm in place while determining the correct measurements.



POSITION THE GATE BRACKET

NOTE: It may be necessary to attach horizontal reinforcement to the gate before attaching the gate bracket. Use the set screws on the arm to temporarily hold the arm in place while determining the correct measurements.

- 1 Position the operator arm onto the output shaft so that the pin slides into the slot.
- 2 Measure 33 inches along the gate length from the gate hinge center.
- 3 Measure 27.5 inches up from the concrete pad to the gate hinge position on the gate as shown.
- 4 Make sure the operator arm is level and tack weld the gate bracket in this position.



INSTALLATION

INSTALLATION CONTINUED...


INSTALLATION CONTINUED...

WELD THE OPERATOR ARM

Once the operator arm measurements are verified:


- 1 Weld the gate bracket to the gate.
- 2 Weld the short arm section.
- 3 Weld the long arm section.
- 4 Remove the set screws from the arm.

NOTE: Completely weld around the outer tubing and bracket.




SECURE THE OPERATOR ARM TO THE OUTPUT SHAFT

- 1 Adjust the nuts on the operator arm so the operator arm fits snug on the output shaft yet still allows enough room to swivel (the handle must be in a 90° position).
- 2 Tighten the handle by pushing it down. Test to make sure the operator arm does not slip on the output shaft.



REMOVE THE PINS FROM THE VENT PLUGS

- 1 Remove the pin from the vent plug on both the top and bottom gear boxes.



WIRING

WIRE THE ENTRAPMENT PROTECTION DEVICES + EARTH GROUND ROD

WIRE THE ENTRAPMENT PROTECTION DEVICES

Entrapment protection devices are required. Refer to page 5 for more information regarding application.


! WARNING

To prevent **SERIOUS INJURY** or **DEATH** from a moving gate:

- Entrapment protection devices **MUST** be installed to protect anyone who may come near a moving gate.
- Locate entrapment protection devices to protect in **BOTH** the open and close gate cycles.
- Locate entrapment protection devices to protect between moving gate and **RIGID** objects, such as posts or walls.

1 Connect the entrapment protection device to the EYES EDGE terminal on the control board:

- Close Photoelectric Sensor Entrapment Protection: Connect wires from the photoelectric sensors to the Inputs on the CLOSE EYES/INTERRUPT terminal.
- Close Edge Entrapment Protection: Connect wires from the entrapment protection device to the Inputs on the CLOSE EDGE terminal.
- Open Entrapment Protection: Connect wires from the entrapment protection device to the Inputs on the OPEN EYES/EDGE terminal.



NOTE: Refer to the “Wiring Accessories to the Control Board” section on page 33.

TO ERASE LEARNED MONITORED PHOTOELECTRIC SENSORS

- 1** Remove the photoelectric sensor wires from the terminal block.
- 2** Press and release the SET OPEN and SET CLOSE buttons simultaneously. The SET OPEN and SET CLOSE LEDs will turn on (entering learn limit mode).
- 3** Press and release both SET OPEN and SET CLOSE buttons again to turn off the SET OPEN and SET CLOSE LEDs (exiting learn limit mode).


NOTE: For dual gate applications repeat the steps above on the other operator.

EARTH GROUND ROD

Use the proper earth ground rod for your local area. The ground wire must be a single, whole piece of wire. Never splice two wires for the ground wire. If you should cut the ground wire too short, break it, or destroy its integrity, replace it with a single wire length.

- 1** Install the earth ground rod within 3 feet of the operator.
- 2** Run wire from the earth ground rod to the operator.

NOTE: If the operator is not grounded properly the range of the remote controls will be reduced.



WIRING

POWER WIRING

POWER WIRING

This operator can be wired for either 120 Vac or 240 Vac or a solar panel (not provided). Follow the directions according to your application. For dual gate applications, power will have to be connected to each operator. Main power supply and control wiring **MUST** be run in separate conduits.

NOTE: If using an external receiver use shielded wire for the connections and mount the receiver away from the operator to avoid interference with the operator.


AMERICAN WIRE GAUGE (AWG)	MAXIMUM WIRE LENGTH (120 VAC)	MAXIMUM WIRE LENGTH (240 VAC)
14	130 feet	260 feet
12	205 feet	410 feet
10	325 feet	650 feet
8	520 feet	1040 feet
6	825 feet	1650 feet
4	1312 feet	2624 feet

NOTE: Use copper conductors **ONLY**.

240 VAC ONLY


If using the 240 Vac option a heater cannot be used. The accessory outlet is disabled and cannot be used with the 240 Vac option.

- 1 Remove the outlet housing from the electrical box by removing the screws (2).
- 2 Pull the outlet housing out and locate the power wiring connector on the EMI board.
- 3 Unplug the power wiring connector from the 120 Vac socket (factory default location) and plug it into the 240 Vac socket.
- 4 Replace the outlet housing by securing with the screws. The operator is now set for 240 Vac operation.



120 VAC AND 240 VAC

- 1 Turn off the AC power from the main power source circuit breaker.
- 2 Run the AC power wires to the operator.
- 3 Remove the junction box cover.
- 4 Connect the green wire to the earth ground rod and AC ground using a wire nut. **NOTE:** The earth ground rod can be grounded to the chassis.
- 5 Connect the white wire to NEUTRAL using a wire nut.
- 6 Connect the black wire to HOT using a wire nut.
- 7 Replace the junction box cover. Ensure the wires are not pinched.



POWER WIRING CONTINUED...

SOLAR PANEL(S)

NOT PROVIDED. SEE ACCESSORIES.

Solar Application requirements:

- A minimum of four 10W solar panels (Model SOLPNL10W12V). Configuration of two sets of two 10W paralleled panels put in series.
- A maximum of six 10W solar panels (Model SOLPNL10W12V). Configuration of three sets of two 10W paralleled panels put in series.
- Battery Tray (Model K10-36183).
- Solar Battery Harness (Model K94-36596).
- Two 33AH batteries, the standard 7AH batteries cannot be used.
- A heater cannot be used with a solar application.

For solar applications DO NOT use the expansion board and the wireless dual gate feature. These features will substantially decrease the cycle rate and standby time of the operator. We recommend LiftMaster low power draw accessories to minimize power draw, refer to accessory page.



The solar panel(s) must be located in an open area clear of obstructions and shading for the entire day. The gate operator is not supported in northern climates where temperatures reach below -4°F. This is due to cold weather and a reduced number of hours of sunlight during the winter months. Cycle rate may vary from solar chart for areas that reach below 32°F. Solar panels should be cleaned on a regular basis for best performance to ensure proper operation.

NOTE: Input solar power is 24 Vdc at 60 watts maximum.

- 1 Locate the J15 plug on the control board and unplug it from the control board (it will not be used).
- 2 Install the new 33AH batteries using the tray as shown.
- 3 Connect the white jumper between the positive (+) terminal of one battery to the negative terminal (-) of the other battery.
- 4 Route the battery wires (the longer set of wires) from the J15 plug (new wire harness) through the lower, right, rear knockout (KO) in the electrical box. Use the included adhesive wire clamps to route the wires up the right side of the operator frame. Connect the red wire to the positive (+) terminal of one battery. Connect the black wire to the negative (-) terminal of the other battery.
- 5 Connect the red wire (+) from one solar panel to the black wire (-) of the other solar panel.
- 6 Connect the shorter red wire (+) from the J15 plug (new wire harness) labeled DC Power to the red wire on one solar panel. Connect the shorter black (-) wire from the J15 plug (new wire harness) labeled DC Power to the black wire from the other solar panel.
- 7 Plug the J15 plug (new wire harness) into the J15 input on the control board.
NOTE: You may see a small spark when plugging the J15 plug into the board.


Proceed to the Dual Gate section (if applicable) or proceed to the Adjustment section.

NUMBER OF CYCLES PER DAY (SOLAR)				
Swing Gate Installation (12 ft. 800 lb. gate)	ACCESSORY POWER DRAW (mA)	ZONE 1	ZONE 2	ZONE 3
		(6 Hrs sunlight/day)	(4 Hrs sunlight/day)	(2 Hrs sunlight/day)
		33AH Batteries Required (2)	33AH Batteries Required (2)	33AH Batteries Required (2)
40W SOLAR PANEL	0	106	61	22
	50	85	42	N/A
	100	64	24	N/A
	300	N/A	N/A	N/A
	500	N/A	N/A	N/A
60W SOLAR PANEL	0	172	101	39
	50	149	80	21
	100	126	60	N/A
	300	42	N/A	N/A
	500	N/A	N/A	N/A



AC POWER SWITCH

The AC Power switch on the operator will turn the incoming 120/240 Vac power ON or OFF. The operator's AC Power switch **ONLY** turns off AC power to the control board and **DOES NOT** turn off battery power.




CONNECT BATTERIES

7AH BATTERIES

The batteries are charged in the circuit by the integrated transformer. The batteries are for battery backup.

- 1 Turn OFF AC power to the operator.
- 2 Unplug the J15 plug labeled BATT on the control board by squeezing the plug and pulling it from the control board. This disconnects the ac/dc power to the control board.
- 3 Connect a jumper between the positive (+) terminal of one battery to the negative terminal (-) of the other battery.
- 4 Connect the red wire from the J15 plug to the positive (+) terminal of the battery.
- 5 Connect the black wire from the J15 plug to the negative (-) terminal of the battery.
- 6 Plug the J15 plug back into the control board. This will power up the control board. **NOTE:** You may see a small spark when plugging the J15 plug into the board.
- 7 Turn ON AC power to the operator.
- 8 Turn ON the AC power switch on the operator.




CONNECT BATTERIES CONTINUED...

33AH BATTERIES

The batteries are charged in the circuit by the integrated transformer. The batteries are for battery backup or solar installation. The 33AH application requires the 33AH wire harness (Model K94-36596) and an additional battery tray (Model K10-36183) to allow more space in the enclosure. The heater option cannot be used with the 33AH battery application.

- 1 Locate the J15 plug on the control board and disconnect it.
- 2 Connect the white jumper from the 33AH wire harness kit between the positive (+) terminal of one battery and the negative (-) terminal of the other battery.
- 3 Connect one end of the red (+) wire from the 33AH wire harness kit to the red wire from the J15 plug as shown. Connect the other end of the red (+) wire to the positive (+) terminal on the battery as shown.
- 4 Connect one end of the black (-) wire from the 33AH wire harness kit to the black wire from the J15 plug as shown. Connect the other end of the black (-) wire to the negative (-) terminal on the battery as shown.
- 5 Turn ON AC power to the operator.
- 6 Turn ON the AC power switch on the operator.
- 7 Reconnect the J15 plug to the control board. **NOTE:** You may see a small spark when plugging the J15 plug into the board.



DUAL GATES ONLY

There are two options for dual gate communication: wired or wireless. Follow the directions according to your application. Do not use wired and wireless communication simultaneously. Wired dual gate applications will have a longer battery standby time than wireless applications.

WIRELESS DUAL GATES

TO ACTIVATE THE WIRELESS FEATURE:


- 1 Choose an operator to be the network primary operator. All wireless accessories will need to be programmed to the primary operator. **NOTE:** We recommend that all accessories and board configurations are set on the primary operator.
- 2 Press and release the LEARN RADIO button on the primary operator. The green XMITTER LED will light.
- 3 Press and release the LEARN RADIO button again on the primary operator. The NETWORK LED will light.
- 4 Press and release the OPEN test button to assign this operator as network primary.
- 5 Press and release the LEARN RADIO button on the second operator. The green XMITTER LED will light.
- 6 Press and release the LEARN RADIO button again on the second operator. The NETWORK LED will light.
- 7 Press and release the CLOSE test button to assign this operator as network second.

Both operators will beep and the NETWORK LEDs will turn off indicating programming is successful.

TO DEACTIVATE THE WIRELESS FEATURE:

- 1 Press and release the LEARN RADIO button on either operator. The green XMITTER LED will light.
- 2 Press and release the LEARN RADIO button again on the same operator. The yellow NETWORK LED will light.
- 3 Press and hold the LEARN RADIO button for 5 seconds. The yellow NETWORK LED will blink (operator will beep) then turn off indicating successful deactivation.

Repeat the steps for the other operator.



DUAL GATES ONLY CONTINUED...

WIRED DUAL GATES


Before digging, contact local underground utility locating companies. Use PVC conduit to prevent damage to cables.

Disconnect ALL power to the operator and unplug the J15 plug from the control board.

- 1 Trench across driveway to bury the extension cable.
- 2 Connect the wires from the extension cable to the Comm Link terminals on the primary gate operator control board. **NOTE:** We recommend that all accessories and board configurations are set on the primary operator.
- 3 Route the extension cable to the secondary gate operator's control board.
- 4 Connect the wires from the extension cable to the Comm Link terminals on the secondary control board (Comm Link A to Comm Link A and Comm Link B to Comm Link B).

Connect ALL power to the operator and plug the J15 plug into the control board.

DUAL GATE WIRE TYPE (SHIELDED TWISTED PAIR CABLE)	
22AWG up to 200 feet (61 m)	18AWG - 200-1000 feet (61-305 m)
Wire must be rated at 30 Volt minimum	



BIPART DELAY/SYNCHRONIZED CLOSE

The LOCK/BIPART DELAY switch is used only with dual gate applications and serves two functions:


- **BIPART DELAY**

SWING GATE APPLICATIONS: The BIPART DELAY is used in applications where a mag-lock, solenoid lock, or decorative overlay would require one gate to close before the other. The operator with the LOCK/BIPART DELAY switch ON will delay from the close limit when opening and be the first to close from the open limit.

SLIDE GATE APPLICATIONS: Not applicable, set to OFF.

- **SYNCHRONIZED CLOSE**

The BIPART DELAY is also used in applications where one gate travels a longer distance than the other. To synchronize the closing of the gates, set the LOCK/BIPART DELAY switch to ON for both operators.



LIMIT AND FORCE ADJUSTMENT

⚠ WARNING

To reduce the risk of SEVERE INJURY or DEATH:

- Without a properly installed safety reversal system, persons (particularly small children) could be SERIOUSLY INJURED or KILLED by a moving gate.
- Too much force on gate will interfere with proper operation of safety reversal system.
- NEVER increase force beyond minimum amount required to move gate.
- NEVER use force adjustments to compensate for a binding or sticking gate.
- If one control (force or travel limits) is adjusted, the other control may also need adjustment.
- After ANY adjustments are made, the safety reversal system MUST be tested. Gate MUST reverse on contact with a rigid object.
- Keep clear of moving arm while setting limits.

INTRODUCTION

Your operator is designed with electronic controls to make travel limit and force adjustments easy. The adjustments allow you to program where the gate will stop in the open and close position. The electronic controls sense the amount of force required to open and close the gate. The force is adjusted automatically when you program the limits but should be fine tuned using the REVERSAL FORCE dial on the control board (refer to Fine Tune the Force section) to compensate for environmental changes. The limit setup LEDs (located next to the SET OPEN and SET CLOSE buttons) indicate the status of the limits, refer to the table to the right.

The limits can be set using the control board (below) or a remote control (refer to Limit Setup with a Remote Control in the Additional Features section). Setting the limits with a remote control requires a 3-button remote control programmed to OPEN, CLOSE, and STOP.

NOTE: The Test Buttons on the control board will not work until the limits have been set.

INITIAL LIMITS AND FORCE ADJUSTMENT


For dual gate applications the limits will have to be set for each operator. The gate MUST be attached to the operator before setting the limits and force.

- 1 Press and release the SET OPEN and SET CLOSE buttons simultaneously to enter limit setting mode.
- 2 Press and hold one of the MOVE GATE buttons to move the gate to the open or close limit.
- 3 Press and release the SET CLOSE or SET OPEN button depending on which limit is being set.
- 4 Press and hold one of the MOVE GATE button to move the gate to the other limit.
- 5 Press and release the SET CLOSE or SET OPEN button depending on which limit is being set.
- 6 Cycle the gate open and close. This automatically sets the force.

When limits are set properly the operator will automatically exit limit setting mode.

LIMIT SETUP LEDS

SET OPEN LED	SET CLOSE LED	OPERATOR MODE	EXPLANATION
BLINKING	BLINKING	NORMAL MODE	Limits are not set.
OFF	OFF	NORMAL MODE	Limits are set.
BLINKING	BLINKING	LIMIT SETTING MODE	Limits are not set.
BLINKING	ON	LIMIT SETTING MODE	Open limit is not set.
ON	BLINKING	LIMIT SETTING MODE	Close limit is not set.
ON	ON	LIMIT SETTING MODE	Limits are set.



ADJUSTMENT


LIMIT AND FORCE ADJUSTMENT + OBSTRUCTION TEST

FINE TUNE THE FORCE

The FORCE DIAL on the control board is used for fine tuning the force in cases where wind or environmental changes may affect the gate travel.

Based on the length and weight of the gate it may be necessary to make additional force adjustments. The force setting should be high enough that the gate will not reverse by itself nor cause nuisance interruptions, but low enough to prevent serious injury to a person. The force setting is the same for both the open and close gate directions.

- 1 Open and close the gate with the TEST BUTTONS.
- 2 If the gate stops or reverses before reaching the fully open or closed position, increase the force by turning the force control slightly clockwise.
- 3 Perform the "Obstruction Test" after every force setting adjustment (see below).




ADJUST THE LIMITS

If the limits have already been set the operator will exit the limit setting mode after resetting each limit. Each limit is set separately by following steps 1-3 of the Initial Limit and Force Adjustment section, on page 26.

ERASE LIMITS


- 1 To erase the limits, press and hold the SET OPEN and SET CLOSE buttons simultaneously (5 seconds) until both the SET OPEN and SET CLOSE LEDs blink rapidly and the operator beeps.
- 2 Release the buttons and the SET OPEN and SET CLOSE LEDs will blink slowly indicating the limits will need to be set.



OBSTRUCTION TEST

The operator is equipped with an automatic obstruction sensing feature. If the gate encounters an obstruction during motion, the operator will automatically reverse direction of the gate for a short time and then stop the gate. After any adjustments are made, test the operator:

- 1 Open and close the gate with the TEST BUTTONS, ensuring that the gate is stopping at the proper open and close limit positions.
- 2 Place a solid object between the open gate and a rigid structure. Ensure that the gate, the solid object, and the rigid structure can withstand the forces generated during this obstruction test.
- 3 Run the gate in the close direction. The gate should stop and reverse upon contact with the solid object. If the gate does not reverse off the solid object, reduce the force setting by turning the force control slightly counter-clockwise. The gate should have enough force to reach both the open and close limits, but MUST reverse after contact with a solid object.
- 4 Repeat the test for the open direction.




PROGRAMMING

REMOTE CONTROLS + ERASE ALL CODES

REMOTE CONTROLS (NOT PROVIDED)

A total of 50 Security+ 2.0™ remote controls and 2 keyless entries (1 PIN for each keyless entry) can be programmed to the operator. When programming a third keyless entry to the operator, the first keyless entry will be erased to allow the third keyless entry to be programmed. When the operator's memory is full it will exit the programming mode and the remote control will not be programmed. The memory will need to be erased before programming any additional remote controls. **NOTE:** If installing an 86LM to extend the range of the remote controls DO NOT bend the antenna.

There are 3 different options for programming the remote control depending on how you would like the remote control to function. Choose a programming option:




OPTION	DESCRIPTION	PROGRAMMING STEPS
Single button as OPEN only	Program a single button on the remote control for open only. The Timer-to-Close can be set to close the gate.	<ol style="list-style-type: none"> 1. Press and release the LEARN button (operator will beep and green XMITTER LED will light). 2. Press the OPEN button. 3. Press the remote control button that you would like to program.
Single button (SBC) as OPEN, CLOSE, and STOP	Program one remote control button as an open, close, and stop.	<ol style="list-style-type: none"> 1. Press and release the LEARN button (operator will beep and green XMITTER LED will light). 2. Press the remote control button that you would like to program.
Three separate buttons as OPEN, CLOSE, and STOP	Program each remote control button as an open, close, and stop.	<ol style="list-style-type: none"> 1. Press and release the LEARN button (operator will beep and green XMITTER LED will light). 2. Press the OPEN, CLOSE, or STOP button, depending on the desired function. 3. Press the remote control button that you would like to program.

The operator will automatically exit learn mode (operator will beep and green XMITTER LED will go out) if programming is successful. To program additional Security+ 2.0™ remote controls or remote control buttons, repeat the programming steps above.

ERASE ALL CODES

- 1 Press and release the LEARN RADIO button (operator will beep and green XMITTER LED will light).
- 2 Press and hold the LEARN RADIO button again until the green XMITTER LED flashes and then release the button (approximately 6 seconds). All remote control codes are now erased.



NOTICE: To comply with FCC and/or Industry Canada (IC) rules, adjustment or modifications of this transceiver are prohibited. THERE ARE NO USER SERVICEABLE PARTS. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device complies with Part 15 of the FCC rules and IC RSS-210. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
This Class B digital apparatus complies with Canadian ICES-003.

AVIS : Les règles de la FCC et/ou d'Industrie Canada (IC) interdisent tout ajustement ou toute modification de ce récepteur. IL N'EXISTE AUCUNE PIÈCE SUSCEPTIBLE D'ÊTRE ENTRETENUE PAR L'UTILISATEUR. Tout changement ou toute modification non expressément approuvé par la partie responsable de la conformité peut avoir pour résultat d'annuler l'autorité de l'utilisateur de faire fonctionner l'équipement.
Cet appareil est conforme aux dispositions de la partie 15 du règlement de la FCC et de la norme IC RSS-210. Son utilisation est assujettie aux deux conditions suivantes : (1) ce dispositif ne peut causer des interférences nuisibles, et (2) ce dispositif doit accepter toute interférence reçue, y compris une interférence pouvant causer un fonctionnement non souhaité.
Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

FINISH INSTALLATION


INSTALL THE COVER

INSTALL THE COVER

The operator cover consists of two pieces: a rear cover and a front cover. The front cover can easily be removed to access the electrical box. To access the reset switch slide the access door up. The front cover and access door can be locked with the key.

TO INSTALL THE COVER


- 1 Remove the operator arm from the output shaft by releasing the handle.
- 2 Align the tabs on the rear cover with the slots on the chassis and place the cover over the operator.
- 3 Secure both sides of the rear cover to the chassis with two 5/16-18 hex bolts and washers.
- 4 Reattach the operator arm to the output shaft (making sure the pin fits into the slot) and secure by pushing the handle down.
- 5 Place the operator arm cover over the operator arm and secure.
- 6 Align the front cover with the back cover, making sure the grooves line up.
- 7 Secure the front cover to the chassis with two 5/16-18 hex bolts and washers.
- 8 Secure the front cover to the rear cover using the 5/16-18 screw.



TO LOCK THE ACCESS DOOR

From the factory the access door for the reset switch will not be locked. To lock the access door follow the steps below:

- 1 Locate the lock tab on the back of the front cover and remove the screw securing the tab to the cover.
- 2 Turn the tab 180 degrees, then secure with the screw. The access door can now be locked.



The basic installation is complete.

OPERATION

MANUAL DISCONNECT + RESET SWITCH + OPERATOR ALARM + REMOTE CONTROL + HEATER (IF APPLICABLE)

MANUAL DISCONNECT

Press the reset switch to RESET/DISCONNECT. Release the handle on the operator arm to allow the gate to be opened and closed manually. On a dual gate application the handle must be released on both operators. To resume normal function tighten the handle by pushing it down.

RESET SWITCH

The reset switch is located on the front of the operator and serves several functions. Toggling the reset switch will stop a moving gate during a normal open/close cycle, like a stop button. The operator does not need to be reset after doing this. The reset switch will disable the gate in the present position and will energize the solenoid lock for two minutes and disable the maglock for two minutes.

OPERATOR ALARM

If a contact sensor detects an obstruction twice consecutively the alarm will sound (up to 5 minutes) and the operator will need to be reset. If a command is given after the initial 5 minutes the operator will beep. The operator alarm will beep 3 times with a command if the battery is low.

When the inherent force of the operator (RPM/current sensor) detects the following (twice consecutively) the alarm will sound (up to 5 minutes) and the operator will need to be reset:

- A. The operator arm or gate is incorrectly installed.
- B. The gate does not meet specifications.
- C. Gate hinges are too tight or broken and the gate is not moving freely.
- D. The gate is moving and a car pushes the gate.
- E. A foreign object is on the gate frame while the gate is moving.
- F. The gate hits the driveway or curb and gets stuck or bent in an awkward position.

Remove any obstructions. Press the reset button to shut off the alarm and reset the operator. After the operator is reset, normal functions will resume.

REMOTE CONTROL

SINGLE BUTTON CONTROL (SBC) FUNCTIONALITY




Once the remote control has been programmed the operator will operate as follows:

When gate is in the closed position, activation of the remote control button will open the gate. During the open cycle another activation of the remote control will stop the gate and the next activation of the remote control will close the gate.

When the gate is in the open position, activation of the remote control button will close the gate. If the remote control is activated while the gate is closing, the gate will stop and the next activation will open the gate.

HEATER (IF APPLICABLE)

The operator may have a heater installed, depending on the model purchased. The heater must be powered by 120 Vac ONLY. If the heater switch is left in the "ON" position, the heater will turn on at approximately 40°F (4°C) and will turn off at approximately 60°F (16°C).



ADDITIONAL FEATURES

GATE OPERATOR SETUP EXAMPLES

GATE OPERATOR SETUP EXAMPLES

The following are example setups for the gate operator. Your specific site requirements may be different. Always setup the operator system to the site requirements, including all necessary secondary entrapment protection systems. **NOTE:** We recommend that all accessories and board configurations are set on the primary operator.

RESIDENTIAL SMALL: One to four residential homes sharing a gated entrance/exit, allowing vehicle access trumps security concerns

RESIDENTIAL LARGE: A residential community (more than four homes) having one or more gated entrances/exits, allowing vehicle access trumps security concerns

COMMERCIAL: Business site where security (gate closed) is important


INDUSTRIAL: Large business site where security is required

Setting	RESIDENTIAL SMALL	RESIDENTIAL LARGE	COMMERCIAL	INDUSTRIAL
Quick Close switch setting	Normally set to OFF. Normal gate close (timer or control).	Normally set to OFF. Normal gate close (timer or control).	Normally set to OFF. Normal gate close (timer or control).	Set to ON, so that gate closes immediately after vehicle passes CLOSE EYES/Interrupt loop.
AC Fail Open switch setting	Normally set to BATT. Run on battery if AC power fails.	Normally set to BATT. For local jurisdiction requirement, set to OPEN so that the gate will open approximately 15 seconds after AC power fail.	Normally set to BATT. Run on battery if AC power fails.	Normally set to BATT. Run on battery if AC power fails.
Low Battery switch setting	Normally set to OPEN. If powered from battery and battery is low, gate stays open.	Normally set to OPEN. If powered from battery and battery is low, gate stays open.	Normally set to CLOSE. If powered from battery and battery is low, gate stays close.	Normally set to CLOSE. If powered from battery and battery is low, gate stays close.
Anti-Tail switch setting	Normally set to OFF. CLOSE EYES/Interrupt loop reverses a closing gate.	Normally set to OFF. CLOSE EYES/Interrupt loop reverses a closing gate.	Set to ON. In attempt to prevent vehicle tail-gating, CLOSE EYES/Interrupt loop pauses a closing gate.	Set to ON. In attempt to prevent vehicle tail-gating, CLOSE EYES/Interrupt loop pauses a closing gate.
Bipart Delay switch setting	For DUAL-GATE site, set to ON for gate that delays upon opening	For DUAL-GATE site, set to ON for gate that delays upon opening	For DUAL-GATE site, set to ON for gate that delays upon opening	For DUAL-GATE site, set to ON for gate that delays upon opening
Aux Relay Out – Open Limit Switch	Typically not required.	Use with SAMS (Sequence Access Management System)	1) Use with SAMS (Sequence Access Management System) 2) Connect "Gate Open" indicator (e.g. light)	1) Use with SAMS (Sequence Access Management System) 2) Connect "Gate Open" indicator (e.g. light)
Aux Relay Out – Close Limit Switch	Typically not required.	Typically not required.	Connect "Gate Close/Secure" indicator (e.g. light)	Connect "Gate Close/Secure" indicator (e.g. light)
Aux Relay Out – Gate Motion	Attach alert signal (audible or visual alert system)	Attach alert signal (audible or visual alert system)	Attach alert signal (audible or visual alert system)	Attach alert signal (audible or visual alert system)
Aux Relay Out – Pre-Motion Delay (Expansion Board Inputs)	Attach alert signal (audible or visual alert system)	Attach alert signal (audible or visual alert system)	Attach alert signal (audible or visual alert system)	Attach alert signal (audible or visual alert system)
Aux Relay Out – Power	Attach visual alert to know when system is charging batteries (i.e. not running on batteries)	Attach visual alert to know when system is charging batteries (i.e. not running on batteries)	Attach visual alert to know when system is charging batteries (i.e. not running on batteries)	Attach visual alert to know when system is charging batteries (i.e. not running on batteries)
Aux Relay Out – Tamper (Slide Gates Only)	Attach alert signal (audible or visual alert system) to indicate if gate is manually tampered with by being pushed off of close limit	Attach alert signal (audible or visual alert system) to indicate if gate is manually tampered with by being pushed off of close limit	Attach alert signal (audible or visual alert system) to indicate if gate is manually tampered with by being pushed off of close limit	Attach alert signal (audible or visual alert system) to indicate if gate is manually tampered with by being pushed off of close limit
Cycle Quantity Feedback	Use during servicing only to determine operator cycles	Use during servicing only to determine operator cycles	Use during servicing only to determine operator cycles	Use during servicing only to determine operator cycles
Fire Dept Open input	Typically not required.	Connect emergency access system (Knox box switch, SOS system, etc.)	Typically not required.	Typically not required.
Heater Option	Suggested use if outside temperature remain below 0°F (-18°C).	Suggested use if outside temperature remain below 0°F (-18°C).	Suggested use if outside temperature remain below 0°F (-18°C).	Suggested use if outside temperature remain below 0°F (-18°C).

ADDITIONAL FEATURES

CONTROL BOARD OVERVIEW

- 1 **SET OPEN Button:** The SET OPEN button sets the OPEN limit. See Adjust Limits section.
 - 2 **SET CLOSE Button:** The SET CLOSE button sets the CLOSE limit. See Adjust Limits section.
 - 3 **MOVE GATE Buttons:** The MOVE GATE buttons will either open or close the gate when the operator is in Limit setting mode. See Adjust Limits section.
 - 4 **BIPART DELAY Switch:** The LOCK/BIPART DELAY switch is used only for dual gates. See Bipart Delay section.
 - 5 **LEARN RADIO Button:** The LEARN RADIO button is for programming remote controls and the network.
 - 6 **TIMER-TO-CLOSE dial:** The TIMER-TO-CLOSE (TTC) dial can be set to automatically close the gate after a specified time period. The TTC is factory set to OFF. If the TTC is set to the OFF position, then the gate will remain open until the operator receives another command from a control. Rotate the TIMER-TO-CLOSE dial to the desired setting. The range is 0 to 180 seconds, 0 seconds is OFF.
- NOTE:** Any radio command, single button control, or CLOSE command on the control board prior to the TTC expiring will close the gate. The TTC is reset by any signals from the open controls, loops, close edges, and close photoelectric sensors (IR's).
- 7 **REVERSAL FORCE dial:** The REVERSAL FORCE dial adjusts the force. See Force Adjustment section.
 - 8 **TEST BUTTONS:** The TEST BUTTONS will operate the gate (OPEN, STOP and CLOSE).
 - 9 **STATUS LEDs:** The STATUS LEDs are diagnostic codes for the operator. See Status LED Chart in the Troubleshooting section.
 - 10 **Firmware Version:** To check the firmware version for the main board:
 1. Locate the yellow diagnostic LED on the main control board.
 2. Disconnect AC/DC power to the main control board for 15 seconds.
 3. Connect power. The yellow diagnostic LED will flash rapidly, then stop, then flash the version number, then stop, then flash the revision number (for example: For version 5.1 the LED will flash rapidly, stop, flash 5 times, stop, then flash once).



ADDITIONAL FEATURES


WIRING ACCESSORIES TO THE CONTROL BOARD

WIRING ACCESSORIES TO THE CONTROL BOARD

Refer to the chart below and the corresponding image for a description of the control board inputs.

A	Open Input (& common) (3-Button Control Station, 4 terminals total)	Open command - opens a closed gate. Hard open (maintained switch overrides external safeties and resets alarm condition) If maintained, pauses Timer-to-Close at OPEN limit. Opens a closing gate and holds open an open gate (within line-of-sight).
B	Close Input (& common) (3-Button Control Station, 4 terminals total)	Close command - closes an open gate. Hard close (maintained switch overrides external safeties and resets alarm condition within line-of-sight)
C	Stop Input (& common) (3-Button Control Station, 4 terminals total)	Stop command - stops a moving gate. Hard stop (maintained switch overrides Open and Close commands and resets alarm condition) If maintained, pauses Timer-to-Close at OPEN limit. Overrides Open and Close commands (within line-of-sight).
D	Fire Dept Open Input (2 terminals)	Acts as hard open. Maintained input overrides (ignores) external safeties (photoelectric sensor and edge), pauses Timer-to-Close momentary input logic as single button control and safeties remain active, re-enables Timer-to-Close.
E	Exit Loop Input (2 terminals)	Open command - opens a closed gate. Soft open (maintained switch does not override external safeties and does not reset alarm condition) If maintained, pauses Timer-to-Close at OPEN limit. Opens a closing gate and holds open an open gate.
F	Shadow Loop Input (2 terminals)	Loop detector connection when loop is positioned under gate. - Holds open gate at open limit - Disregarded during gate motion - Pauses Timer-to-Close at OPEN limit
G	CLOSE EYES/Interrupt Loop Input (2 terminals)	CLOSE EYES/Interrupt Loop detector connection when loop is along the side of the gate. - Holds open gate at open limit - Stops and reverses a closing gate to open limit - Pauses Timer-to-Close at OPEN limit Close Direction Photoelectric Sensors, IR, or Infra-red detector wired to CLOSE EYES Input, disregarded during gate opening. Pulsed Photoelectric Sensors = monitored device putting out a pulse train when unblocked. Photoelectric Sensors, IR, Infra-red detector, normally open contact, contact opens fully with obstruction.
H	Close Edge (2 terminals)	Close Direction Edge Sensor to Close Safety Input, disregarded during gate opening
I	Open Eyes/Edge (2 terminals)	Open Direction Photoelectric Sensors, IR, Infra-red detector wired or Edge Sensor to Close Entrapments Input, disregarded during gate closing, Pulsed Photoelectric Sensors = monitored device putting out a pulse train when unblocked. Photoelectric Sensors, IR, Infra-red detector, edge sensor = normally open contact, contact reverses for 2 seconds with obstruction.

(right side of control board)



J	Comm Link (2 terminals)	Commercial Link (two wires) - connects two operators together (primary-secondary wired connection)
K	Lock Outputs: Maglock (2 terminals, N.C. and COM)	Relay contact output, Normally - closed (N.C.) output for maglocks Relay activates prior to motor activation and during motor run. Relay is off when motor is off.
L	Solenoid Lock & Common (2 terminals, N.O. and COM)	Normally - open (N.O.) output for solenoid locks Relay activates prior to motor activation and during motor run. Relay is off when motor is off.
M	Accessory Power Out Switched, (2 terminals)	Switched ON with gate motion (stays on 5 seconds after motion)
N	Accessory Power Out Un-switched, (2 terminals)	24 Vdc voltage out to power accessories, always ON

ADDITIONAL FEATURES

EXPANSION BOARD OVERVIEW

EXPANSION BOARD OVERVIEW

1 QUICK CLOSE Switch:

OFF: No change to the gate's normal operation.
ON: When CLOSE EYES/Interrupt loop is deactivated it causes an opening or a stopped gate to close (ignores the Timer-to-Close).

2 AC FAIL OPEN/BATT Switch:

OPEN: Loss of AC power will cause the gate to open approximately 15 seconds after AC power fail and remain OPEN until AC power is restored (enabling the Timer-to-Close).
BATT: With loss of AC power, gate will remain in present position and operator is powered from batteries.

3 LOW BATT/EXIT LOOP FAIL Switch:

- When AC power is OFF and battery voltage is low the gate will latch at a limit until AC power is restored or batteries voltage increases.
- Option select switch set to OPEN forces gate to latch at the OPEN limit if it is at the OPEN limit or on next open command until AC power is restored or battery voltage increases.
- Option select switch set to CLOSE forces gate to latch at CLOSE limit if at CLOSE limit or on next CLOSE command until AC power restored or battery voltage increases.
- Constant pressure on a hard command input overrides to open or close the gate.
- Low battery detect point = 22 V
- When set to OPEN, if the EXIT plug-in loop detector detects a fault, then the gate will open and remain open until fault is cleared. When set to CLOSE, then plug-in EXIT loop detector faults are ignored (EXIT loop is faulted and inoperative).

4 ANTI-TAIL OPEN/CLOSE SELECTION switch:

OFF: When CLOSE EYES/Interrupt loop is activated it causes a closing gate to stop and reverse.
ON: When CLOSE EYES/Interrupt loop is activated it causes a closing gate to pause. Once the vehicle is clear the gate will continue to close.

5 AUX RELAY switches: Set the AUX RELAY switches as needed to obtain the desired function as shown in the table below.

AUX RELAY SETTING	SWITCH SETTINGS			AUX RELAY 1	AUX RELAY 2
	1	2	3		
Off (no feature selected)	OFF	OFF	OFF	Relay always off. Use this Aux Relay setting to conserve battery power.	
Open Limit Switch	OFF	OFF	ON	Energizes at open limit. Use with SAMS (Sequenced Access Management System, jointly with barrier gate)	
Close Limit Switch	OFF	ON	OFF	Energizes when not at close limit. For an additional audible or visual display, connect an external light (low voltage).	
Gate Motion	OFF	ON	ON	Energizes when motor is on (gate in motion). For an additional audible or visual display, connect an external buzzer or light (low voltage).	
Pre-Motion Delay	ON	OFF	OFF	Energizes 3 seconds before gate motion and remains energized during gate motion. The onboard alarm will sound. For an additional audible or visual display, connect an external buzzer or light (low voltage).	Energizes 3 seconds before gate motion and remains energized during gate motion. For an additional audible or visual display, connect an external buzzer or light (low voltage).
Power	ON	ON	OFF	Energizes when AC power or solar power is present. There is approximately a 10-12 second delay before relay cutoff, after AC shutdown.	Energizes when on battery power. There is approximately a 10-12 second delay before relay cutoff, after AC shutdown.
Tamper	ON	OFF	ON	Energizes if gate is manually tampered with by being pushed off of close limit. For an additional audible or visual display, connect an external buzzer or light (low voltage).	Energizes if gate is manually tampered with by being pushed off of close limit. For an additional audible or visual display, connect an external buzzer or light (low voltage).
Cycle Quantity Feedback*	ON	ON	ON	The OPEN, CLOSE, and STOP LEDs will blink out the cycle count (cycle count is stored on the control board). See below.	Not used.

CYCLE COUNT

* First, note the current Aux Relay switch positions. To determine the actual cycles that the gate operator has run (in thousands), set all three Aux Relay switches to the ON setting for Aux Relay 1. The Expansion Board's OPEN, CLOSE, and STOP LEDs will blink out the cycle count, with OPEN LED blinking 1000's, CLOSE LED blink 10,000's, STOP LED blinking 100,000's, and simultaneously all three LED's blink 1,000,000's (e.g. Open blinks 3 times, Close blinks 6 times, and Stop blinks once. Cycle count is 163,000.). Cycle count displayed is between 1,000 and 9,999,000 cycles. After servicing, set Aux Relay switches back to their appropriate positions. Cycle count cannot be reset or changed. If under 1,000 cycles the Open, Close, and Stop LEDs will turn on for 10 seconds, then turn off.


NOTE: The expansion board will flash the cycle count 3 times then all the LEDs will turn on solid for 10 seconds then turn off.

CAUTION

To AVOID damaging the circuit board, relays or accessories, DO NOT connect more than 42 Vdc (32 Vac) to the AUX relay contact terminal blocks.

6 Firmware Version: To check the firmware version for the expansion board:

- Locate the OPEN, CLOSE, STOP, and DATA LEDs on the expansion board.
- Disconnect AC/DC power to the main control board for 15 seconds.
- Connect power. The OPEN, CLOSE, and STOP LEDs will flash in sequence until the main control board firmware revision is displayed. When the green DATA LED glows solid the OPEN LED will flash the version number, then stop, then the CLOSE LED will flash the revision number (for example: For version 5.1 when the green DATA LED is solid the OPEN LED will flash 5 times, then stop, then the CLOSE LED will flash once).




ADDITIONAL FEATURES

WIRING ACCESSORIES TO THE EXPANSION BOARD

WIRING ACCESSORIES TO THE EXPANSION BOARD


Refer to the chart below and the corresponding image for a description of the expansion board inputs.

A	Open Input (& common) (3-Button Control Station, 4 terminals total)	Open command - opens a closed gate. Soft close (maintained switch does not override external safeties and does not reset alarm condition) If maintained, pauses Timer-to-Close at OPEN limit. Opens a closing gate and holds open an open gate.
B	Close Input (& common) (3-Button Control Station, 4 terminals total)	Close command - closes an open gate. Soft close (maintained switch does not override external safeties and does not reset alarm condition)
C	Stop Input (& common) (3-PB station, 4 terminals total)	Stop command - stops a moving gate. Hard stop (maintained switch overrides Open and Close commands and resets alarm condition) If maintained, pauses Timer-to-Close at OPEN limit. Overrides an Open or Close command.
D	Single Button Control, SBC (2 terminals)	Gate command sequence - Open, Stop, Close, Stop, ... Soft Open, Soft Close, Soft Stop (maintained switch does not override external safeties and does not reset alarm condition)
E	Exit Loop Input (2 terminals)	Loop wire connection for plug-in loop detector when loop is inside secured area near gate. Open command - opens a closed gate. Soft open (maintained switch does not override external safeties and does not reset alarm condition) If maintained, pauses Timer-to-Close at OPEN limit. Opens a closing gate and holds open an open gate.
F	Shadow Loop Input (2 terminals)	Loop wire connection for plug-in loop detector when loop is along side gate. - Holds open gate at open - Disregarded at Close limit and during gate motion - Pauses Timer-to-Close at Open Limit
G	Interrupt Loop Input (2 terminals)	Loop wire connection for plug-in loop detector when loop is positioned under gate. - Holds open gate at open - Stops and reverses a closing gate - Pauses Timer-to-Close at Open Limit
H	AUX Relay #1	Normally - open and normally - closed relay contacts to control external devices, Function of relay contact activation determined by AUX Relay #1 option switch settings. (For connection of Class 2, low voltage (42 Vdc [34 Vac] max 5 Amps, power sources only)
I	AUX Relay #2	Normally-open and normally-closed relay contacts to control external devices, Function of relay contact activation determined by AUX Relay #2 option switch settings. (For connection of Class 2, low voltage (42 Vdc [34 Vac] max 5 Amps, power sources only)



D Single Button Control Station


A B C 3-Button Control Station



ADDITIONAL FEATURES

SAMS WIRING WITH RELAYS NOT ENERGIZED + DUAL GATE SETTINGS

SAMS WIRING WITH RELAYS NOT ENERGIZED



DUAL GATE SETTINGS

NOTE: We recommend that all accessories and board configurations are set on the primary operator.

MAIN CONTROL BOARD

FEATURE	PRIMARY OPERATOR	SECONDARY OPERATOR
Timer-to-Close	Set the TTC dial to desired setting	OFF
Bi-Part Delay Switch	Bi-Part Delay: ON (will open last & close first) Tandem Mode: OFF Synchronized Close: ON	Bi-Part Delay: OFF (will open first & close last) Tandem Mode: OFF Synchronized Close: ON

ACCESSORY	PRIMARY OPERATOR	SECONDARY OPERATOR
Remote Controls	Program remote controls 1 to 50 to the primary operator.	Program remote controls 51 to 100 to the secondary operator
LiftMaster Internet Gateway	Program to primary operator.	
Garage Door Monitor	Program to primary operator.	

EXPANSION BOARD

FEATURE	PRIMARY OPERATOR	SECONDARY OPERATOR
QUICK CLOSE Switch	ON	OFF
ANTI-TAIL Switch	ON	OFF
LOW BATT Switch	Battery Fail OPEN: OPEN Battery Fail CLOSE: CLOSE	Battery Fail OPEN: OPEN Battery Fail CLOSE: CLOSE
AC FAIL OPEN/BATT Switch	OPEN	OPEN

ADDITIONAL FEATURES

LIMIT SETUP WITH A REMOTE CONTROL

LIMIT SETUP WITH A REMOTE CONTROL


To set the limits using a remote control, first you will need a 3-button remote control that has been programmed for OPEN, CLOSE, and STOP. Refer to the Programming section.

INITIAL LIMITS AND FORCE ADJUSTMENT

For dual gate applications the limits will have to be set for each operator. The gate **MUST** be attached to the operator before setting the limits and force.

Ensure the gate is closed.

- 1 Press and release the SET OPEN and SET CLOSE buttons simultaneously to enter limit setting mode.
 - 2 Press and hold the OPEN or CLOSE button on the remote control until the gate reaches the desired open position. The gate can be jogged back and forth using the OPEN and CLOSE buttons on the remote control.
 - 3 Once the gate is in the desired open position, press and release the STOP button on the remote control.
 - 4 Press and release the OPEN button on the remote control again to set the open limit.
 - 5 Press and hold the CLOSE or OPEN button on the remote control until the gate reaches the desired close position. The gate can be jogged back and forth using the OPEN and CLOSE buttons on the remote control.
 - 6 Once the gate is in the desired close position, press and release the STOP button on the remote control.
 - 7 Press and release the CLOSE button on the remote control again to set the close limit.
 - 8 Cycle the gate open and close. This automatically sets the force.
- When limits are set properly the operator will automatically exit limit setting mode.



WARNING

To reduce the risk of injury keep clear of moving arm while setting limits.

ADJUST THE LIMITS

If the limits have already been set the operator will exit the limit setting mode after resetting each limit.

Set the Close Limit Only

- 1 Press and release the SET OPEN and SET CLOSE buttons simultaneously to enter limit setting mode.
- 2 Press and hold the CLOSE button on the remote control until the gate reaches the desired close position. The gate can be jogged back and forth using the OPEN and CLOSE buttons on the remote control.
- 3 Once the gate is in the desired close position, press and release the STOP button on the remote control.
- 4 Press and release the CLOSE button on the remote control again to set the close limit.


When the close limit is set properly the operator will automatically exit limit setting mode.

Set the Open Limit Only

- 1 Press and release the SET OPEN and SET CLOSE buttons simultaneously to enter limit setting mode.
- 2 Press and hold the OPEN button on the remote control until the gate reaches the desired open position. The gate can be jogged back and forth using the OPEN and CLOSE buttons on the remote control.
- 3 Once the gate is in the desired open position, press and release the STOP button on the remote control.
- 4 Press and release the OPEN button on the remote control again to set the open limit.

When the open limit is set properly the operator will automatically exit limit setting mode.

3-Button Remote Control programmed for OPEN, CLOSE, and STOP




ADDITIONAL FEATURES

LIFTMASTER INTERNET GATEWAY

To program the operator to the LiftMaster Internet Gateway:

USING THE LEARN BUTTON ON THE OPERATOR'S CONTROL BOARD

- 1 Connect the ethernet cable to the LiftMaster Internet Gateway and the router.
- 2 Connect power to the LiftMaster Internet Gateway.
- 3 Create an online account by visiting www.myliftmaster.com.
- 4 Register the LiftMaster Internet Gateway.
- 5 Use an internet enabled computer or smartphone to add devices. The LiftMaster Internet Gateway will stay in learn mode for three minutes.
- 6 Press the Learn button twice on the primary operator (the operator will beep as it enters learn mode). The LiftMaster Internet Gateway will pair to the operator if it is within range and the operator will beep if programming is successful.



OR

USING THE RESET SWITCH ON THE OPERATOR


- 1 Connect the ethernet cable to the LiftMaster Internet Gateway and the router.
- 2 Connect power to the LiftMaster Internet Gateway.
- 3 Create an online account by visiting www.myliftmaster.com.
- 4 Register the LiftMaster Internet Gateway.
- 5 Use an internet enabled computer or smartphone to add devices. The LiftMaster Internet Gateway will stay in learn mode for three minutes.
- 6 Ensure gate is closed.
- 7 Give the operator an OPEN command.
- 8 Within 30 seconds, when the gate is at the open limit toggle the reset switch 3 times (on primary gate) to put primary operator into High Band Learn Mode (the operator will beep as it enters learn mode). The LiftMaster Internet Gateway will pair to the operator if it is within range and the operator will beep if programming is successful.

The status as shown by the LiftMaster Internet Gateway app will be either "open" or "closed". The gate operator can then be controlled through the LiftMaster Internet Gateway app.

CONTROL BOARD LEDS

The control board is equipped with many LEDs that have a variety of functions. The control board LEDs indicate the status of the operator, assist with programming, and diagnose potential problems with the operator.

NOTE: When cycling or disconnecting power (ac/dc) to the control board, it is recommended that you unplug the J15 plug.



LIMIT SETUP LEDS			
SET OPEN LED	SET CLOSE LED	OPERATOR MODE	EXPLANATION
BLINKING	BLINKING	NORMAL MODE	Limits are not set.
OFF	OFF	NORMAL MODE	Limits are set.
BLINKING	BLINKING	LIMIT SETTING MODE	Limits are not set.
BLINKING	ON	LIMIT SETTING MODE	Open limit is not set.
ON	BLINKING	LIMIT SETTING MODE	Close limit is not set.
ON	ON	LIMIT SETTING MODE	Limits are set.

GREEN XMITTER LED	
XMITTER LED	EXPLANATION
OFF	No remote control activity, normal operation.
ON	Programming mode active.
ON (for 1 second)	Recognized remote control signal.
ON (for a 1/4 of a second)	Unrecognized remote control signal.
ON (8 blinks per second)	Remote controls are being erased.

TROUBLESHOOTING

CONTROL BOARD LEDS CONTINUED...

DIAGNOSTIC CODES LEDS

YELLOW DIAGNOSTIC LED		
# BLINKS	MEANING	CORRECTION
2 BLINKS	<i>ID resistor failure</i>	Check ID resistor wiring, clear limit settings and reset limits
3 BLINKS	<i>Exceeded Maximum Run Timer</i>	Check gate travel, if necessary adjust force setting
5 BLINKS	<i>RPM (obstruction)</i>	Check for obstruction, if necessary adjust force setting
6 BLINKS	<i>Current (obstruction)</i>	Check for obstruction, if necessary adjust force setting
7 BLINKS	<i>Position failure</i>	Check gate travel, clear limit settings and reset limits
12 BLINKS	<i>Loop Error</i>	One of the loops is in error. Refer to the loop detector to determine the error.

RED DIAGNOSTIC LED		
# BLINKS	MEANING	CORRECTION
2 BLINKS	<i>Current Sense</i>	Motor control circuit fault, replace control board
3 BLINKS	<i>FET Failure</i>	Motor control circuit fault, replace control board
4 BLINKS	<i>RAM Failure</i>	Memory failure, replace control board
5 BLINKS	<i>Flash Memory Failure</i>	Memory failure, replace control board
6 BLINKS	<i>EEPROM Failure</i>	Memory failure, replace control board
7 BLINKS	<i>Watchdog Failure</i>	Controller failure, replace control board
8 BLINKS	<i>Brownout</i>	Check power harness or line voltage
9 BLINKS	<i>Fail</i>	Control Board failure
10-14 BLINKS	<i>Software Failure</i>	Cycle power to the control board. If continues replace control board.

STATUS LEDS

INPUT POWER	OFF	OFF state
	ON	AC charger or Solar power available
BATT CHARGING	OFF	Not charging
	ON	Trickle charge
	FAST BLINK (2 blinks per second)	High current charge
	SLOW BLINK (1 blink every 2 seconds)	Medium charge
TIMER	OFF	The timer is disabled
	ON	The timer is enabled
	MEDIUM BLINK (1 blink per second)	The timer is running
	FAST BLINK (2 blinks per second)	The timer is paused
	FASTEST BLINK (8 blinks per second)	The timer is cancelled
GATE MOVING	OFF	The gate is stopped
	ON	The gate is opening or closing
	MEDIUM BLINK (1 blink per second)	Operator is in E1 (single entrapment)
	FASTEST BLINK (8 blinks per second)	The operator is in E2 (double entrapment)
BATT LOW	OFF	No battery error
	ON	Battery low
	MEDIUM BLINK (1 blink per second)	Battery critically low
	FAST BLINK (2 blinks per second)	Battery disconnected error (seen in solar application, motion is inhibited)
	FASTEST BLINK (8 blinks per second)	Battery over voltage/over current error
ACC PWR OVLD	OFF	OFF state
	ON	Accessory overload protector opened

INPUT LEDS

OPEN INPUT	OFF	Input inactive
	ON	Input active
	BLINK	Input active on other operator
CLOSE INPUT	OFF	Input inactive
	ON	Input active
	BLINK	Input active on other operator
STOP INPUT	OFF	Input inactive
	ON	Input active
	BLINK	Input active on other operator
FIRE DEPT INPUT	OFF	Input inactive
	ON	Input active
	BLINK	Input active on other operator
OPEN SAFETY INPUT	OFF	Input inactive
	ON	Input active
	BLINK	Input active on other operator
CLOSE SAFETY INPUT	OFF	Input inactive
	ON	Input active
	BLINK	Input active on other operator

TROUBLESHOOTING CHART


FAULT	POSSIBLE CAUSES	CORRECTIONS
Operator does not run and diagnostic LED not on.	<ul style="list-style-type: none"> a) No power to control board b) Open fuse c) If on battery power only, low or dead batteries d) Defective control board 	<ul style="list-style-type: none"> a) Check AC and battery power b) Check fuses c) Charge batteries by AC or solar power or replace batteries d) Replace defective control board
Control board powers up, but motor does not run.	<ul style="list-style-type: none"> a) Check DIAGNOSTIC LEDs b) Reset button is stuck c) Stop button active d) If on battery power only, low or dead batteries e) Open or Close input active f) Entrapment Protection Device active g) Vehicle loop detector or probe active h) Defective control board 	<ul style="list-style-type: none"> a) Use Diagnostic code to identify issue b) Check Reset button c) Check Stop button is not "stuck on" d) Charges batteries by AC or solar power or replace batteries e) Check all Open and Close inputs for a "stuck on" input f) Check all Entrapment Protection Device inputs for a "stuck on" sensor g) Check all vehicle detector inputs for a "stuck on" detector h) Replace defective control board
Relay clicks with command, but motor does not turn on.	<ul style="list-style-type: none"> a) Arm jammed or not connected b) Defective motor or motor wires c) Defective control board 	<ul style="list-style-type: none"> a) Disconnect the arm from the operator and ensure arm moves freely b) Inspect motor and motor wires for open wire, shorted wires, damage, etc. Else, replace motor. c) Replace defective control board.
Arm moves, but cannot set correct limits.	<ul style="list-style-type: none"> a) Arm does not extend or retract enough during travel b) Arm is interfering with mounting bracket c) Gate is too difficult to move 	<ul style="list-style-type: none"> a) Disconnect the arm from the operator and ensure arm moves freely b) Examine the hinge point where the arm mounts to the gate post. Make sure that the arm housing does not hit or interfere with the gate post or mounting bracket. Correct as necessary. c) Disconnect arm from gate and move gate manually. Gate must move easily and freely through its entire range, limit-to-limit. Repair gate as needed.
Gate does not fully open or fully close when setting limits.	<ul style="list-style-type: none"> a) Arm does not extend or retract enough during travel b) Arm is interfering with mounting bracket c) Gate is too difficult to move 	<ul style="list-style-type: none"> a) Disconnect the arm from the operator and ensure arm moves freely b) Examine the hinge point where the arm mounts to the gate post. Make sure that the arm housing does not hit or interfere with the gate post or mounting bracket. Correct as necessary. c) Disconnect arm from gate and move gate manually. Gate must move easily and freely through its entire range, limit-to-limit. Repair gate as needed.
Operator does not respond to a wired control/command (example: Open, Close, SBC, etc.)	<ul style="list-style-type: none"> a) Check DIAGNOSTIC LEDs b) Check Open and Close command input LEDs c) Stop button is active d) Reset button is stuck e) If on battery power only, low or dead batteries f) Entrapment Protection Device active g) Vehicle loop detector or vehicle probe active h) Defective control board 	<ul style="list-style-type: none"> a) Use Diagnostic code to identify issue b) Check all Open and Close inputs for a "stuck on" input c) Check Stop button is not "stuck on" d) Check Reset button e) Charges batteries by AC or solar power or replace batteries f) Check all Entrapment Protection Device inputs for a "stuck on" sensor g) Check all vehicle detector inputs for a "stuck on" detector h) Replace defective control board
Operator does not respond to a wireless control or transmitter	<ul style="list-style-type: none"> a) Check DIAGNOSTIC LEDs b) Check XMITTER LED when wireless control is active c) Stop button is active d) Reset button is stuck e) Poor radio reception f) Defective control board 	<ul style="list-style-type: none"> a) Use Diagnostic code to identify issue b) Activate wireless control and check XMITTER LED is on. Re-learn wireless control/transmitter to control board. Replace wireless control as needed. c) Check Stop button is not "stuck on" d) Check Reset button e) Check if similar wired control operates correctly. Check if wireless controls works properly when within a few feet of operator. Check operator's antenna and antenna wire. Check other wireless controls or devices. f) Replace defective control board
Gate stops during travel and reverses immediately.	<ul style="list-style-type: none"> a) Check DIAGNOSTIC LEDs b) Inherent force obstruction detection c) External Entrapment Protection Device activation d) Control (Open, Close) becoming active e) Vehicle loop detector active f) Low battery voltage 	<ul style="list-style-type: none"> a) Use Diagnostic code to identify issue b) Check for obstruction in gate's path or travel. Disconnect arm from gate and move gate manually. Gate must move easily and freely through its entire range, limit-to-limit. Remove obstruction or repair gate as needed. c) Check all Entrapment Protection Device inputs for an active sensor d) Check all Open and Close inputs for an active input e) Check all vehicle detector inputs for an active detector f) Battery voltage must be 22.0 Vdc or higher. Charge batteries by AC or solar power or replace batteries

FAULT	POSSIBLE CAUSES	CORRECTIONS
Gate opens, but will not close.	<ul style="list-style-type: none"> a) Check DIAGNOSTIC LEDs b) Open control active c) Close Entrapment Protection Device active d) Vehicle loop detector active e) Loss of AC power with AC FAIL set to OPEN f) Low battery with LOW BATT set to OPEN g) Fire Dept input active 	<ul style="list-style-type: none"> a) Use Diagnostic code to identify issue b) Check all Open inputs for an active input c) Check all Entrapment Protection Device inputs for an active sensor d) Check all vehicle detector inputs for an active detector e) Check AC power and AC Fail option setting f) Battery voltage must be 22.0 Vdc or higher. Charge batteries by AC or solar power or replace batteries g) Check Fire Dept input
Gate closes, but will not open.	<ul style="list-style-type: none"> a) Check DIAGNOSTIC LEDs b) Open Entrapment Protection Device active c) Vehicle loop detector active d) Low battery with LOW BATT option set to CLOSE 	<ul style="list-style-type: none"> a) Use Diagnostic code to identify issue b) Check all Entrapment Protection Device inputs for an active sensor c) Check all vehicle detector inputs for an active detector d) Check if AC power is available. If no AC power, then running on batteries and battery voltage must be 22.0 Vdc or higher. Charge batteries by AC or solar power or replace batteries
Gate does not close from Timer-to-Close.	<ul style="list-style-type: none"> a) Timer-to-Close not set b) Open control active c) Close Entrapment Protection Device active d) Vehicle loop detector active e) Loss of AC power with AC FAIL set to OPEN f) Low battery with LOW BATT option set to OPEN g) Fire Dept input active 	<ul style="list-style-type: none"> a) Check Timer-to-Close (TTC) setting b) Check all Open inputs for an active input c) Check all Entrapment Protection Device inputs for an active sensor d) Check all vehicle detector inputs for an active detector e) Check AC power and AC Fail option setting f) Check if AC power is available. If no AC power, then running on batteries and battery voltage must be 22.0 Vdc or higher. Charge batteries by AC or solar power or replace batteries. g) Check Fire Dept input
Vehicle Exit loop activation does not cause gate to open.	<ul style="list-style-type: none"> a) Check DIAGNOSTIC LEDs b) Exit vehicle detector setup incorrectly c) Defective Exit loop detector or loop wire d) Low battery with LOW BATT option set to CLOSE 	<ul style="list-style-type: none"> a) Use Diagnostic code to identify issue. b) Review Exit loop detector settings. Adjust settings as needed. c) Check Exit loop wire. Replace defective Exit loop detector. d) Check if AC power is available. If no AC power, then running on batteries and battery voltage must be 22.0 Vdc or higher. Charge batteries by AC or solar power or replace batteries.
CLOSE EYES/Interrupt loop does not cause gate to stop and reverse.	<ul style="list-style-type: none"> a) Check DIAGNOSTIC LEDs b) Vehicle detector setup incorrectly c) Defective vehicle loop detector or loop wire 	<ul style="list-style-type: none"> a) Use Diagnostic code to identify issue. Check Anti-Tail gate switch. b) Review Interrupt loop detector settings. Adjust settings as needed c) Check Interrupt loop wire. Replace defective Interrupt loop detector
Vehicle Shadow loop does not keep gate at open limit.	<ul style="list-style-type: none"> a) Check DIAGNOSTIC LEDs b) Vehicle detector setup incorrectly c) Defective vehicle loop detector or loop wire 	<ul style="list-style-type: none"> a) Use Diagnostic code to identify issue b) Review Shadow loop detector settings. Adjust settings as needed c) Check Shadow loop wire. Replace defective Shadow loop detector
Obstruction in gates path does not cause gate to stop and reverse	<ul style="list-style-type: none"> a) Force setting too high 	<ul style="list-style-type: none"> a) Adjust force setting. Retest that obstruction in gate's path causes gate to stop and reverse direction.
Photoelectric sensor does not stop or reverse gate.	<ul style="list-style-type: none"> a) Incorrect photoelectric sensor wiring b) Defective photoelectric sensor 	<ul style="list-style-type: none"> a) Check photoelectric sensor wiring. Retest that obstructing photoelectric sensor causes moving gate to stop, and may reverse direction. Check Anti-Tail gate switch. b) Replace defective photoelectric sensor. Retest that obstructing photoelectric sensor causes moving gate to stop, and may reverse direction.
Edge Sensor does not stop or reverse gate.	<ul style="list-style-type: none"> a) Incorrect edge sensor wiring b) Defective edge sensor 	<ul style="list-style-type: none"> a) Check edge sensor wiring. Retest that activating edge sensor causes moving gate to stop and reverse direction. b) Replace defective edge sensor. Retest that activating edge sensor causes moving gate to stop and reverse direction.
Alarm sounds for 5 minutes or alarm sounds with a command.	<ul style="list-style-type: none"> a) Double entrapment occurred 	<ul style="list-style-type: none"> a) Check for cause of entrapment (obstruction) detection and correct. Press the reset button to shut off alarm and reset the operator.

FAULT	POSSIBLE CAUSES	CORRECTIONS
Alarm beeps three times with a command.	a) Low battery with loss of AC/solar power	a) Check if AC power is available. If no AC power, then running on batteries and battery voltage must be 22.0 Vdc or higher. Charge batteries by AC or solar power or replace batteries
On dual-gate system, one gate is not commanding the other.	a) Defective or incorrect Operator-to-Operator wiring b) Incorrect Operator-to-Operator wireless learning	a) Check operator-to-operator wiring. b) Relearn the wireless network of one operator to the other operator.
On dual-gate system, incorrect gate opens first or closes first.	a) Incorrect Bipart switch setting	a) Change setting of both operator's Bipart switch settings. One operator should have Bipart switch OFF (operator that opens first) and the other operator should have Bipart switch ON (operator that opens second)
Expansion board function not controlling gate.	a) Defective main board to expansion board wiring b) Incorrect input wiring to expansion board c) Defective expansion board or defective main board	a) Check main board to expansion board wiring. If required, replace wire cable. b) Check wiring to all inputs on expansion board. c) Replace defective expansion board or defective main board
Maglock not working correctly.	a) Maglock wired incorrectly	a) Check that Maglock is wired to N.C. and COM terminals. Check that Maglock has power (do not power maglock from control board accessory power terminals). If shorting lock's NO and COM wires does not activate Maglock, then replace Maglock or Maglock wiring
Solenoid lock not working correctly.	a) Solenoid wired incorrectly	a) Check that Solenoid is wired to N.O. and COM terminals. Check that Solenoid has power (do not power solenoid from control board accessory power terminals). If shorting lock's NC and COM wires does not activate Solenoid, then replace Solenoid lock or Solenoid wiring
Switched (SW) Accessory power remaining on.	a) In limit setup mode	a) Learn the limits
Accessories connected to Switch (SW) Accessory power not working correctly, turning off, or resetting.	a) Normal behavior	a) Move accessory to accessory power "ON"
Accessories connected to Accessory power not working correctly, turning off, or resetting.	a) Accessory power protector active b) Defective control board	a) Disconnect all accessory powered devices and measure accessory power voltage (should be 23 – 30 Vdc). If voltage is correct, connect accessories one at a time, measuring accessory voltage after every new connection. b) Replace defective control board
Quick Close not working correctly.	a) Quick Close setting incorrect b) CLOSE EYES/Interrupt loop detector or loop wire defective c) Defective Expansion board	a) Check that Quick Close setting is ON b) Check operation of CLOSE EYES/Interrupt Loop detector c) Replace defective Expansion board
Anti-Tailgating not working correctly.	a) Anti-Tail setting incorrect b) CLOSE EYES/Interrupt loop detector or loop wire defective c) Defective Expansion board	a) Check that Anti-Tail setting is ON b) Check operation of CLOSE EYES/Interrupt Loop detector c) Replace defective Expansion board
AUX Relay not working correctly.	a) AUX Relay setting incorrect b) AUX Relay wiring incorrect c) Defective Expansion board	a) Check AUX Relay switches settings b) Check that wiring is connected to either N.O. and COM or to N.C. and COM. c) Set AUX Relay to another setting and test. Replace defective expansion board.

ACCESSORIES


ENTRAPMENT PROTECTION DEVICES



PHOTOELECTRIC SENSORS (NON-CONTACT)

The photoelectric sensors are designed to detect an obstacle in the path of the electronic beam and stop the operator. Includes mounting brackets.

Models CPS-UN4 (through beam, LiftMaster low power accessory), AOMRON E3K-R10K4-NR (retro-reflective), RETROAB 60-2728 (retro-reflective)



SENSING EDGE (2-WIRE, NON-MONITORED, CONTACT)

Sensing edges can detect an obstacle upon contact and stop the operator.

Models G65MG0204, G65MG0205, G65MGR205, and G65MGS205


SENSING EDGE CHANNEL

Mounting channel for all MG020 type edges.

Model G65ME120C5

REMOTE CONTROLS


Chamberlain offers a variety of LiftMaster remote controls to satisfy your application needs. Single-button to 4-button, visor or key chain. The following remote controls are compatible with operators manufactured by Chamberlain after 1993. Contact your authorized LiftMaster dealer for additional details and options.



3-BUTTON REMOTE CONTROL

The 3-button remote control can be programmed to control the operator. Includes visor clip.


Model 893MAX



3-BUTTON MINI-REMOTE CONTROL

The 3-button remote control can be programmed to control the operator. Includes key ring and fastening strip.

Model 890MAX




KEYLESS ENTRY

Enables homeowner to operate gate operator from outside by entering a 4-digit code on a specially designed keypad.

Model 877MAX


MISCELLANEOUS



POST-MOUNTING PLATE

For post-mounting model CSW24V commercial swing operator (also CSW200 commercial swing operator). Posts not included.


Model MPEL



REMOTE ANTENNA EXTENSION KIT

The remote antenna extension kit allows the antenna to be remotely installed.


Model 86LM



WIRELESS ACCESS CONTROL RECEIVER

Access control receiver for up to 450 remote controls.

Model STAR450-315




PLUG-IN LOOP DETECTOR

Conveniently plugs into existing control board.

Model LOOPDETLM


MISCELLANEOUS



LOOP DETECTOR

Low power loop detectors mounted and wired separately inside control box. LiftMaster low power accessory.

Model LD7LP



HEATER

Keeps operator, gearbox and batteries at suitable temperature when outside temperature is below 0°F for extended periods of time.


Models GHTRKITSW (for Swing operator, includes bracket for optimal heater location) and G6518CSW (Swing replacement heater only)



VEHICLE SENSING PROBE

The vehicle sensing probe is buried in the ground and can detect a car as it approaches and will then open the gate.


Model CP3



SOLAR PANEL KIT - 10 WATT

This kit is to replace or add a solar panel to the operator application. Up to six solar panels can be connected to the operator in a series/parallel type configuration.

Model SOLPNL10W12V (requires 2 minimum)



SOLENOID GATE LOCK

The automatic gate lock is a solenoid-driven lock that automatically unlocks when the gate is open and locks when the gate is closed. Can be mounted onto a gate or post. Can be released in case of emergency.

Models GC824 (115 Vac) and GC824-12 (12/24 Vac/dc)




MAGNETIC GATE LOCK

Outdoor magnetic lock, transformer, junction box, mounting plate and hardware. Not for use with Solar Applications. Must be powered separately.

Model MG1300

BATTERIES


Gate access system batteries replace or upgrade the gate operator batteries. Two identical 12 Vdc batteries are required for each gate operator. Do not mix 7AH and 33AH batteries within a gate operator.



7AH BATTERIES

Standard 7 AMP-Hour Battery, 12 Vdc, to replace original batteries provided with operator. Reuse existing harnesses.


Models 29-NP712 (1) and K74-30762 (2)



33AH BATTERIES

Upgrade 33 AMP-Hour Battery, 12 Vdc. Ideal for solar applications and extended battery backup. Two required.


Model A12330SGLPK



BATTERY TRAY

For use with 33AH batteries.

Model K10-36183



33AH BATTERY HARNESS

Required for 33AH applications.


Model K94-36596

REPAIR PARTS

INDIVIDUAL PARTS

ITEM	PART NUMBER	DESCRIPTION	NOT SHOWN	
1	K13-36117	Cludge Cover	K94-36540	Wiring Harness with ID resistor assembly
2	K77-36538	Operator Cover with labels, keys, and lock assembly	K94-36250	Battery Harness (for 7AH batteries)
			Q103	Swivel Arm Assembly
3	K73-36109	Chassis	K80-36544	Vent Plug (for top gear box)
4	K76-34644	APS Encoder with cable	K80-36545	Vent Plug (for bottom gear box)
5	K19-50038	#50 Drive Chain and Master Link		30 Amp Fuses
6	K32-35814	Gear Reducer (bottom)	K74-30762	Two 7AH batteries
7	K15-50B18LKGH	Gear Reducer Sprocket with set screws and key (1)	K94-36596	Battery Harness (for 33AH batteries)
8	K77-36539	Output Shaft with sprocket, #35 limit chain, and APS sprocket roll pin		
9	K32-34655-1	Gear Box (top)		
10	K10-36395	Battery Tray		
11	29-NP712	Battery, 7AH, 12 Vdc		
12	K204C0211	Toroid Transformer		
13	K1A6408	APE Assembly with plastic tray, RPM board with mounting hardware		
14	K52C0481	Bridge Rectifier		
15	K1D6597-1CC	Main Board with heat sink		
16	K1D6686CC	Expansion Board		
17	K76-34728	EMI Board with 120V receptacles and AC power switch		
18	K77-36541	Antenna		
19	K76-36398	Motor, 1/2 HP, 24 Vdc		
20	K77-36542	Electrical Box with junction box		
21	K180A0357	Reset Switch		
22	K94-35152	Alarm with harness		
23	K75-36260	Lock and Keys		
24	Q118	Keys		
25	K13-34729	Dust Guard		
26	Q061	Output Shaft Cludge Arm Clamp and Release Handle		
27	Q059	Output Arm		
28	Q060	Release Handle		
29	Q104	Standard Arm Assembly		

REPAIR PARTS



MAINTENANCE

MAINTENANCE CHART + BATTERIES

MAINTENANCE CHART

Disconnect all power (AC, solar, battery) to the operator before servicing. The operator's AC Power switch ONLY turns off AC power to the control board and DOES NOT turn off battery power. ALWAYS disconnect the batteries to service the operator.

DESCRIPTION	TASK	CHECK AT LEAST ONCE EVERY		
		MONTH	6 MONTHS	3 YEARS
Entrapment Protection Devices	Check and test for proper operation	X		
Warning Signs	Make sure they are present	X		
Manual Disconnect	Check and test for proper operation		X	
Sprockets and Chains	Check for excessive slack and lubricate		X	
Gate	Inspect for wear or damage	X		
Accessories	Check all for proper operation		X	
Electrical	Inspect all wire connections		X	
Chassis Mounting Bolts	Check for tightness		X	
Operator	Inspect for wear or damage		X	
Batteries	Replace			X

NOTES:

- Severe or high cycle usage will require more frequent maintenance checks.
- It is suggested that while at the site voltage readings be taken at the operator. Using a digital voltmeter, verify that the incoming voltage to the operator is within ten percent of the operator's rating.

BATTERIES

Batteries will degrade over time depending on temperature and usage. The operator alarm will beep 3 times with a command if the battery is low. Batteries do not perform well in extremely cold temperatures. For best performance, the batteries should be replaced every 3 years. Use only LiftMaster part 29-NP712 for replacement batteries. The operator comes with two 7AH batteries. Two 33AH (A12330SGLPK), 33AH Battery Harness (K94-36596) with additional battery tray (K10-36183) may be used in place of the 7AH batteries.

The batteries contain lead and need to be disposed of properly.

NOTE: If your application includes a heater, two 33AH will not fit into the operator enclosure.

WARRANTY

7 YEAR RESIDENTIAL / 5 YEAR COMMERCIAL CSW24V™ AND CSW24VH™ LIMITED WARRANTY

The Chamberlain Group, Inc. ("Seller") warrants to the first purchaser of this product, for the structure in which this product is originally installed, that it is free from defect in materials and/or workmanship for a period of 7 year residential/ 5 year commercial from the date of purchase [and that the CSW24V™ and CSW24VH™ are free from defect in materials and/or workmanship for a period of 7 year residential/ 5 year commercial from the date of purchase]. The proper operation of this product is dependent on your compliance with the instructions regarding installation, operation, maintenance and testing. Failure to comply strictly with those instructions will void this limited warranty in its entirety.

If, during the limited warranty period, this product appears to contain a defect covered by this limited warranty, call **1-800-528-2806**, toll free, before dismantling this product. Then send this product, pre-paid and insured, to our service center for warranty repair. You will be advised of shipping instructions when you call. Please include a brief description of the problem and a dated proof-of-purchase receipt with any product returned for warranty repair. Products returned to Seller for warranty repair, which upon receipt by Seller are confirmed to be defective and covered by this limited warranty, will be repaired or replaced (at Seller's sole option) at no cost to you and returned pre-paid. Defective parts will be repaired or replaced with new or factory-rebuilt parts at Seller's sole option.

ALL IMPLIED WARRANTIES FOR THE PRODUCT, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE 7 YEAR RESIDENTIAL/ 5 YEAR COMMERCIAL LIMITED WARRANTY PERIOD SET FORTH ABOVE [EXCEPT THE IMPLIED WARRANTIES WITH RESPECT TO THE CSW24V™ AND CSW24VH™, WHICH ARE LIMITED IN DURATION TO THE 7 YEAR RESIDENTIAL/ 5 YEAR COMMERCIAL LIMITED WARRANTY PERIOD FOR THE CSW24V™ AND CSW24VH™], AND NO IMPLIED WARRANTIES WILL EXIST OR APPLY AFTER SUCH PERIOD. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. THIS LIMITED WARRANTY DOES NOT COVER NON-DEFECT DAMAGE, DAMAGE CAUSED BY IMPROPER INSTALLATION, OPERATION OR CARE (INCLUDING, BUT NOT LIMITED TO ABUSE, MISUSE, FAILURE TO PROVIDE REASONABLE AND NECESSARY MAINTENANCE, UNAUTHORIZED REPAIRS OR ANY ALTERATIONS TO THIS PRODUCT), LABOR CHARGES FOR REINSTALLING A REPAIRED OR REPLACED UNIT, OR REPLACEMENT OF BATTERIES. THIS LIMITED WARRANTY DOES NOT COVER ANY PROBLEMS WITH, OR RELATING TO, THE GATE OR GATE HARDWARE, INCLUDING BUT NOT LIMITED TO THE GATE SPRINGS, GATE ROLLERS, GATE ALIGNMENT OR HINGES. THIS LIMITED WARRANTY ALSO DOES NOT COVER ANY PROBLEMS CAUSED BY INTERFERENCE. ANY SERVICE CALL THAT DETERMINES THE PROBLEM HAS BEEN CAUSED BY ANY OF THESE ITEMS COULD RESULT IN A FEE TO YOU.

UNDER NO CIRCUMSTANCES SHALL SELLER BE LIABLE FOR CONSEQUENTIAL, INCIDENTAL OR SPECIAL DAMAGES ARISING IN CONNECTION WITH USE, OR INABILITY TO USE, THIS PRODUCT. IN NO EVENT SHALL SELLER'S LIABILITY FOR BREACH OF WARRANTY, BREACH OF CONTRACT, NEGLIGENCE OR STRICT LIABILITY EXCEED THE COST OF THE PRODUCT COVERED HEREBY. NO PERSON IS AUTHORIZED TO ASSUME FOR US ANY OTHER LIABILITY IN CONNECTION WITH THE SALE OF THIS PRODUCT.

Some states do not allow the exclusion or limitation of consequential, incidental or special damages, so the above limitation or exclusion may not apply to you. This limited warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

**845 Larch Avenue
Elmhurst, Illinois 60126-1196**