

allomatic.net



ALL-O-MATIC

BLDC-PRO SWINGER MANUAL



SW-300DC PRO



SW-320DC PRO



SW-325DC PRO



SW-350DC PRO

EACH INCLUDE: Arm | Pre-Wired Loop Detector Rack | 2 Safety Gate Signs | 1 RED EYE Photoeye

ALL-O-MATIC

SLIDERS | SWINGERS | OVERHEADS



allomatic.net

UL325
COMPLIANT

CANADA
CSA C22.2
COMPLIANT

The widest selection of **AC & DC Gate Operators**
for all your residential and commercial installations.

TABLE OF CONTENTS

SAFETY AND INTRODUCTION

Safety Instructions	1-2
UL 325 Class Types	3
Operator Specifications	4-5

INSTALLATION

SW-300DC PRO Concrete Pad Installation	6
SW-350DC PRO Concrete Pad Installation	7
SW-320DC PRO & SW-325DC PRO Concrete Pad Installation.	8
SW-300DC PRO and SW-350DC PRO Operator and Arm Dimensions.	9
SW-320DC PRO & SW-325DC PRO Operator and Arm Dimensions	10
Operator Placement and Arm Layout.	11-12
Compact Installation	13 & 14
Torque Limiter and Arm Adjustments	15 & 16
Electrical Connection	17
Wire Size Chart.	18

BOARD FEATURES

Gate Opening Direction and Gate Travel Setting	19
Dip Switch Functions	20
Timer Adjustment and Radio Receiver Setting	21
Electronic Reversing Device (ERD) Adjustment	22

WIRING ACCESSORIES TO CONTROL BOARD

Primary/Secondary Connection and Setup.	23
Programmable Relay and Leaf Delay	24
Entrapment Protection Installation.	25-28
Loop Rack Installation	29-30
Accessory Connections	31
Three-Button Station & Mag/Sol Lock Connection	32
Solar Panel Connection	33-34

DIAGNOSTICS

LED Diagnostics	35
Technical Tips	36
Aux Inputs Programming	37
LCD Settings and Diagnostics menu	38-39

EMERGENCY RELEASE INSTRUCTIONS

SW-300DC PRO and SW-350DC PRO Manual Release	40
SW-320DC PRO and SW-325DC PRO Manual Release	41

SWING ARM BREAKDOWN

WARRANTY AND CUSTOMER RECORD.	42-43
	44

PARTS BREAKDOWN

Blowout Drawings	Check Website
----------------------------	---------------

IMPORTANT SAFETY INSTRUCTIONS

WARNING

TO REDUCE THE RISK OF **INJURY**:

Please read and adhere to all installation instructions provided. Do not start installation procedures until you have thoroughly read and comprehended these directions. If there are any aspects that are unclear to you, please don't hesitate to contact us for assistance.

NEVER let children operate or play with gate controls.

Locate the control station and make sure it is (a) within sight of the gate and (b) at a minimum height of 5 feet so small children cannot reach it.

Install the enclosed entrapment warning signs next to the control station and in a prominent location.

For operators equipped with a manual release, instruct the end user on the correct operation of the manual release. Use the manual release only when the gate is not moving. It is advised that the power be turned off.

Always keep people and objects away from the gate. No one should cross the path of a moving gate.

The gate operator must be tested monthly. The gate must reverse on contact with a rigid object, or stop when an object activates the non-contact sensor(s). Always re-test the operator after adjusting the limits and/or force. Failure to adjust and re-test the gate operator properly may cause severe injury or death.

Keep gate(s) properly maintained. Have a qualified service technician make repairs to gate hardware and make proper adjustments to gate operator.

This gate entrance/exit is for vehicles only. Pedestrians must use a separate entrance.

There is nothing on a gate operator that is easily repaired or adjusted without a great deal of experience. Call a qualified gate service technician who knows your gate operator.

SAVE THESE INSTRUCTIONS

IMPORTANT SAFETY INSTRUCTIONS (CONTINUED)

INSTALL THE GATE OPERATOR ONLY WHEN YOU HAVE READ THE FOLLOWING

BEFORE GATE OPERATOR INSTALLATION

- Confirm that the gate operator being installed is appropriate for the application.
- Confirm that the gate is designed and built according to the current published industry standards.
- Confirm that all appropriate safety features and safety accessory devices are being installed, including all entrapment protection devices.
- Make sure that the gate opens and closes freely (by hand) before installing the operator.
- Repair or replace worn or damaged gate hardware before installing the gate operator.
- Eliminate all gaps in the sliding gate below a 6 foot height that permits a 2 1/4" sphere to pass through any location. This includes the area of the adjacent fence covered when the gate is in the open position
- Eliminate all gaps in a swing gate below a 4 foot height that permits a 4" sphere to pass through any location. This includes the hinge area of the gate.
- Install a proper electrical ground to the gate operator.
- Controls intended for user activation must be located at least 6 feet away from any moving part of the gate, and where the user is prevented from reaching over, under, around, or through the gate to operate the controls.
- Outdoor or easily accessible controls shall have a security feature to prevent unauthorized use.
- The stop and/or reset button must be located in the line of sight of the gate. Activation of the operator reset control shall not cause the operator to move.
- Install a minimum of 2 warning signs, one on each side of the gate where they are easily visible.
- Take pictures of the installation.
- Test all safety features for proper function before placing the automatic vehicular gate in operation.

GATE OPERATOR INSTALLATION

- Operator must be disconnected from the power source before attempting any installation of accessories.
- Install gate operator according to the installation instructions in this manual.
- Adjust the operator clutch or load sensing device to the minimum force setting that will allow for reliable gate operation.
- Install the operator inside the fence line. Do not install the operator on the public side of the fence line.

MAINTENANCE

- Train owners/users on the basic functions and safety features of the gate system, including how to turn off the power and operate the manual disconnect feature.
- Leave safety instructions, product literature, installation manual, and maintenance manual with the owner or end user.
- Explain to the owner or end user the importance of routine service and operator testing on a monthly basis.

UL 325 CLASS TYPES AND OBSTRUCTIONS SENSING SYSTEMS

Each class must have (2) monitored entrapment protection devices in each entrapment zone to sense and react to obstructions within 2 seconds.

All-O-Matic's gate operators conform to the most rigid Class One.

UL 325 CLASS TYPES

CLASS ONE: RESIDENTIAL

- A vehicular gate operator intended for use in garages or parking areas associated with a residence of one to four single families.

CLASS TWO: COMMERCIAL OR GENERAL PUBLIC ACCESS

- A vehicular gate operator intended for use at a commercial location or building, such as a multi-family housing unit (five or more single family units), hotel, garages, retail stores, or other buildings accessible by or servicing the general public.

CLASS THREE: INDUSTRIAL OR LIMITED ACCESS

- A vehicular gate operator intended for use at an industrial location or building, such as a factory, loading dock area, or other locations not accessible by or intended to service the general public.

CLASS FOUR: RESTRICTED ACCESS

- A vehicular gate operator intended for use at a guarded industrial location or building, such as airport security areas or other restricted access locations not servicing the general public and where unauthorized access is prevented via supervision by security personnel.

THE SIX TYPES OF OBSTRUCTION SENSING SYSTEMS

TYPE A:

- Inherent entrapment protection system. This system must sense and initiate the reverse of the gate within 2 seconds of contact with a solid object.

TYPE B1:

- Non-contact sensor (photoelectric sensor or equivalent). This system shall, upon sensing an obstruction in the direction of the gate travel, reverse the gate within a maximum of 2 seconds.

TYPE B2:

- Contact sensor (edge device or equivalent). This system shall, upon sensing an obstruction in the direction of the gate travel, initiate the reversal of the gate within a maximum of 2 seconds.

TYPE C:

- Inherent force limiting, inherent adjustable clutch, or pressure relief valve.

TYPE D:

- Actuating device requiring continuous pressure to maintain opening or closing motion of the gate.

SPECIFICATIONS


	SW-300DC PRO	SW-320DC PRO
Max Gate Weight	1,200 lbs.	700 lbs
Max Gate Length	20 feet	14 feet
Warranty	7 year residential 5 year commercial	5 year residential 3 year commercial
Motor	24 VDC brushless 1/2 HP motor	24VDC brushless gearhead motor
Gate Speed	Adjustable 17-25 seconds per 90 degree opening	Adjustable 13-25 seconds per 90 degree opening
Power Options	115 VAC single phase - 6 amps 230 VAC single phase - 3.5 amp or 24 VDC solar panel up to 80 watts	115 VAC single phase - 2.5 amps 230 VAC single phase - 1.5 amps or 24 VDC solar panel up to 80 watts
Duty Cycle	Continuous	30Min
Temperature Range	-40° to 160°	-40° to 160°
Gearbox Ratio	60:1	15:1
Width X Length X Height	12" W X 17" L X 25.5" H	14" W X 22.5" L X 20" H
Shipping Weight	140 lbs. + 35 lbs. arm	90 lbs. + 30 lbs. arm
Emergency Release	Quick release arm	Easy slide quick release arm
Belt Size	4L-370 (AX35)	N/A
Main Sprocket Size	40A54TX2 with torque limiter	N/A
Chain Size	40NP	N/A
Gearbox Sprocket	41B22X7/8	N/A
Limit Shaft Sprocket	N/A	N/A
Breaker Requirement	20 amp dedicated	20 amp dedicated
Gearbox Pulley	8" with 5/8" bore	N/A
Motor Pulley	2" with 5/8" bore	N/A
UL Classes	I, II, III & IV	I, II, III & IV

SPECIFICATIONS


	SW-325DC PRO	SW-350DC PRO
Max Gate Weight	2,000 lbs.	1/2 HP: 2,000 lbs 1 HP: 2,500 lbs
Max Gate Length	22 feet	22 feet
Warranty	7 year residential 5 year commercial	7 year residential 5 year commercial
Motor	24 VDC brushless 1/2 HP motor	24 VDC brushless 1/2 HP motor
Gate Speed	Adjustable 14-25 seconds per 90 degree opening	Adjustable 17-25 seconds per 90 degree opening
Power Options	115 VAC single phase - 6 amps 230 VAC single phase - 3.5 amp or 24 VDC solar panel up to 80 watts	115 VAC single phase - 8 amps 230 VAC single phase -4.5 amps or 24 VDC solar panel up to 80 watts
Duty Cycle	Continuous	Continuous
Temperature Range	-40° to 160°	-40° to 160°
Gearbox Ratio	750:1 with internal clutch	60:1 with internal clutch
Width X Length X Height	19" W X 25.5" L X 21" H	14" W X 24" L X 18" H
Shipping Weight	160 lbs. + 30 lbs. arm	1/2 HP: 190 lbs. + 35 lbs. arm 1 HP: 205 lbs. + 35 lbs. arm
Emergency Release	Easy slide quick release arm	Mechanical foot pedal release
Belt Size	N/A	4L-360 (AX34)
Main Sprocket Size	N/A	50B44X1.25
Chain Size	N/A	50NP
Gearbox Sprocket	N/A	50B11X1
Limit Shaft Sprocket	N/A	N/A
Breaker Requirement	20 amp dedicated	20 amp dedicated
Gearbox Pulley	N/A	7" with 3/4" bore
Motor Pulley	N/A	2" with 5/8" bore
UL Classes	I, II, III & IV	I, II, III & IV

SW-300DC PRO CONCRETE PAD INSTALLATION

TOP VIEW




FRONT VIEW




SW-350DC PRO CONCRETE PAD INSTALLATION

TOP VIEW




FRONT VIEW




SW-320DC PRO AND SW-325DC PRO CONCRETE PAD INSTALLATION

PAD MOUNT

SPD-325




SPD-320



POST MOUNT

SPT-325



SW-300DC PRO AND SW-350DC PRO OPERATOR ARM DIMENSIONS

Please refer to the chart and drawing below for operator and arm dimensions.

A: Distance between the center of the gate bracket and the center of the hinge point.

B: Distance between the gate hinge point and the edge of the operator concrete pad.

C: Distance from the gate in the open position to the center of the operator shaft.


D: Distance from the center of the gate hinge to the center of the operator shaft.

Minimum distance: The minimum distance required behind an open gate and an obstruction (ie: wall, bush, etc).
If this distance is between 20" and 34", refer to the compact installation page.

SW-300/350DC PRO Dimensions Chart

Gate length	A	B	C	D	Minimum Distance
Less than 12'	36"	32"	13"	46"	34"
13'-15'	42"	38"	13"	52"	37"
16'-22'	48"	44"	13"	58"	40"

NOTE: The indicated 2-inch distance pertains to the space from the gate when fully open at a 90-degree angle to the edge of the concrete pad. Should the gate require an opening angle exceeding 90 degrees, both the concrete pad and the distance marked as "C" must be adjusted accordingly to accommodate the extended movement. It is essential to maintain a consistent 2-inch clearance between the open gate and the concrete pad.



SW-320DC PRO AND SW-325DC PRO OPERATOR AND ARM DIMENSIONS

Please refer to the chart and drawing below for operator and arm dimensions. See page before for layout.

A: Distance between the center of the gate bracket and the center of the hinge point.

B: Distance between the gate hinge point and the edge of the operator concrete pad.

C: Distance from the gate in the open position to the center of the operator shaft.

D: Distance from the center of the gate hinge to the center of the operator shaft.


Minimum distance: The minimum distance required behind an open gate and an obstruction (ie: wall, bush, etc).
If this distance is between 20" and 33", refer to the compact installation page.

SW-320DC PRO Dimensions Chart


Gate length	A	B	C	D	Minimum Distance
Less than 12'	36"	26"	13"	46"	34"
More than 12'-14'	42"	32"	13"	52"	37"

SW-325DC PRO Dimensions Chart


Gate length	A	B	C	D	Minimum Distance
Less than 12'	36"	26"	13"	46"	34"
13'-15'	42"	32"	13"	52"	37"
16'-22'	48"	38"	13"	58"	40"



PAD MOUNT




POST MOUNT



OPERATOR PLACEMENT AND ARM LAYOUT


Step 1:

- With the gate in the closed position, mark the ground directly below the center of the gate bracket. This will be point **Y**.
- With the gate in the open position, mark the ground directly below the center of the gate bracket. This will be point **Z**.



Step 2:


- Chalk out a line connecting point **Y** and going past point **Z** as shown in the drawing below.
- The center of the operator shaft goes on this line. Bolt down operator.



OPERATOR PLACEMENT AND ARM LAYOUT (CONTINUED)


Step 3:

- Measure the distance between point **Y** and point **Z**. Divide this number in half.
- This number is length of the primary arm section in the next step.
- **Please be exact.**



Step 4:

- Cut the primary arm section the measurement you recorded in Step 3 (half the distance between point **Y** and point **Z**).
- The secondary arm makes up the rest of the arm length to the gate bracket and does not need to be measured exactly.





COMPACT INSTALLATION (FOR SW-300DC PRO AND SW-350DC PRO ONLY)

The gate must be 12'0" long or less to use this installation.

The measurements in the installation drawing below will only work if the distance between the gate in the open position and the obstruction (ie: wall, bush, etc) is between 20" and 34". If you have more than 34", please refer to the standard installation.

The secondary arm makes up the rest of the arm length to the gate bracket and does not need to be measured exactly.



COMPACT INSTALLATION (FOR SW-320DC PRO SW-325DC PRO)

The gate must be less than 12'0" wide to use this installation.

The measurements in the installation drawing below will only work if the distance between the gate in the open position and the obstruction (ie: wall, bush, etc) is between 24" and 34". If you have more than 34", please refer to the standard installation.

The secondary arm makes up the rest of the arm length to the gate bracket and does not need to be measured exactly.




A: The distance between the center of the gate bracket and the center of the hinge point.

B: The distance between the gate hinge point and the edge of the operator concrete pad.

C: The distance from the gate in the open position to the center of the operator shaft.

D: The distance from the center of the gate hinge to the center of the operator shaft.


Minimum distance: The minimum distance required behind an open gate and an obstruction (ie: wall, bush, etc).



SW-300DC PRO AND SW-350DC PRO TORQUE LIMITER AND ARM ADJUSTMENTS


- Adjust the torque limiter on the operator before use.
- Utilize a wrench to tighten the large torque limiter nut or bolts, as demonstrated in the below images.
- Ensure the torque limiter nut is sufficiently tightened to prevent the clutch from slipping during operation.
- Verify functionality by manually operating the gate and confirming the torque limiter engages appropriately.
- This adjustment is crucial; ensure it is executed accurately and with attention to detail.

SW-350DC PRO



TOP VIEW

SW-300DC PRO



SIDE VIEW


Arm Adjustment:

- Secure the quick release arm lever in the closed position using either a bolt or padlock.
- Once secured, utilize an Allen wrench to tighten the arm adjusting setscrew with the arm lever closed.


Arm Quick Release:

- To disengage the arm quickly, remove the bolt or padlock securing the arm lever and fully open it.
- Once the arm lever is open, manual operation of the gate—both opening and closing—is enabled.

ARM ADJUSTMENT




ARM QUICK RELEASE




SW-320DC PRO AND SW-325DC PRO TORQUE LIMITER ADJUSTMENT

- Adjust the torque limiter on the operator prior to use, as it is shipped loose and requires adjustment.
- Utilize either a pipe wrench or a pair of channel lock pliers to adjust the large torque limiter nut on the operator, as illustrated in the accompanying images.
- Tighten the torque limiter nut until the clutch no longer slips during operation of the operator.
- It is imperative to manually operate the gate by hand and ensure that the torque limiter functions properly.
- This adjustment is crucial; therefore, please allocate sufficient time to perform it accurately and with care.

SW-320DC



SW-325DC



ELECTRICAL CONNECTION

OPERATORS **MUST** BE PROPERLY GROUNDED!


- It is **mandatory** for all gate operators to be correctly grounded. This precaution is essential to minimize or prevent potential damage caused by electrical events, such as a nearby lightning strike or an electrical static discharge.
- Utilize a single wire for grounding purposes; **under no circumstances** should two wires be spliced for this purpose. In the event of a break or cut in the wire, replace it with a single uninterrupted length of wire. It is imperative to never employ two wires for grounding.
- **Refer to the local city code to determine the correct type of earth ground rod and grounding procedures. This is essential for ensuring adequate lightning protection for the control board.**
- These operators can be powered either from a 115VAC or 230VAC single-phase source. Utilize the voltage selector switch located on the EMI board to choose the appropriate voltage option. Refer to the table below for the wiring configuration of the incoming power.
- Use a minimum of a 20Amp, dedicated circuit for each operator.
- See current draw table to calculate power wire size.

DC PRO GATE OPERATORS	CURRENT DRAW @ 115VAC	CURRENT DRAW @ 230VAC
SW-300DC PRO	6 AMPS	3.5 AMP
SW-320DC PRO	2 AMPS	1 AMPS
SW-325DC PRO	6 AMPS	3.5 AMPS
SW-350DC PRO – ½HP	6 AMPS	3.5 AMPS
SW-350DC PRO – 1 HP	8 AMPS	4.5 AMPS

Use above operator current draw table and the tables on next page to help you calculate the power wire size for the run.

It is important to use the correct size wire to avoid large voltage drops.

IMPORTANT: Due to the dual voltage option (115VAC/230VAC single phase), the receptacle neutral is separate from the neutral wire to the EMI board. The white wire connected to the receptacle neutral must be connected to the neutral wire of the EMI board when 115VAC power is used. **DO NOT** connect this receptacle white wire when 230VAC is used. This will cause damage to devices plugged to receptacle.



CAUTION: Before wiring high voltage, be sure to turn OFF the breaker.

WIRE SIZE CHART

Refer to the table below to choose the appropriate wire size for the power run. Using the correct wire size is vital to prevent voltage drops.

Max Wire Feet @ 120 Volts, 1 Phase, 2% Max Voltage Drop						
Amps	Volt- Amps	#14	#12	#10	#8	#6
1	120	450	700	1100	1800	2800
5	600	90	140	225	360	575
10	1200	45	70	115	180	285
15	1800	30	47	75	120	190
20	2400	-	36	57	90	140
25	3000	-	-	45	72	115
Amps	Volt- Amps	#4	#2	1/0	2/0	3/0
1	120	4500	7000	-	-	-
5	600	910	1400	2250	2800	-
10	1200	455	705	1100	1400	1800
15	1800	305	485	770	965	1200
20	2400	230	365	575	725	900
25	3000	180	290	460	580	720

Max Wire Feet @ 240 Volts, 1 Phase, 2% Max Voltage Drop						
Amps	Volt- Amps	#14	#12	#10	#8	#6
1	240	900	1400	2200	3600	5600
5	1200	180	285	455	720	1020
10	2400	90	140	225	360	525
15	3600	60	95	150	240	350
20	4800	-	70	110	180	265
25	6000	-	-	90	144	210
Amps	Volt- Amps	#4	#2	1/0	2/0	3/0
1	240	9000	-	-	-	-
5	1200	1750	2800	4500	5600	7000
10	2400	910	1400	2200	2800	3600
15	3600	605	965	1500	1900	2400
20	4800	455	725	1100	1400	1800
25	6000	365	580	920	1100	1440

GATE DIRECTION AND TRAVEL ADJUSTMENT


GATE DIRECTION ADJUSTMENT

- To change the opening direction of the operator, utilize the "OPEN L/R" dipswitch (#8).
- The direction of gate opening is determined from behind the gate operator.
- LEDs will indicate the opening and closing direction while the gate is in motion.
- When the "OPEN L/R" switch is set to "OFF," it signifies left-hand opening.
- Conversely, setting the switch to "ON" indicates right-hand opening.

DIP-SWITCHES




LED indicators will indicate opening or closing when the gate is in motion



GATE TRAVEL ADJUSTMENT

Once you've found the limit switches and identified which one controls the open and close functions, proceed with the following steps to adjust the gate travel:

1. Power off the gate operator.
2. Loosen the limit cams using a screwdriver and adjust them in the desired direction.
3. Secure the limit cams by tightening the Phillips screw.
4. Power on the gate operator.
5. Operate the gate to test adjustments.
6. Repeat the adjustment process if further modifications are needed.
7. Once limits are set, move the gate to the closed position. Press and release "RESET" on the circuit board, then run the gate through one uninterrupted cycle (full open and full close) to establish the slow down distance.



DIP SWITCH FUNCTIONS

TIMER

TIMER switch “ON” activates the automatic close timer. See page 21 for details.

RADIO

RADIO switch “ON” allows the radio receiver to override the automatic close timer. See page 21 for details.

OSC

OSC switch “ON” allows the radio receiver to stop and reverse the gate in any direction. During a cycle, the first signal stops the gate. A second signal reverses the gate.

FAIL SC/SF

ON for **Fail-Safe**: Upon power failure, board will monitor battery voltage to make sure gate opens before battery completely drains. **OFF** for **Fail-Secure**: Upon power failure, gate will run until battery is low and lock closed.

1-PASS

1-PASS switch “ON” allows the gate to open until one vehicle goes over the safety loop. Once the vehicle has cleared the loop, the gate will stop and close. If a second vehicle goes over the loop while the gate is closing, the gate will stop. The vehicle must get off of the loop before the gate continues to close, forcing the second vehicle to present valid credentials. This is a true one pass, anti-tailgating feature to be used with safety loops.

SECONDARY

This feature is used in dual gate applications. The **SECONDARY** switch will be “ON” only on the secondary operator. All other dip switches will be “off”, except the OPEN L/R. **SECONDARY** switch will be “OFF” on the primary operator.

AUTO OPEN



This feature is to automatically open the gate on power interruption. It is a very particular feature used in areas where the fire department requires the gate to open automatically after a power outage.

Set this dip switch “ON” when this feature is desired.

NOTE: There is a 40 second delay between power outage and the gate opening.

OPEN L/R

OPEN L/R switch “ON” is used for right hand opening of the gate. The “OFF” position is used for left hand opening of the gate.



NOTE: IF ANY CHANGES ARE MADE TO THE DIP-SWITCHES, PRESS THE **MAIN RESET** BUTTON TO RECOGNIZE THE CHANGES.

AUTO CLOSE TIME SETTING & RADIO RECEIVER WIRING

AUTO CLOSE TIMER SETTINGS

TIMER ON: Automatic timer to close can be set from 1 to 120 seconds (2 minutes)

TIMER OFF: Gate operation is “push button to open, push button to close”


RADIO ON: Use this option to override the timer and allow the transmitter to close gate before auto close timer does.

OSC ON: Use this option to use the remote/transmitter to stop the gate mid cycle (just like a garage door opener). 1. press remote once, gate starts to run. 2. press it a second time to stop gate. 3. press it a third time to reverse the gate.

To activate and adjust the timer, set the **TIMER** dip-switch to the **ON** position, then press the **TIMER** push button to open the **TIMER** adjustment in the LCD display.

Once, the display shows the **TIMER** adjustment, use the **UP** and **DOWN** push buttons to set the number of seconds the gate will remain open before it closes automatically.

TIMER, RADIO & OSC dip-switches




RADIO RECEIVER WIRING

There are two types of receivers: 3-wire and 4-wire:

3 wire receivers can mounted on the radio receiver terminal strip located outside of the control box.

For 4 wire receivers, connect the relay contact wires to terminals 1 (**COMMON**) and 2 (**RELAY/RADIO**) on the receiver terminal strip located outside the control box (one wire on each terminal). For power connect the black(negative) wire to terminal 1 (**COMMON**) and the red (positive) wire to terminal 3 (**+12/24VDC**) on the receiver terminal strip as shown below.

RADIO dip switch **ON** allows the radio receiver to override the automatic close timer. See **TIMER** adjustment above for more details.



PRIMARY/SECONDARY CONNECTION

BEFORE LINKING PRIMARY/SECONDARY COMMUNICATION, TAKE THE FOLLOWING STEPS:

1. Adjust the ERDs and limit switches for each operator individually following the instructions provided in the ERD and limit switch adjustment sections.
2. After adjusting both operator, on the secondary operator, set the **SECONDARY** dip-switch to "ON". Press the **RESET** button on the secondary operator.


For communication between controllers, the ALL-BLDC PRO offers two options: wireless and hard-wired connections. Additionally, accessories can now be connected to either the primary or secondary operator.

WIRELESS SETUP


1. To establish a wireless link between the units, press and hold the **UP** button on one unit. While holding the **UP** button, press and release the **RESET** button (do not release the **UP** button yet). A message prompting you to setup the other unit will appear. Release the **UP** button. The LCD display will show the default channel, usually channel 1. (see LCD display page for wireless channel settings)
2. Repeat step 1 on the second unit. Ensure both units display the same channel. Also, ensure that the first two adjustments have been completed and the **SECONDARY** dip-switch is set to "ON" on the secondary operator.
3. Once both units have completed step 1 with matching channels and correct dip-switch settings, they will link up, and the **P/S LINK** LED will illuminate.

HARD WIRED SETUP

1. To establish a hard-wired link between the units, press and hold the **DOWN** button on one unit. While holding the **DOWN** button, press and release the **RESET** button (do not release the **DOWN** button yet). The LCD will indicate WIRED MODE.
2. Repeat step 1 on the second unit. Ensure that the first two adjustments have been completed and the **SECONDARY** dip-switch is set to "ON" on the secondary operator.
3. Once step 1 is complete on both units, wire the two units following the diagram, matching **DATA+** to **DATA+** and **DATA-** to **DATA-**. After the connection is complete, both operators will link up, and turn on their respective **P/S LINK** LED.



PROGRAMMABLE RELAY AND LEAF DELAY



ENTERING LCD DISPLAY MENU

To wake up the display, press OK button twice. The message shown on image will be displayed. Press < left button to start English menu. From there, you can press OK button while cursor is on SETTINGS option. In there you can find the settings for the setting below, AUXILIARY RELAY and LEAF DELAY.

Use UP or DOWN buttons to scroll through menu items.
Use < LEFT button to go to previous menu.

RELAY-1 SETTINGS

ALL-BLDC PRO includes a programmable relay (N.O. or N.C.) with four different configurations. Using the LCD display menu, relay can be programmed for one of 4 different options. Navigate to menu setting Auxiliary Relay. To get there, go into English menu, go into SETTINGS, then scroll down to AUXILIARY RELAY, press OK. In there you can find the following options.

- (1) PRE-WARN SIGNAL: Use this option to control an alarm, or strobe light to pre-warn people the gate will move. In this setting, there can be a delay set to start the alarm or strobe before gate starts to move.
- (2) MOVING SIGNAL: To activate the relay when ever the gate is in motion. This function is similar to first option, except no delay.
- (3) OPENED SIGNAL: With this option, relay will be activated whenever the gate is fully open. It could be for an indicator for end user to see the position of gate.
- (4) CLOSED SIGNAL: With this option, relay will be activated when gate is fully closed. It could be for an indicator for end user to see the position of gate.

DELAY SETTINGS

ALL-BLDC PRO control boards includes a delay option for open or close cycles. This delay option is most commonly used on swing gate applications. To activate this delay, navigate to the menu setting LEAF DELAY. To get there, go into English menu, go into SETTINGS, then scroll down to LEAF DELAY, press OK. In there you'll find the following.

DELAY CLOSE ^
DELAY 00.0SEC.


While the cursor is on first line DELAY CLOSE, press OK button to change the delay direction. While in this setting, use the UP button to toggle/change from CLOSE to OPEN. Once you have the desired delay direction displayed, press OK button.
Scroll down to DELAY and press OK button. In here, you will see one line displayed saying DELAY and the seconds. Using up and down buttons, adjust the delay. Once you have the desired delay displayed, press OK button to save.

If you have a secondary operator, repeat the process on it but set the delay for the opposite direction.


Important: Delay can be set for one direction only.

ENTRAPMENT PROTECTION INSTALLATION

- Each entrapment zone must have at least two monitored entrapment protection devices in place.
- An entrapment zone is defined as any area where a person could potentially become trapped between the moving gate and a solid object.
- The gate operator comes with its own built-in entrapment protection system (ERD). However, before the gate can operate, it requires an additional external monitored entrapment protection device for each entrapment zone.
- These external devices can include non-contact photoelectric sensors or contact edges. Before initiating gate operation, the operator activates and verifies the signals from the external entrapment protection devices. If the operator fails to receive the correct feedback from these devices, the gate will not be allowed to operate.




MONITORED ENTRAPMENT PROTECTION DEVICE CONNECTION



WIRING ENTRAPMENT DEVICE TO DC BOARD


WIRING DEVICE ACROSS DRIVEWAY / CLOSE DIRECTION (MON_CLOSE)

WIRING THE AOM-RED-EYE
(INCLUDED WITH OPERATOR)
TO THE CIRCUIT BOARD



WIRING DEVICE FOR OPEN DIRECTION (MON_OPEN)

WIRING THE AOM-RED-EYE
(INCLUDED WITH OPERATOR)
TO THE CIRCUIT BOARD




ALL-BLDC PRO offers the 10K termination alternate option. Connect 10K sensor contacts to COMMON and MON-OPEN or MON-CLOSE as shown below.


Close contact edge with 10K termination

Open contact edge with 10K termination

Additionally, AUX INPUT 1 and 2 can be used to wire additional entrapment protection devices (10K or N.C. termination). For N.C. devices, power must be connected to MON +24VDC. For 10K devices power could be connected to the constant +12VDC or +24VDC if it requires power. See LCD display page for details of programming inputs.



- There are 2 types of sensors that can be connected to the gate operator for UL 325 monitored entrapment compliance: non-contact sensors (photo eye) and contact sensors (edge sensors).
- Monitored entrapment protection devices use 4 wires to connect to the board. From the device, connect the **RELAY COMMON** to the board **COMMON** and the **NORMALLY CLOSED** relay contact to the assigned **MON_OPEN** or **MON_CLOSE** input. **MON +24VDC** and **COMMON** must be used to power these devices and properly monitor the them.
- **IMPORTANT:** ALL-BLDC PRO can also work with 10K termination devices. See bottom of previous page for wiring details.
- **NOTE:** The power to the **MON +24VDC** terminal will be off when the gate is at rest (not moving). It will be normal to see the **MON_OPEN** and **MON_CLOSE** LEDs when the gate is closed. If the auto close timer is **OFF** it will do the same when the gate is at rest in the open position. Also, if no devices are connected both of these lights will stay ON.
- Please refer to the device manufacturer wiring instructions for details (on next page), making sure to follow the normally closed wiring directions. Some devices may work on monitoring interfaces other than normally closed.
- Should there be a need for more than 1 entrapment protection device for each direction, **AUX INPUT 1** and **AUX INPUT 2** could be used as MONITORED input expansion. See LCD display page for programming details.



This input is only for the monitored entrapment protection device for the close direction. When the gate is closing, it will open to the full open position if an obstruction is sensed and resets the automatic close timer. This input does nothing in the opening direction. If a device is not connected or the board senses a fault (MON_FAULT LED will turn on), the operator will only work with a constant pressure actuated switch. Once the obstruction is cleared, the gate will operate normally.

This input is only for the monitored entrapment protection device for the open direction. When the gate is opening, it will reverse for 2 seconds and stop if it senses an obstruction. This input does nothing in the closing direction. If a device is connected and the board detects a fault (MON_FAULT LED will turn on), the operator will only work with a constant pressure actuated switch. Once the obstruction is cleared, the gate will operate normally.

MONITORED ENTRAPMENT PROTECTION DEVICE CONNECTIONS

ENFORCER E-960-D90GQ/ E-931-S33RRGQ / E-931-S50RRGQ	
CONTACT	BOARD TERMINAL
N.C.	MON_CLOSE OR MON_OPEN
COM	COMMON
12-30 VDC/AC	COMMON
12-30 VDC/AC	MON_12/24VDC

ENFORCER E-936-S45RRGQ	
WIRE	BOARD TERMINAL
BLACK	MON_CLOSE OR MON_OPEN
WHITE	COMMON
BLUE	COMMON
BROWN	MON_12/24VDC

ALLEN BRADLEY GRU-24	
WIRE	BOARD TERMINAL
BLACK	MON_CLOSE OR MON_OPEN
ORANGE	COMMON
BLUE	COMMON
BROWN	MON_12/24VDC

OMRON E3K-R10K4-NR		
SWITCH	CONTACT	BOARD TERMINAL
LIGHT ON	N.O.2	MON_CLOSE OR MON_OPEN
	C.2	COMMON
	24 TO 240 VAC	COMMON
	24 TO 240 VAC	MON_12/24VDC

EMX IRB-MON		
SWITCH	CONTACT	BOARD TERMINAL
SW1 - OFF	N.C.	MON_CLOSE OR MON_OPEN
SW2 - OFF	COM	COMMON
SW3 - ON	POWER/ VRX	COMMON
SW4 - OFF	POWER/ VRX	MON_12/24VDC

EMX IRB-325	
CONTACT	BOARD TERMINAL
N.C.	MON_CLOSE OR MON_OPEN
COM	COMMON
POWER	COMMON
POWER	MON_12/24VDC

EMX NIR-50-325	
WIRE	BOARD TERMINAL
BLACK	MON_CLOSE OR MON_OPEN
WHITE	COMMON
BLUE	COMMON
BROWN	MON_12/24VDC

EMX IRB-RET		
SWITCH	CONTACT	BOARD TERMINAL
SW1 - OFF	N.C.	MON_CLOSE OR MON_OPEN
SW2 - OFF	COM	COMMON
SW3 - OFF	POWER/ VRX	COMMON
SW4 - ON	POWER/ VRX	MON_12/24VDC

TRANSMITTER SOLUTIONS R50R-UL/R32P-UL/SR33HD/SR66HD	
CONTACT	BOARD TERMINAL
N.C. (3)	MON_CLOSE OR MON_OPEN
COM (5)	COMMON
NON POLARITY (1)	COMMON
12-30 VDC/AC (2)	MON_12/24VDC

TRANSMITTER SOLUTIONS iGAZE RE KIT		
SWITCH	CONTACT	BOARD TERMINAL
ALL OFF	N.C.1	MON_CLOSE OR MON_OPEN
	COM	COMMON
	(-) 12/24 VDC	COMMON
	(+) 12/24 VDC	MON_12/24VDC


EMX WEL-200	
CONTACT	BOARD TERMINAL
RELAY CLOSE (NC) RELAY OPEN (NC)	MON_CLOSE MON_OPEN
RELAY CLOSE (COM) RELAY OPEN (COM)	COMMON COMMON
POWER	COMMON
POWER	MON_12/24VDC

MILLER EDGE RBAND 6 WIRES FOR 1 EDGE - 8 WIRES FOR 2 EDGES		
SWITCH	CONTACT	BOARD TERMINAL
SW 1 - ON	N/C N/C	MON_CLOSE MON_OPEN
SW 2 - ON	COM COM	COMMON COMMON
SW 3 - ON	COM A.TEST	COMMON MON_12/24VDC
SW 4 - ON	12/24 (+) AC/DC	24-VDC GROUND

MON_CLOSE = PROTECTS ACROSS THE DRIVEWAY/CLOSING DIRECTION
MON_OPEN = PROTECTS THE REAR SLIDE / OPENING DIRECTION

LOOP LAYOUT



- Below is a typical loop layout. When connecting to an All-O-Matic circuit board, use the following:
 - Safety Loop - Normally Closed (N.C) Contacts
 - Exit Loop and Center/Phantom Loop - Normally Open (N.O.) Contacts
- Loop wires **MUST** be twisted from the exit point of the loop saw cut to the loop detector.
- Twist loop wires 6 turns per foot, as shown below. Improper twisting of wires can cause loop issues.
- When using an inside and outside safety loop, loops must be **WIRED IN SERIES**.



LOOP RACK INSTALLATION

- The SW-300DC, SW-320DC, SW-325DC and SW-350DC models come equipped with the pre-wired LPR-2 loop rack for safety, phantom and exit plug-in loop detectors, making installation quick and efficient.
- Hardwired loop detectors with harnesses can also be installed. The circuit board has 12 VDC and 24 VDC terminals to power the detector of your choice. See "Accessory Connections" page for wiring instructions.
- Wire one or more safety devices in series with the loop rack wires. To do this, remove the white wire (N.C) from the loop rack off of the SAFETY terminal on the circuit board and wire nut to the COM of the additional device. The N.C. contact of the additional device will now go on the SAFETY terminal of the board.
- **IMPORTANT:** Use different frequencies for each loop detector to eliminate interference.

LOOP RACK	DC BOARD	WIRE COLOR
12VdC	12-VDC	RED
GROUND	GROUND	BLACK
EXIT	EXIT	GREEN
PHANTOM	PHANTOM	BROWN
SAFETY	SAFETY	WHITE



Remove Safety loop wire jumper when a SAFETY LOOP detector is installed.

STOP	P/S LINK
CLOSE	RADIO
+12VDC	EXIT LOOP
COMMON	PHAN LOOP
EXIT LOOP	SAFETY LOOP
PHAN LOOP	FIRE ACCESS
SAFETY LOOP	MON-CLOSE
FIRE ACCESS	MON-OPEN
COMMON	MON-FAULT
MON +24VDC	OPEN

IMPORTANT: Dip switch SW3 must be set when installing the detector in order for it to work properly.

Use chart below to set the output of the detector either **FAIL-SECURE** (N.O.) or **FAIL-SAFE** (N.C.).

OFF will set the output as **FAIL-SECURE** and **ON** will set output as **FAIL-SAFE**. See chart below.

OUTPUT	SW3
EXIT/PHANTOM	OFF
SAFETY	ON

PRIME-VD1
VEHICLE DETECTOR

INDICATORS:
RED - DETECT
GREEN - PWR/LOOP FAIL

SETTINGS

SENSITIVITY	SW1	SW2
LOW	OFF	OFF
MEDIUM LOW	ON	OFF
MEDIUM HI	OFF	ON
HIGH	ON	ON

FREQUENCY	SW5	SW6
HIGH	OFF	OFF
MEDIUM HI	ON	OFF
MEDIUM LOW	OFF	ON
LOW	ON	ON

PRESS RESET AFTER CHANGING SENSITIVITY AND FREQUENCY SETTINGS

GREEN LED BLINKING
INDICATE LOOP FAIL:
1 BLINK - OPEN LOOP
2 BLINKS - LOOP SHORTED

OUTPUT	SW3
N.O.	OFF
N.C.	ON


USE N.C. FOR SAFETY/
REVERSE LOOP. N.O.
FOR EXIT OR PHANTOM LOOPS.

ACCESSORY CONNECTIONS

The **ALL-BLDC PRO** controller has auxiliary **+12VDC** and **+24VDC** terminals that provide up to 750mAmps on **+12VDC** and 750mAmps on **+24VDC** to power accessories. If the total current draw of the accessories exceeds the rated current for any of the +12VDC or +24VDC terminals, a separate power supply (transformer) is required.

IMPORTANT: From factory, we include wire jumpers on N.C. inputs. When installing a safety loop detector or a stop push button (**STOP** input), make sure to remove the wire jumper between the **COMMON** and **SAFETY LOOP** terminal for the safety detector and/or wire jumper between **STOP** and **COMMON** for a stop push button.

AUX INPUT 1 AND AUX INPUT 2, could be programmed to different functions. Depending on the function, the input can be N.O., N.C. or 10K termination for entrapment protection devices. See LCD display page for details on input function details.




ALL-BLDC PRO controller has a built in delay of 0.5 seconds. Some locks may require longer delay to fully release. See auxiliary relay and delay page for details on setting a leaf delay and give the lock more time to release.

NOTE: Delay can be set on either **PRIMARY** or **SECONDARY** operator.

THREE BUTTON STATION CONNECTION

- A three button station and reset push button are integrated on the board to make limit and ERD adjustments easier.
- An external three button station may also be installed. See diagram below for wiring instructions.
- **NOTE:** STOP jumper must be removed if a three button station is installed.




Magnetic or solenoid lock installation require a step down transformer with the appropriate voltage for the specific lock accessory. Most operators include a 120VAC outlet for the step down transformer. The **SL-45DC PRO** does not.

Connections: Plug power supply (transformer) to the 120VAC outlet receptacle. Connect one wire of from power supply low voltage directly to the lock device. The second low voltage wire from the power supply to board Lock relay COMMON terminal.

For Magnetic Lock: Connect second wire of the magnetic lock to MAGLOCK terminal of board lock relay.

For Solenoid Lock: Connect second wire of the solenoid lock to SOLENOID terminal of board lock relay.

See diagram for reference.




SOLAR PANEL CONNECTION

The solar panel input requires a minimum of a 24VDC, 40 Watt panel. The charging circuit is capable up to 80 watt. With (2) 14Ah, 12VDC batteries, a receiver and (2) monitored entrapment devices connected, these operators can provide about 20 cycles/day.

Be sure to use the SOLAR input for solar panels. The on board solar battery regulator offers a MPPT feature that makes it more efficient than other types of regulators.

For a solar installation, upgrade the batteries according to usage. When the application requires more than 80 watts of solar power, an external charge controller regulator is necessary. See next page for external solar system.

For information on solar applications (solar panel sizes, battery size, etc.), please call All-O-Matic.




EXTERNAL SOLAR SYSTEM INSTALLATION

When using an external solar package, connect batteries straight into the **BATTERY** input. The batteries will need to be upgraded to meet application requirements. See wiring below.

For information on solar applications (solar panel sizes, battery size, etc.), please call All-O-Matic.

IMPORTANT: When more than two solar panels are needed, special wiring precautions must be taken to prevent damage to batteries and/or charge controller regulator. If the panels are 12VDC they must be wired in series to make 24VDC. If 24VDC panels are used they must be wired in parallel.



LED DIAGNOSTICS

P/S LINK

ON when primary/secondary communication is active.

RADIO

ON when the RADIO input is activated (closed circuit to common).

EXIT LOOP

ON when the EXIT input is activated (closed circuit to common).

PHANTOM LOOP

ON when the PHANTOM LOOP input is activated (closed circuit to common).

SAFETY LOOP

ON when the SAFETY LOOP input is activated (open circuit to common).

FIRE ACCESS

ON when the FIRE ACCESS input is activated (closed circuit to common).

MON_CLOSE

ON when the MON_CLOSE input is activated (open circuit to common) or when a device is not installed.

MON_OPEN

ON when the MON-OPEN input is activated (open circuit to common) or when a device is not installed.

MON_FAULT

ON when a fault has been detected on devices in MON-OPEN or MON-CLOSE inputs (if a device isn't working correctly or it isn't present).

OPEN

ON when the OPEN inputs or OPEN push button are activated (closed circuit to common). It will be ON together with other inputs. See inputs page for more details.

STOP

ON when the STOP input or STOP push button are activated (open circuit to common).

CLOSE

ON when the CLOSE input or CLOSE push button are activated (closed circuit to common).

ALARM

Turns on for 5 minutes (alarms also goes off) when the operator goes into shut down mode due to the gate hitting an obstruction (ERD) twice before reaching fully closed position.

TIMER

Blinks every 1/2 second when the timer is counting down to close automatically.

MODE

Blinks **once** every two seconds when there is a problem with the motor **sensor** feedback. Blinks twice every **two seconds** when a **motor overload** is detected. Blinks **three** times every two seconds when the gate is **jammed**.

OPENING

ON while the gate is opening.

OPEN-LIMIT

ON while the limit nut is activating the open limit switch.

CLOSING

ON while the gate is closing.

CLOSE-LIMIT

ON while the limit nut is activating the close limit switch.

AUX-IN 1

ON while AUX INPUT 1 is activated (closed circuit to common).

AUX-IN 2

ON while AUX INPUT 2 is activated (closed circuit to common).

FP_DISABLE

ON when the foot pedal is pressed down.

AC/PWR ON

ON when AC power is on. It will also blink about every 1/2 second to indicate the main board fuse is blown.

LOW-BATTERY

ON when the batteries are low, turned off or disconnected.

TIPS: When troubleshooting, it is important to note what lights are ON. It is very helpful to pay attention to the lights as they tell us what the board is doing and what inputs are active.

When calling ALL-O-MATIC for technical support please have the name of the lights that are ON in the control board. This will speed up the process to get the gate operator up and running.

TECHNICAL TIPS

Operator Symptom	Solutions (diganose)
Opening or closing LEDs are on, but gate doesn't move	If AC PWR_LED is blinking, replace the fuse at bottom right corner of the board. After replacing the fuse and before a signal is given, inspect the gate and make sure it's not bound up and that the limit switches are set correctly. If gate still doesn't run, check motor harness and make sure it is plugged in correctly and no wires are loose.
Radio receiver doesn't work	Jumper at top left corner by factory is set on 12VDC. If the receiver requires 24VDC, move the jumper to 24VDC.
AC PWR_ON LED is off	Make sure main high voltage power is connected and AC power switch is in the ON position. If that is fine, check 10Amp fuse in EMI board in the power box. If it's blown, check rectifier, it may also be damaged and need to be replaced along with the 10Amp fuse.
Gate opens very slow	Check limit switch adjustment. Usually when gate opens very slow it is due to gate hitting the receiving post or positive stop before close limit swith activates. Check the variable speed setting to be sure it's set at 100%. Check that the AC power is turned ON and that the AC PWR_ON LED is lit. Also, make sure limit learning has been done. See below.
Learning the limits for soft stop function.	Set the gate in closed position with the close limit activated. Press and release the RESET button on board. Run the gate a full cycle (full open and full close) without interruption. The first cycclc will be slower while learning the distance between limits. It will run full speed once limits have been learned.
Gate does not run and ALARM LED is ON	Gate is in Shut down mode due to obstruction detection. Press red RESET button outside control box next to radio connector. Run the gate and inspect gate is not bound up or jammed. Test ERD sensivity. See ERD adjusment page for details on the adjustment.
Gate does not run and FP_DISABLE is ON	Check foot pedel and make sure it's up. Foot pedal has a kill switch and when it's down, it disables the operator.
Gate does not run and STOP LED is ON	Check STOP input device and make sure it is not activated. Remember, this input is N.C. and LED will stay on if the wrong contact is used.
Gate does not run and MODE LED blinks	See LED DIAGNOSTICS for details on the meaning of the blinks.
Gate doesn't close	Check LEDs, any of the following input LEDs will prevent gate from closing. Check inputs for LEDs that are ON: RADIO, OPEN, STOP, EXIT LOOP, PHAN LOOP, SAFETY LOOP, FIRE ACCES, MON-CLOSE (check wiring and alignment), FP_DISABLE, (AUX INPUT 1 & 2, depending on programmed function). Also, check if AC PWR_ON LED is OFF(if it's OFF and dip-switch 4 or 7 are ON, gate will remain open).
Gate doesn't open	Check LEDs, any of the following input LEDs will prevent gate from opening. Check inputs for LEDs that are ON: STOP, CLOSE, MON-OPEN, FP-DISABLE and AUX INPUT 1 or 2 (depending on programmed fuction). Also, check if AC PWR_ON LED is OFF (if it's OFF and dip-switch 4 is OFF, gate will remain closed if battery is low)
Gate stops and reverses before reaching limits	Check ERD. If no obvious obstruction is present, it may need to be adjusted and increase the force for the direction it is stopping. See ERD adjustment page for details.
Gate stops and reverses open	Check LEDs and see if any of them turn ON when gate reverses. It may be that the gate movement might be activating that device. See above the devices that prevents gate from closing.

AUX INPUT 1 & 2 PROGRAMMING

AUX INPUT 1 & 2 can be programmed to do different functions. Below are the options

1. AUX INPUT 1

1. EMERGENCY OPEN (factory default)

Devices connected to the input in this function, will open the gate and will override MON-OPEN devices. Use N.O. contact.

2. PARTIAL OPEN (set partial open in %)

Devices connected to this input in this function, will open the gate partially to set opening %. Use N.O. contact from device relay.

3. OPEN-CMD

Devices connected to this input in this function, will open the gate. Use N.O. contact from device

4. CLOSE-CMD

Devices connected to this input in this function, will close the gate. Use N.O. contact.

5. MON-OPEN

In this function, this input is an expansion for open direction entrapment protection devices. N.C. or 10K termination can be used on device.

IMPORTANT: If N.C. termination is used, must use MON +24VDC to power device.

6. MON-CLOSE

In this function, this input is an expansion for close direction entrapment protection devices. N.C. or 10K termination can be used on device.

IMPORTANT: If N.C. termination is used, must use MON +24VDC to power device.

7. STOP-CMD

Devices connected to this input in this function, will stop the gate. Use N.C. contact.

2. AUX INPUT 2

1. EMERGENCY CLOSE (factory default)

Devices connected to the input in this function, will close the gate and will override MON-CLOSE devices. Use N.O. contact.

2. PARTIAL OPEN (set partial open in %)

Devices connected to this input in this function, will open the gate partially to set opening %. Use N.O. contact from device relay.

3. OPEN-CMD

Devices connected to this input in this function, will open the gate. Use N.O. contact from device

4. CLOSE-CMD

Devices connected to this input in this function, will close the gate. Use N.O. contact.

5. MON-OPEN

In this function, this input is an expansion for open direction entrapment protection devices. N.C. or 10K termination can be used on device.

IMPORTANT: If N.C. termination is used, must use MON +24VDC to power device.

6. MON-CLOSE

In this function, this input is an expansion for close direction entrapment protection devices. N.C. or 10K termination can be used on device.

IMPORTANT: If N.C. termination is used, must use MON +24VDC to power device..


7. STOP-CMD

Devices connected to this input in this function, will stop the gate. Use N.O. contact.

See next page on details on how to navigate through LCD display menu to program desired function on AUX INPUT 1 & 2.

Connect device relay contacts to these two terminals. Relay COMMON to board COMMON. RELAY N.O., N.C. or 10K to AUX INPUT 1. The relay contact depends on the function. See above for contact options.

Connect device relay contacts to these two terminals. Relay COMMON to board COMMON. RELAY N.O., N.C. or 10K to AUX INPUT 2. The relay contact depends on the function. See above for contact options.



LCD SETTINGS AND DIAGNOSTICS

These instructions will take you through the ALL-BLDC PRO board LCD display menu.

To wake up the display press the OK button a couple of times until you see the options for <ENG and ESP>. For English press the <left button. For Spanish press the right button. Once language is selected, scroll to settings or diagnostics, and press OK to go into selection. Use up and down buttons to scroll and right or left to move cursor. OK button is to save or select menu items.

1.SETTINGS

1.TIME DATE

1.TIME XX: XX AM

- 1.Press the OK button when the cursor on TIME.
- 2.Move the cursor with the left and right buttons to move between the hour, minutes, & AM/PM
- 3.Use the up and down buttons to adjust.
- 4.Once adjustment are made, press the OK button to save.

2.DATE XX/XX/XXXX

- 1.Press the OK button when the cursor is on DATE.
- 2.Move the cursor with the left and right buttons to move between the month, day, and year.
- 3.Use the up and down buttons to adjust.
- 4.Once the adjustment is made, press the OK button to save them.

2.SPEED

1.MAX SPEED 100%

- 1.This is for adjusting the motor maximum run speed.

2.ACCELERATION FST

- 1.This is for adjusting how fast the motor ramps up.

3.SLOW DOWN 2 FEET

- 1.This is for adjusting when the motor will start to slow down as it approaches a Limit Switch..

3.POWER

1.CURR. SENSE PRGV

- 1.This is for adjusting how responsive the ERD is..
- 2.Options are Progressive and Threshold
- 3.The threshold is the most responsive (sensitive)

2.ERD

- 1.OPEN ERD (this can be accessed directly with quick access OPEN ERD button)
 - a.This is for adjusting Opening ERD force.
- 2.CLOSE ERD (this can be accessed directly with quick access CLOSE ERD button)
 - a.This is for adjusting Closing ERD force.

4.7/DAY TIMER

1.EVENT 1-10

- 1.Each event has active and deactivate time settings for each of the Event Actions.

2.Options for the Event Actions.

- a.OPEN
- b.CLOSE
- c.AUXILIARY RELAY

5.LEAF DELAY

1.DELAY CLOSE

- 1.Select if the delay is for OPEN or CLOSE
- 2.Mainly for swing gates that overlap

2.DELAY 00.0 SEC

- 1.Here where you set the delay in seconds.

6.PRE-WARN ALARM (this uses the built in audible alarm to turn on when gate is in motion)

1.ALARM OFF

- 1.Set it ON or OFF here.

2.DELAY 00.0 SEC

- 1.Set the delay here.
- 2.Range is from 0-12 seconds.

7.AUXILIARY RELAY (below are the options of relay activation)

1.OFF (INACTIVE)*

2.PRE-WARN SIGNAL (this is similar to the PRE-WARN ALARM function)

3.MOVING SIGNAL (this function turns ON the auxiliary relay while the gate is moving)

4.OPENED SIGNAL (relay activates when gate is fully opened)

5.CLOSED SIGNAL (relay activates when gate is fully closed)

6.PULSE ON OPEN (relay does a 1 second pulse when open limit activates)

8.AUXILIARY INPUT (input 1 has the EMERGENCY OPEN and input 2 has the EMERGENCY CLOSE)

1.AUX INPUT 1-2

- 1.EMERGENCY OPEN/CLOSE * (this function will override the monitored open/close input and allow the gate to fully open/close)

2.PARTIAL OPEN (this function is to open the gate partially with opening percentage setting)

3.OPEN_CMD (this will work identical to the other open inputs)

4.CLOSE_CMD (this will work identical to the CLOSE input)

5.MON-OPEN (this is an expansion to the MON-OPEN input)

6.MON-CLOSE (this is an expansion to the MON-CLOSE input)

7.STOP_CMD (this will work identical to the STOP input)

9.SERVICE CYCLE (this will provide a planned service call based on run cycles)

1.SERVICE CYCLE

- 1.Program the number of cycles the gate needs to run before the next preventive maintenance service call.

- 2.When programmed, the board will start the count down. When it gets to zero, it will start beeping to alert the end user it's time to call for service.

- 3.Technician can reset in diagnostics cycle count

LCD SETTINGS AND DIAGNOSTICS (CONT.)

- 2.COUNT 00000
 - 1.Use <right and left> buttons to move the cursor to tens, hundreds, thousands and 10 thousands position.
 - 2.Use UP and DOWN buttons to adjust the value
- 10.AUTO CLOSE TIMER
 - 1.AUTO CLOSE TIMER (this can be accessed with the quick access TIMER push button)
 - 2.SET DELAY: 005 (delay is adjustable from 0-120 seconds)
- 11.SETTINGS CHG LOG (this will keep a log of the last 3 times the settings were adjusted/changed)
 - 1. 01. SETTINGS CHG
 - 2. XX/XX/XX 00:00AM
 - 1.It will save the date and time.
- 12.FIRMWARE UPDATE (firmware could be upgraded in the field)
 - 1.PLUG IN A THUMB DRIVE
 - 1.This is to update firmware in the field if necessary. AOM can provide the BIN file via email, the installer can then mount it into a thumb drive to then plug it in the board USB input to do the update.
 - 2.The thumb drive must be formatted to FAT, FAT16 or FAT32 to be readable by the board.
- 13.WIRELESS SETUP (when wireless PRIMARY/SECONDARY is used and there are other operators nearby using the same communication, it will be necessary for the different systems to have unique channels. This is where channels can be changed. There are 8 channels to choose from)
 - 1.WIRELESS CHANNEL
 - 1.Make sure the pair of operators are set to the same channel.
- 14.SET TO DEFAULT (Set individual or all settings to factory default)
 - 1.DEFAUL ALL
 - 2.DEFAULT SPEED
 - 3.DEFAULT POWER
 - 4.DEFAULT 7/D TMR
 - 5.DEFAULT LEAF DLY
 - 6.DEFAULT PRE ALRM
 - 7.DEFAULT AUX RLY
 - 8.DEFAULT AUX INS
 - 9.DEFAULT SVC CYC
 - 10.DEFAULT AUTO CLS
 - 11.DEFAULT WIRELESS


1.DIAGNOSTICS

- 1.GATE STATUS
 - 1.CLOSED, OPENED OR STOPPED STATUS
- 2.METER (this provides voltage readings from the BATTERY and LINE IN inputs)
 - 1.BATT VOLTAGE
 - 2.LINE IN VOLTAGE
- 3.MOTOR (this provides the motor speed and the gate travel in percentage)
 - 1.MOTOR SPEED
 - 2.TRAVEL
- 4.LAST EVENT (this displays the last event that was recorded)
 - 1. 50. (LAST LOGGED EVENT NAME)
 - 2. XX/XX/XX 00:00PM (LAST EVENT TIME & DATE)
- 5.EVENT LOG (this provides the event log; it can store up to 50 special events)
 - 1.1-50 LOGGED EVENTS
- 6.CYCLE COUNT (this provides the cycle count of the unit; including the service cycle count in case one was programmed)
 - 1.LIFE CYCLES
 - 2.MONTH CYCLES
 - 3.DAY CYCLES
 - 4.SERVICE CYCLES (the service cycle count will be displayed and will show the option to reset if it has reached the zero count)
- 7.EXPORT TO USB
 - 1.PLUG IN A THUMB DRIVE
 - 1.This allows the settings and diagnostic data to be exported to a thumb drive to view on a smartphone or pc; thumb drive must be formatted to FAT, FAT16 or FAT32 in order to work.

SW-300 AND SW-350 DC EMERGENCY RELEASE

Procedures to manually open the **SW-300 DC**:

1. Remove the bolt or pad lock from the arm lever and open the lever fully.
2. Opening the arm lever will allow you to manually open and close the gate.



Procedures to manually open the **SW-350 DC**:

1. Turn operator power "OFF"
2. Push foot pedal down and move to the left to lock pedal in down position
3. Push gate open




SW-320DC PRO & SW-325DC PRO MANUAL RELEASE


To release the gate for manual operation, follow these steps:

1. Remove the bolt or pad lock from the quick release.
2. Slide the quick release assembly out from the crank arm.
3. Bend the arm slightly to start the opening of the gate. Grab and pull the gate to the open position.

To put the operator back into normal operation, align the primary arm with the crank arm and slide the quick release assembly back into the crank arm. Lock it with a bolt or pad lock.




SWING ARM ASSEMBLY FOR SW-300DC PRO AND SW-350DC PRO




RECTANGULAR ARM

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	QRA-300RR	SW Quick Release Arm	1
2	SPA-300RR	SW Primary Arm	1
3	SSA-300RR	SW Secondary Arm	1
4	SAB-300RR	SW Arm Connecting Bar	1
5	SGB-300RR	SW Arm Gate Bracket	1
6	1/2-13 X 3.5 Hex Bolt	Hex Pivot Bolt	1
7	1/2-13x2.25 Hex Bolt	Hex Pivot Bolt	1
8	1/2 Flat Washer	Flat Washer	4
9	1/2-13 Hex Nylon Lock Nut	Nylon Lock Nut	2
10	SSH-300RR	SW Shaft Hub	1



ROUND PIPE ARM

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	QRA-RD300	SW Quick Release Arm	1
2	SPA-RD300	SW Primary Arm	1
3	SSA-RD300	SW Secondary Pipe Arm	1
4	SKN-RD300	SW Arm Connecting Knuckle	2
5	SGB-RD300	SW Arm Gate Bracket	1
6	SAB-RD300	SW Arm Spacer bushing	1
7	1/2-13 X 2.25 Hex bolt	Hex Bolt (Pivot bolt)	2
8	1/2-13 hex Nylon lock nut	Nylon Hex Nut	2
9	1/2" Flat Washer	Flat Washer	2
10	3/8-16 Hex Nut	Hex Nut	2
11	3/8 Split Lock Washer	Split Lock Washer	2
12	3/8-16 X 1.75 Carriage Bolt	Carriage Bolt	2
13	SSH-300RR	SW Shaft Hub	1



SIZE DWG. NO.	
A	SW-ARM Assembly

SWING ARM ASSEMBLY FOR SW-320DC PRO
AND SW-325DC PRO

DETAIL D

DETAIL I

DETAIL G

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	SAB-300RR	SW Arm Connecting Bar	2
2	SSA-300RR	SW Secondary Arm	1
3	SAS-325	SW Arm Spacer	1
4	SGB-300RR	SW-Gate Bracket	1
5	SPA-325	Primary arm	1
6	SQR-325	Quick Release	1
7	1/2-13 X 13/4 Hex bolt	Gate bracket Pivot bolt	1
8	1/2-13 X 3 1/4" Hex Bolt	Arm Center Pivot Bolt	1
9	1/2 Flat washer	Flat washer	4
10	1/2-13 Nylon Lock Nut	Pivot Lock nut	2
11	SCA-325	Crank Arm	1

TITLE:

SW-325DC Arm kit

SIZE DWG. NO. **A** REV

SCALE: 1:50WEIGHT: SHEET 1 OF 1

WARRANTY AND RECORD

MANUFACTURER'S LIMITED WARRANTY

ALL-O-MATIC INC warrants the following gate operators (SW-300DC PRO, SW-320DC PRO, SW-325DC PRO, SW-350DC PRO) for a period of five (5) years in commercial installations and for a period of seven (7) years in residential installations. The above operators, within their warranty period, are to be free from defects in circuitry, motor, gearbox and workmanship. This warranty begins from the date of purchase to the original owner. Warrantor will repair or, at its option, replace any device which it finds to require service. This device must be sent to the warrantor at the consumer's expense to:

**ALL-O-MATIC INC.
7820 GLORIA AVE.
VAN NUYS, CA 91406**

The warrantor will return the repaired or replaced unit to the customer at the consumer's expense. Labor charges for dealer service or replacement are the responsibility of the owner. These warranties are in lieu of all other warranties either expressed or implied, and ALL-O-MATIC INC shall not be liable for consequential damage. All implied warranties of merchantability and or fitness for a particular purpose are hereby disclaimed and excluded. This limitation is not valid in jurisdictions which do not allow limitation of incidental or consequential damages or limitation of warranty periods. In order to obtain this policy, please complete the registration card and send it by mail within 30 days of purchasing from ALL-O-MATIC INC. or your installer. If product is not registered, only a one year warranty on all parts will be provided.

CUSTOMERS RECORD

Customer Name _____

Address _____

Purchased from (Installation Co.) _____

Date ____/____/____

Model Number _____

Serial Number _____ - _____

