

## Instructions for Installment of PoE Circuit Board



IO BOARD

BASE BOARD

CPU BOARD

POWER INPUT  
JUMPER



PoE BOARD  
MOUNTING  
AREA

POWER INPUT  
JUMPER



1. Disconnect Power from Base board
2. Locate Standoff Mounting Holes in Base Board and Support Posts supplied in kit
3. Press One end of Support Post into Holes in Base Board
4. Locate and Position PoE Board over Support Posts and Align Contact Pins with Receiver Block.  
Note 6 Pin Contact is at Upper Edge and 5-Pin is at Bottom Edge.
5. Press and Lock PoE Board into position on Base Board aligning Support Pins and Contact Pins.
6. Locate Power Input Jumper on Base board (Lower Right Hand Corner)
7. Move Power Jumper from Lower Bottom Right Two terminals to Connect Lower Bottom Left Terminals.
8. Connect Ethernet Cable to Base Board.