

PS20 Wiring Information

For wire diameters larger than 5/16"

- 1- Loosen the top portion of the strain relief.
- 2- Insert the large diameter cord into the cord cutout.
- 3- Tighten the 2 retaining screws, ensuring a snug fit around the cord.



For wire diameters smaller than 1/4"

- 1- Detach the top portion of the strain relief by loosening the 2 retaining screws.
- 2- Remove the screws from the top portion of the strain relief.
- 3- Turn the top half of the strain relief over, so that the flat side is facing the bottom cord cutout.
- 4- Insert the smaller coil cord into the cutout.
- 5- Replace the screws into the top portion of the strain relief, ensuring a snug fit around the cord.

