## 1802-EPD Heater Kit Part Number 2600-582



## **IMPORTANT!**

Power the heater assembly only from the 16 V, 20 VA transformer supplied. **Do not power the heater from the telephone entry system power transformer.** 


The 2600-582 Heater Kit allows the 1802-EPD Telephone Entry System LCD display to maintain normal operation to approximately -20°F (-29°C). The heater assembly has a built-in thermostat that will automatically turn the heater on when the temperature drops below 40°F (4°C).

1 ea. Heater Assembly


1 ea. Transformer 16 V, 20 VA

2 ea. Wire Nuts


4 ea. Nylon Washers




Remove the two (2) screws from the lower part of the display board .



Install the heater assembly with the nylon washers supplied. The nylon washers MUST be installed between the heater assembly and the display circuit board. Replace the screws removed in step 1.



Connect the heater assembly wires to the 16 V, 20 VA transformer using the wire nuts supplied. DO NOT power the heater assembly from the telephone entry system power transformer.



P/N 2338-065 REV C 10/17 Page 1