

EAGLE 100-200-AC PARTS LIST AND ILLUSTRATIONS


Diamond Board ONLY

Eagle-100 / Eagle-200 Series Replacement Parts

E-Number Part Description

- E101 - Eagle-100 Limit Switch Assembly (Complete)**
 E102 - Eagle-100 Limit Switch Bracket
 E103 - Limit Switch
 E104 - Eagle-200 Limit Switch Bracket
E105 - Eagle-200 Limit Switch Assembly (Complete)
 E111 - Eagle-100 Operator Cover
 E114 - Eagle-100 Release Cover
 E115 - Eagle-100 Release Cover Cap
 E116 - Easy Release Main Swing Arm
 E130 - Electrical Outlet
 E131 - Power Switch
 E146 - Pulley (SGR)
 E147 - 2 1/2" Motor Pulley (1/2 HP or 1 HP)
 E148 - 2" Motor Pulley (DM)
 E151 - Eagle-200 limit Chain #35
E152 - Clutch Kit (Complete)
 E153 - Eagle-200 Sprocket (SGR)
 E173 - 1/2 HP V-Belt (Single Motor)
 E174 - 1 HP/Dual Motor V-Belt
 E175 - Limit Switch Activator
 E180 - Eagle-200 Primary Gear Reducer (PGR)
 E182 - Eagle-100 Primary Gear Reducer (PGR)
 E185 - 1/2 HP Motor
 E186 - Secondary Gear Reducer (SGR)
 E190 - Eagle-200 Chassis
 E191 - Control Board Box
 E192A - Eagle-200 Right Chassis Leg
 E192B - Eagle-200 Left Chassis Leg
 E193 - Eagle-200 Leg Bracket
 E195 - Eagle-100 Chassis
 E196A - Eagle-100 Right Chassis Leg
 E196B - Eagle-100 Left Chassis Leg
 E197 - Eagle-100 Leg Bracket
 E222 - Eagle-200 Operator Cover
 E223 - Operator Cover Door Frame
 E224 - Operator Cover Door
 E225 - Eagle-200 Release Cover
 E226 - Eagle-200 Release Cover Cap
 E471 - Large Arm
 E472 - Small Arm
 E473 - Arm Attachment Plate
 E475 - Extension Arm
 E476 - Weld Plate (Gate Attachment Bracket)
E515 - Swing Arm Assembly (Complete)
 E525 - Plastic Eagle Logo Plaque
 E555 - Diamond Control Board
 E721 - Arm Hub
 E722 - Plastic Cup
 E723 - Sprocket (PGR)
 E724 - Pillow Block
 E725 - Limit Sprocket
 E726 - Limit Shaft
 E727 - Limit Box
 E728 - Eagle-100 Limit Chain #35
 E729 - Drive Chain #50 (Side Position)

Diamond Board Replacement Parts



If you are uncertain about a specific part you may need, please call us for assistance:

1-800-708-8848