

Activating a system on the Cloud...



DKS Cloud Logging In

The DKS Cloud is available for:

- ✓ DKS Cellular
- ✓ DKS VoIP Voice & Data
- ✓ DKS Data over IP
- ✓ IM Server-Modem



https://access.doorking.com

LOGIN

User ID	rmiller-demo
Password	
	Login
	Forgot Password?



DKS Cloud Logging In

No Hardware Changes needed!

✓ Works with 30 Series control boards





The DKS Cloud

The DKS Cloud is
Controlled from
the Internet
Management Server
registration sites:


- > DKS IM Server
- > DKS Cellular





IM Server registration site:

This is where you will add, edit or remove systems that are using the DKS Cloud.





To activate a system for the Cloud:


- Click on a system,
- Check the "Enable on DKS Cloud" box.
- Click "Update"





NOTE: Systems "Active" for the Cloud:

- Sending Data will be blocked from desktop software 6.5 or earlier.
- This is to ensure the Cloud is the True Database





> The systems will then be available when you log into the Cloud.

