INTRODUCING





How to give permission for people to program on the DKS Cloud!



The DKS Cloud

The DKS Cloud is
Controlled from
the Internet
Management Server
registration sites:

- > DKS IM Server
- > DKS Cellular





If you do not have a User ID, or need to create one for a Tech or Manager:

> Register as a Data **Entry Only user.**

The DKS Cloud

dksdb.dksoftware.com/NewUserRegChoice.aspx



DKS Registration

Register your DoorKing Account Manager software to receive update notifications and other benefits, and to enable Internet programming via the IM Server or the DKS Cellular

Choose your Registration Type.

Various types of registration are available through this site

Click the IM / DKS VoIP button below to register for an IM Server Modem subscription, an IM Server VoIP subscription, or as a person who only programs existing systems, including via direct modem.

To register for voice and data plans using our **DKS Cellular** devices, click the **DKS Cellular** button below.

If you have already registered, you can log in here.

ive Chat now

Proof of Insurance Form W-9 Vendor Verification

IM / DKS VoIP

Choose this option to activate any of the following registrations:

DKS VoIP: Utilize the DKS Voice-Over-IP telephone service, and program your entry systems using our Plug & Play" networking.

- · Voice and Data Service For 1830 Series entry systems.
- Voice Only Service For all DoorKing entry systems.

DKS Data over IP: Plug & Play Internet programming.

· Data over IP Service (formerly IM Server

For 1830 Series entry systems with an existing phone line.

IM Server Modem: Program your entry systems over the internet from your PC using the existing telephone line connected to the entry system.

Data Entry: For those programming entry systems that already have an active subscription. Or if you program your entry system using a direct connection or your own PC modem.

DKS Cellular

Choose this option to activate your DKS Cellular plans for DoorKing Cellular compatible entry systems. The following Service Types are

- · Voice and Data Service.
- . Data Only Service.
- · Voice Only Service.



Permitting Cloud access:


- ✓ The "registered owner" can grant access to other "user id's":
 - ✓ Office staff for programming
 - ✓ Service techs





Permitting Cloud access:


Each person will need a valid User ID on the DKS Server.





Permitting Cloud access:

- Click on the account you wish to share.
- In "Manage Users" field enter a User ID
- > Click on "Add User ID".





Permitting Cloud access:

When this person logs into the cloud under their User ID they will see these systems and can work on them.

