VIKING ACCESS X390 PARTS LIST AND ILLUSTRATIONS

PARTS DIAGRAM - OPERATOR:

Item	Description	Part No.
1	Protective Cover	FA-727292
2	Limit Switch Cover	FAX390C
3	Limit Switch (1) and Cam (1)	FA-390682
4	Limit Plate	FAX390P
5	Mounting Frame	FA-722471
6	Motor/Gear Assembly	FA-104579
7	Manual Release Key	FA-713001
8	Positive Stop Assembly	X390PSE
9	Articulated Arm - Steel	FA-7387051



GATEDEPOT.COM

VIKING ACCESS X390 PARTS LIST AND ILLUSTRATIONS

PARTS DIAGRAM - CONTROLLER:



Item	Description	Part No.
1	Control Board - Primary	VFLEXPCBU18
2	Motor Connector - Primary	FAECUMCM39
3	Power Harness - Primary	DUPHCECU
4	Secondary Power Harness *(Dual Controller only)*	VECUSPH
5	Primary/Secondary Comm Cable *(Dual Controller only)*	VECUMSC
6	Secondary Module *(Dual Controller only)*	VFLEXSMU18
7	EMI Board	DUEMI10
8	EMI Comm Cable	HUSIGEMISW
9	Toroid Transformer - 10 amp	DUTT10
10	Battery	DUBB12
11	Battery Switch	DUMRS10
12	ECU Enclosure w/ PCB Back Plate	ECUEB
13	Alarm Reset Switch	ECUARS
14	Fuse Kit	DUFSKNX
15	ECU Antenna Kit	ECUAH
16	Strain Relief (ECU)	DH3/4NMCC
17	ECU Audio Alarm	ECUAA
18	6 Conductor Cable, per Foot	VA-CB16