



Quick Install Guide

WXP Details & Supported Devices




Items Included in Kit


- Unify Unit
- 12v / 5 Amp power supply (built in) ⚠
- Quick Install Guide
- Activation & Test Process
- Customer Information Packet

Recommended wiring: 18/6 shielded for main device, and 18/4 shielded for optional wiegand devices ⚠

WXP Unit



Power Supply Wiring (pre-wired)



**Ground
Terminal**


Enlarged

12v Fuse Terminal




Important Item

Expansion Board




Expansion Board Default Configuration




****All wiring drawn should use 18-gauge cable**** ⚠️

Gate/Door Wiring Diagram



****All wiring drawn should use 18-gauge cable**** ⚠

Magnetic Lock Wiring – Normally Open



****All wiring drawn should use 18-gauge cable****



Magnetic Lock Wiring – Normally Closed

